











70*110mm 铜版纸128g

User Manual Electric Teeth Cleaner with LED Screen 	Dear customer, thanks for purchasing this product. Please read the user manual carefully before use and keep it for future reference. Product Introduction This is a personal oral care device. It uses high frequency vibrations to effectively remove tartar, calculus, smoke stains, tea stains, coffee stains and more from teeth, bringing back your clean and healthy teeth. It's designed to be compact and simple, easy and safe to use at home. Precautions - The device is for adults use only. Keep out of reach of children to avoid injury. - Do not soak the body of the device in water. - The device has a built-in rechargeable battery. Do not throw into fire or charge, use, or leave in a high temperature environment. - Do not touch the working tip while the device is on. - Do not use the device if it is visibly damaged. Product Features - LED Screen: Show intensity and battery directly 5 Intensities: Offer multiple options for different users - High Vibrations: Deliver great teeth cleaning effect - Versatile: Do the job of cleaning as well polishing - Smart Memory: Select last choice automatically - Safe: Stainless steel working tip & waterproof body - Accurate: LED auxiliary light helps target tartar or stains - Eco-Friendly: Built-in 250mAh rechargeable battery - Comfortable: Silicone handle provides snug grip	Product Overview 	 Hook-Like Cleaning Head Hook-Like Cleaning Head  Hook-Like Cleaning Head Suitable for removing stains and polishing  Brush Cleaning Head (Optional) Brush Cleaning Head (Optional) Charging Methods - When the battery is running low, the battery icon on the LED screen flashes (shows no bar of power left), which reminds you to recharge the device. - Connect the device with a 5V/1A adapter (not included) via the DC charging cable. Then plug the adapter into the socket. - The battery icon will scroll during charging and stop scroll (show 3 bars of power) once charging finished.	Assemble & Disassemble Cleaning Head    Assemble: Pinch the cleaning head. Make an angle of 45° or so between the working tip and the front of device, press the cleaning head down to the root of shaft, and then rotate counterclockwise until it stops. Note: Do not touch the working tip during the process to avoid injury. Disassemble: Pinch the cleaning head and rotate clockwise to remove it.
--	---	---	--	---

Application Methods  1. Choose and assemble a suitable cleaning head.  2. Clean the working tip with running water or alcohol. Note: Recommend to disinfect the working tip with alcohol.	 3. Press the Power Button to turn the device on. The LED light will turn on automatically. The default mode is the Soft Mode.  4. Press the Power/Intensity Button to choose an intensity. There are 5 intensities. The longer the intensity icon, the higher the intensity. Note: Recommend beginners to start with the lowest intensity. Note: The device comes with smart memory function, which means it will select your last choice automatically.	 45°  90° 5. Look in a mirror, and apply the working tip to the needed part on your teeth to remove any tartar or stain. Note: When removing tartar, it's better to keep an angle of 45° between the working tip and teeth; When removing stain and polishing, it's better to keep an angle of 90° between the working tip and teeth. Note: Do not press the cleaning head too hard during using.  6. After use, press and hold the Power/Intensity Button to turn the device off. The LED light will go out automatically. Gargle with clean water.	 7. Rinse the cleaning head under water. Wipe dry or wait for air dry, then put the device in a clean place. Store & Care - Rinse the body of device or wipe with wet cloth if there is any dirt on its surface. - Place the device in cool shadow. Avoid direct sunlight or high temperature. - Keep the device out of reach of children to avoid any hazard. - The device has a built-in rechargeable battery. To maintain its service life, please recharge the device every 3 months if it is not in use for a long time. - Never attempt to open or repair the device yourself. If any malfunction happens or it doesn't work, please contact the customer service center.	Specifications Name: Electric Teeth Cleaner with LED Screen Battery Capacity: 250mAh Charging Mode: DC Charging Working Voltage: 3.7~4.2V Rated Current: 130mA Max Waterproof Grade: IPX6 Store Temperature: -10 °C - 40 °C Package Contents: 1* Device Body 1* Hook-Like Cleaning Head 1* Flat Hook-Like Cleaning Head 1* Brush Cleaning Head (Optional) 1* DC Charging Cable 1* User Manual
--	---	---	---	---

