

尺寸：105x148mm

英语

User Manual
Wired Backlit Keyboard

English


Model: IWG-DHXXB01

Specification

Dimension	44.5 * 10 * 4.5 CM
Weight	690 g
Length of the wire	1.5 M
Compatible Operating System	Win XP / Win 7/ Win 8 / Win 10

Instructions of multimedia keys

For using multimedia functions, you need to press and hold the button "Fn" first, and then press the corresponding function button.



Press F1-F12 keys directly, you can only use the functions of F1-F12.

EN-1

Instruction of Multimedia Key Function

- Fn + F1 (Music icon) Music Player
- Fn + F2 (Volume - icon) Volume -
- Fn + F3 (Volume + icon) Volume +
- Fn + F4 (Mute icon) Mute
- Fn + F5 (Previous Music icon) Previous Music
- Fn + F6 (Next Music icon) Next Music
- Fn + F7 (Pause/Play icon) Pause/Play
- Fn + F8 (Halt Key icon) Halt Key
- Fn + F9 (Home Page icon) Home Page
- Fn + F10 (E-mail icon) E-mail
- Fn + F11 (My Computer icon) My Computer
- Fn + F12 (Favorite icon) Favorite

EN-2

Instruction of Backlight

- Press the button (Backlight icon), then you can switch on / off the backlight of the keyboard.
- Press and hold the button (Fn) first, and then press the button (Pause), you can switch on / off breathing light mode of backlight.
- Press and hold the button (Fn) first, and then press the button (Page Up) / (Page Down), you can adjust the brightness of the backlight.

Instruction of typing Special symbol

| €

For typing these Special symbols, you need to press and hold the button (Alt Gr) first, and then press the corresponding function button.

EN-3

德语

Bedienungsanleitung
der Beleuchteten Tastatur

Deutsch


Model: IWG-DHXXB01

Spezifikation

Abmessung	44.5 * 10 * 4.5 CM
Nettogewicht	690 g
Kabellänge	1.5 M
Kompatible Systeme	Win XP / Win 7/ Win 8 / Win 10

Funktionentasten

Drücken Sie FN + F1-F12 zusammen, um entsprechende Funktion zu aktivieren.



DE-1

Anweisung der Multifunktionentasten


- Fn + F1 (Musik icon) Musik
- Fn + F2 (Lautstärke - icon) Lautstärke -
- Fn + F3 (Lautstärke + icon) Lautstärke +
- Fn + F4 (Stumm icon) Stumm
- Fn + F5 (vorheriges Stück icon) vorheriges Stück
- Fn + F6 (nächstes Stück icon) nächstes Stück
- Fn + F7 (Pause / Start icon) Pause / Start
- Fn + F8 (Halt icon) Halt
- Fn + F9 (Browser icon) Browser
- Fn + F10 (Email icon) Email
- Fn + F11 (mein Computer icon) mein Computer
- Fn + F12 (Web-Favoriten icon) Web-Favoriten

DE-2

Hintergrundbeleuchtung

- Klicken Sie (Backlight icon), um die Hintergrundbeleuchtung ein- oder auszuschalten.
- Drücken Sie (Fn) + (Pause) zusammen, um den Atmung-Modus ein-oder auszuschalten.
- Drücken Sie (Fn) + (Page Up) / (Page Down) zusammen, um die Helligkeit der Hintergrundbeleuchtung umzustellen.

Sonderzeichen



Die Tasten mit Pfeilchen sollten mit (Alt Gr) zusammengedrückt werden.

DE-3



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

