

QUICK START GUIDE

Food Server Supreme - FSPW-SS

Tips and tricks to help you get started with your new Server topping warmer.

1

Remove unit from box. Clean, rinse, sanitize, and air dry all parts.




Never immerse complete unit into water. Electrical shock could occur. Be aware of the product you are serving and the temperature the product is required to maintain.




2

See separate pump quick start guide and manual for pump set-up and cleaning instructions.




3

Do NOT add water to basin. Ensure pouch support is inside warmer. Plug cord into power source and press switch to ON. Pre-heat unit for at least 15 minutes with pump installed and thermostat knob set at maximum setting.




4

Attach pump to pouch. Place pouch on countertop with pouch fitment circle facing upward. Position pump connector directly over center of pouch fitment. Press pump connector down to pierce through film in pouch fitment.




Pump is fully engaged when top surface of pouch fitment touches pump connector rim.



5


Install pump and pouch combo into warmer. Hold pump with pouch wrapped up around both sides of pump.

IMPORTANT: Fold sides of pouch up around pump to assist with food flow and allow pump to fit.



6

Set thermostat knob to recommended serving temperature. Dial indicator uses increments of 10° F. To heat unit faster, thermostat may TEMPORARILY be rotated to maximum.




7

Allow unit to cool before cleaning.



Clean external surfaces daily with a clean damp cloth. Dry with clean soft cloth. Glass and surface cleaners approved for use in food contact areas may be used.



WANT TO LEARN MORE?

Visit server-products.com/manual-more for your manual, part breakdown, support videos and more.

spsales@server-products.com | 800.558.8722



Manual & More

MODEL
XXXX
P/N
#####



SERIES
##X ##X

2 YEAR
WARRANTY

REFERENCE YOUR PART NUMBER (P/N) LOCATED ON THE LID OR BASE.