



REPUBLIC

Starbuds 3

Black Edition

TRUE WIRELESS EARPHONES

USER MANUAL

Model No: NU517

INTRODUCTION TO EARPHONES

Thank you for purchasing Starbuds 3 True Wireless Earphones. This guide is provided to help you get started quickly with your true wireless earphones; please read it carefully and save it for your future reference.

SAFETY INSTRUCTIONS

Read the instruction manual carefully and completely before using the product.

PREVENTING DAMAGE TO HEALTH AND PRODUCT

- Protect your hearing from high volume levels. Permanent hearing damage may occur when earphones are used at high volume for prolonged periods of time.
- Don't charge them with high voltage adaptors.
- Don't allow children or infirm to play with your earphones without adult supervision.
- Don't use the product in an environment that requires special attention (e.g. in traffic).
- Don't use earphones near water, Clean using dry or slight moist cloth.
- Store earphones at room temperature.
- Don't use in extreme dry environments as it leads to static discharge during usage.
- Don't expose your earphones to temperature above 40 degrees, Keep out of direct sunlight.
- Don't attempt to repair the product yourself. It will void product warranty.
- Don't drop, puncture or expose your earphones to excessive trauma.
- Always press all buttons carefully. Don't mishandle your earphones.
- Don't place near object generating strong magnetic field.
- Use only the supplied charging cable. Unplug the device when not in use or during lightning storm.

- Don't expose earphones to excessive heat or fire.

INTENDED USE/LIABILITY

Nu Republic does not accept liability for damage arising from improper use or misuse of this product and it's attached accessories.

USAGE INSTRUCTIONS




- Answer The Call- Click on the L/R ear
- Hang Up The Call- Click on the L/R ear
- Reject The Call- Long Press L/R ear for 2 Seconds
- Redial the last number- Double click on the L/R ear
- Next Song- Long Press L/R ear for 2 Seconds
- Play Song- Click on the L/R ear
- Pause Song- Click on the L/R ear
- Siri- Triple Click L/R ear
- On/Off- Long Press L/R ear for 3 Seconds

INCLUDED WITH EARPHONES

- Starbuds 3 Black Edition TWS
- 3 Sets of Eargels in 3 sizes
- USB charging Cable
- Charging/ Storage Case
- User Manual

UNDERSTANDING THE EARPHONES



A: Button Controls
B: Indicator Light
C: Charging Port
D: Silicone Earphones Caps
E: Sound Hole



A: Left Ear
B: Right Ear
C: Micro Charging Port
D: Battery Indicator LED light

PAIRING YOUR EARPHONES

- Open the charging case and take out the left and right earphones.
- Long press both the earphones for 3 seconds. The red and blue light will start flash alternately. This indicates the earphones have entered the pairing state.
- Turn on the Bluetooth of the mobile phone, search the Bluetooth name of the earphones "Nu Republic"

OTHER INSTRUCTIONS:

- The earphones will re-connect the last paired smart phone automatically once they power on.
- If you want the earphones to connect with other device, turn off the Bluetooth of the last paired device and then the earphone will be available for pairing with a new device.
- Put the earphones back in the charging case and they will charge automatically.
- The earphones will power off automatically in 5 minutes if they are not connected to any Bluetooth device.
- Make sure the earphones are in pairing mode (the blue indicator of the master earphone blinks quickly) if your new device does not find "Nu Republic"

SHUTTING DOWN YOUR EARPHONES

- After using the earphones, put it back into the charging case and the earphones will shut down automatically for charging.

CHARGING YOUR EARPHONES

- Before the first use, take the earphones out from the charging case and take off the protection film on each earphone. Put them back in the case and charge it with the included Micro USB Cable.
- For daily use, just put the earphones in the box to charge them.
- Earphones Charging Indicator: Red LED light will flash while charging and when the earphones are fully charged the Blue Light will turn on.

LED LIGHT INDICATOR

Charging Case

- When the case is charging: Blue LED Flashing
- Charging Case fully charged: Blue LED stable
- Charging time: 2 Hour

Earphones

- Pairing mode on: Blue & Red LED Alternately Flashing
- Earphones Paired: Blue LED slow flashing
- Battery Indication: Red LED flashes every 5 seconds
- Charging: Red LED flashes
- Earphones fully charges: Blue LED stable
- Charging time: 2 Hours

SPECIFICATIONS

Bluetooth Version	5.0
Bluetooth Protocol	HSP, HFP, A2DP, AVRCP
Working Distance	10m / 33Ft
Music Working Time	4-5 hours*
Standby Time	120 hours*
Charging Time	2 hour*
Earbuds Battery Capacity	45mAh
Charging Case Battery Capacity	350mAh
Playing System	iOs and Android
Support Function	Hands-free Calling, Siri Voice Control, Google Voice Assistant
Frequency	20Hz-20KHz
Single Earbud Weight	5.25 g
Charging Case Weight	38.8 g
Charging Case Charging Port	Micro-USB
Charging Time for Earphones	2-3 Times
Earbud Product Size	22mmX18mmX 21mm
Charging Case Product Size	69mmX33mmX 28mm

PRODUCT FEATURES

- Support AI intelligent voice function, support voice assistant function of iOS and android system.
- In-ear design, comfortable and not easy to fall down.
- One touch button design, more convenient than other buttons on TWS earphones.
- Equipped with charging case.
- When mobile phone has an incoming call, the headset is automatically turned on and answered when it is picked up from charging case.
- Support iOS system and Android system power display.
- Hi-fi sound effect with built-in 10MM dynamics drivers.
- Pair automatically after taking out from charging case.

Notes:

If you do not charge the earphones for a long time, the battery life will be greatly shortened. It is recommended that you charge the earphones at least once a month.

CHOOSING PERFECT EARTIPS

It provides ear-tips in small/medium/large three sizes, made from premium grade rubber.

Select an ear-tip that provides the best fit and sound isolation. It should be easy to insert, fit comfortably, and easy to remove.

DISCARDING THE EARPHONES

For proper treatment to avoid harmful effect on human health and environment, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

UNDERSTANDING THE WARRANTY

Nu Republic thanks you for showing confidence in our products and becoming our valued customers. To ensure a delightful product experience Nu Republic recommends reading the user guide carefully and contacting our customer care helpline to understand the product warranty period.

Nu Republic warrants that the product at the time of its original purchase is free of defects in material and workmanship.

This warranty is subject to the following terms

- The warranty is given only to original purchaser of the product ("customer")
- The warranty will be applicable for 6 months from date of original purchase or 18 months from date of import as mentioned in the import sticker on the box whichever is earlier. The customer has to present the proof of payment/ invoice for claiming any warranty.
- For entire warranty period, Nu Republic or its authorized representative will at their discretion repair or replace the product.
- The details of the service locations can be taken from our service helpline. It is responsibility of the Customer to bring the product to Nu Republic Service Location at his/her own risk and expenses.

For any product repaired or replaced dur warranty period, the repaired or replaced product shall continue being within period of the original product.

The warranty will not be applicable under following circumstances:

- The product code/serial number, water indicator or warranty seal has been removed, erased, defaced altered or is illegible.
- Deterioration of the product due to normal wear and tear.
- Use other than in accordance with the user manual, rough handling, ingresson of /exposure to any kind of liquid (water, sweat, beverages, oils etc.) exposure to moisture, dampness or exposure to extreme environmental conditions.
- The warranty will also not cover any physical damage to surface of the product including but not limited to scratches on the body parts.
- As defects caused by the fact that the battery has been short circuited or by the fact that the seals of the casing or any evidence of tampering or the product is used for equipment other that for which it is certified.

For any claim under the warranty is subject to notification to Nu Republic. For the alleged defect within a reasonable time of its occurrence and in no event not later than expiry of warranty period.

Nu Republic / authorized partner will not be responsible for any kind of losses direct or indirect.

Nu Republic's obligation under this warranty shall be limited to repair or providing replacement of parts only the maximum claim entertained by Nu Republic will be subject to maximum retail price of the product or purchase price (as per invoice) whichever one is lower.

Note: Check out our website www.nurepublic.co for existing offers & extended warranty.

In an event of any unforeseen circumstances, there is unavailability of certain spare parts, prevailing depreciation rules will be binding on the purchaser to accept as a commercial solution in lieu of repairs.

Helpline Number: +91-8826257630

Working Hours: Monday to Friday 10:00 AM- 5:30 PM (except national and public holidays)

Email: hello@alchemie.co



REPUBLIC