




BATMAN RGB LED GAMING MOUSE PAD

36 X 26CM

KAMSPDWBRMA

SAFETY & WARNINGS

Ensure to read all warnings and instructions in this user guide prior to first use.

- Do not submerge the connected cable into water or any other liquid.
- Do not stretch or pull on the mouse pad.
- Do not use the mouse pad under direct sunlight or near heat sources.

CLEANING & CARE

To clean the mouse pad, unplug the cable from the Micro-USB port and wipe it down with a damp cloth.

OVERVIEW



OPERATION

1. Connect the Micro-USB cable attached on the mouse pad into a Micro-USB port on your device. The mouse pad's RGB LED lights will light up to confirm it is connected.
2. Press the light button to cycle through the RGB LED light modes.
Hold the light button for 3 seconds to turn off the RGB LED lights.

Note:

When the mouse pad is reconnected, the RGB LED backlight will light up in the same mode as the last time the mouse pad was disconnected.

SPECIFICATIONS

Mouse pad size	36 x 26 x 0.3cm
Material	Waterproof fibre with anti-slip rubber
Voltage	5V
Current	100mA
Backlight modes available	14
Foldable	Yes
Waterproof	Yes
Cable length	1.8m



NOTES

[illegible]

Need more information?

We hope that this user guide has given you the assistance needed for a simple set-up.

For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com**

kogan.com