


2.12 Getting Started with Complete Air Management System

Pairing Air Conditioner and Ventilator.

How to pair your air conditioner and ventilator to link both units in a single location.



Living Room


Dining Room

Bedroom




Pairing the Air Conditioner and Ventilator.*

* Initial registration of each compatible model of air conditioner and ventilator is required.




STEP 1

Tap “+” icon to begin pairing devices.




STEP 2

Tap “Create a new pair”.



STEP 3

- Enter pairing name.
- Select air conditioner to pair.
- Select ventilation unit to pair.
- Tap “Create”.



STEP 4

When pairing is successful, tap “OK”.