




PBTNC50
Bluetooth Active Noise
Cancellation Headphone
USER MANUAL

CONTENTS


Bluetooth Connection	01~03
Basic Operation	04~05
Ports Description	06
Specifications	07
Simple Troubleshooting	08
Safety Notice	09

BLUETOOTH CONNECTION




Step1 Power on 
Press for 2 seconds until red and blue indicator flashes alternatively,
then enter the setting and switch on
the Bluetooth in cell phone

1



Step2 Choose the device
Find the PyleUSA from the Bluetooth
name list in the phone

2




Step3 Connection finish
If PyleUSA shows connected, the
blue indicator will flash which
means the connection successful
You can now start to play music.

3



BASIC OPERATION




1. Power/Multi-function button

- Short press for pause/play
- When a call is coming, short press to answer
- During call conversation, short press to hang off
- When a call is coming, double click to refuse the call

2. 3. Volume control buttons

- Short press 2 to turn up and long press to next track.
- Short press 3 to turn down and long press to previous track.
- Press and hold 2 & 3 together for 2 seconds to disconnect the current pairing (under Bluetooth connection mode).
- Press and hold 2 & 3 together for 5 seconds to default setting (under Bluetooth pairing mode).

4




Noise cancellation function

- Click 4 for NC on and indicator is green
- Click 4 for NC off and indicator is off

5

PORTS DESCRIPTION



Charging LED Indicators:

- During charging, red LED is ON
- When charging is finished, green LED is on
- When battery is low, red LED flashes slowly

6

PRODUCT SPECIFICATIONS

Product name	Bluetooth Active Noise Cancellation Headphone
Model	PBTNC50
Battery capacity	500mAh
Phone call talking time	NC ON: 15~18Hs
	NC OFF: 26 ~ 29Hs
Music play time	NC ON: 12 ~ 14Hs
	NC OFF: 18 ~ 23Hs
Charging time	2~3Hs
Battery Capacity	500mAh
Battery voltage	3.7V
Charging current	5V/400mAh
Dimensions	80 x 171.5 x 188mm
Weight	222g

7

SIMPLE TROUBLESHOOTING

When you meet below problems please refer to below instructions to solve, if the problems can't be solved please contact with the local distributors. Don't fix by yourself. Avoid electric shock or enlarge the trouble scope.

1. What if no sound from the headphone?
 - To check if it's connected and power on again.
 - To check if the Line in status.
2. What if the distortion happens when the volume is max.
 - Check if the audio cable is not loose and make sure it is connected properly.
 - Check if the audio cable is not loose and make sure it is connected

8

SAFETY NOTICE

PLEASE READ ALL INFORMATION AND FOLLOW INSTRUCTIONS CAREFULLY

Any sharp cutting edge, non-smooth surface, metal accessories and package will cause harm injury and bleeding, please be careful during use. Make sure to keep them out of reach of children.

Please don't modify, fix or disassemble this product. Inappropriate handle may cause short-circuit, damage or fire. We will not accept device for repair if disassembled by users.

Please don't clean the speaker's surface by detergent and any liquid, use only dry cloth. Inappropriate adjustment of the volume (such as frequent adjustment) will affect the sound quality or may cause damage. DO NOT drop, clash or crack or use on dangerous environment (such as lab) that may cause interference.

If anything abnormal happens please stop immediately. It may cause explosion under open fire and high temperature environment.

9