



Sprint Inseego MIFI 8000 Mobile Hotspot - Antenna Port Guide -



Secondary External Antenna Port

*When Using Dual Antennas or a MIMO Antenna, Connect an Antenna To Each Port.

Primary External Antenna Port

*When Using 1 Antenna Connect Antenna To This Port.

Warning: The Inseego MIFI 8000 has 2 external antenna port. For single antenna use, either port can be used. Use both ports for MIMO (Dual Antennas) use. Antenna ports can be fragile. Using excessive force when connecting or disconnecting your adapter cable can damaged the modem's internal antenna. To avoid damaging your modem - Be Gentle.





Sprint Inseego MIFI 8000 Mobile Hotspot - Antenna Port Guide -



Secondary External Antenna Port

*When Using Dual Antennas or a MIMO Antenna, Connect an Antenna To Each Port.

Primary External Antenna Port

*When Using 1 Antenna Connect Antenna To This Port.

Warning: The Inseego MIFI 8000 has 2 external antenna port. For single antenna use, either port can be used. Use both ports for MIMO (Dual Antennas) use. Antenna ports can be fragile. Using excessive force when connecting or disconnecting your adapter cable can damaged the modem's internal antenna. To avoid damaging your modem - Be Gentle.



Sprint Inseego MIFI 8000 Mobile WiFi Hotspot

Increase Speeds & Range: An external antenna can improve performance when in fringe areas. To attach an external antenna first flip open the antenna cover(s). The Inseego MIFI 8000 has two antenna ports for LTE MIMO capability. If you are only connecting a single antenna you should use Antenna Port - 2 For convenient placement you can attach the antenna(s) to your laptop screen.

Single Antenna Solutions 3G 4G LTE



3G / 4G LTE Antenna Solution




Antenna Port - 2

Dual Antenna Solutions MIMO 3G 4G LTE



4G MIMO LTE Antenna Solution



Antenna Port - 1

Antenna Port - 2

MIMO (Multiple In / Multiple Out)

Connect Dual Antennas to take full advantage of Hi-Speed MIMO 4G LTE Device capabilities



Sprint Inseego MIFI 8000 Mobile WiFi Hotspot

Increase Speeds & Range: An external antenna can improve performance when in fringe areas. To attach an external antenna first flip open the antenna cover(s). The Inseego MIFI 8000 has two antenna ports for LTE MIMO capability. If you are only connecting a single antenna you should use Antenna Port - 2 For convenient placement you can attach the antenna(s) to your laptop screen.




3G / 4G LTE Antenna Solution



Antenna Port - 2



4G MIMO LTE Antenna Solution



Antenna Port - 1

Antenna Port - 2

MIMO (Multiple In / Multiple Out)

Connect Dual Antennas to take full advantage of Hi-Speed MIMO 4G LTE Device capabilities

