


INSTRUCTION MANUAL

EAGLE PEAK 61" x 28' x 79" Greenhouse



Do not return your greenhouse to the place of purchase.
For warranty service, repair parts, or product questions
please contact Eagle Peak through the website and
we'll reply immediately.




Thank you for choosing Eagle Peak !




SET UP THE GREENHOUSE


- Assemble the metal frame as shown in the below diagram .
All the connectors are marked with letters that correspond to the letters in the assembly instructions.
NOTICE: Please make sure all the tubes are fitted together snugly with no gaps.
- Place the net racks on the shelves, and make sure they fit into place properly.

Part NO.	Part list	QTY	Part NO.	Part list	QTY
1		14	A		6
2		15	B		20
3		3	E		4
4		22	G		2
5		4	H		4
6		4	I		1
			J		4


Step 1




Step 2




Step 3




Step 4



Step 5




Step 6









- Unzip the zipper system on the cover completely. Locate the roof of the greenhouse and align it carefully over every corner of the frame to ensure a snug fit.



- Secure cover and frame using the ropes.



- Roll up the door and the curtains if desired.



SECURE THE CANOPY IN PLACE

- Tie four ropes to the corners of the top fabric. Using the ropes, measure out the distance from each leg that the rope needs to be staked down in order to have proper tension. Place four stakes in the ground at this distance away from each leg, and then tie the ropes to the stakes.
- Put stones on the overlong fabric to help weigh it down.

