

LY & S Information for Recliners

Use this information for any recliner cartons.

Instructions for removing recliner from carton

1 Tip carton on the floor

2 Open BOTTOM panels of carton

3 Remove / dispose of filler pad

4 Grasp bottom back rail of arms and pull / slide recliner from carton

5 Remove / dispose of package material

6 Holding the back, stand behind the recliner arms and slide the sleeve brackets on the back, over the hinge uprights of the arms



7 Press down firmly on top of the back to LOCK in place



8 Attach the loop and hook fastener strip on outback fabric to the corresponding strip on bottom back rail of arms

