

QUICK START GUIDE


SAMSUNG Galaxy Buds Pro

What's in the box


- Earbuds (L/R)
- Charging case
- Ear tips (S/M/L)
- USB cable (Plug sold separately)
- Quick Start Guide

Your device

Ear buds



Charging case



Charge your device

1. Insert the buds into the charging case.
2. Close the charging case and connect the USB cable.
3. The earbuds and the charging case are charged simultaneously

You can also charge the earbuds and charging case simultaneously using a wireless charger.

Use only Samsung-approved charging devices and accessories. Using other accessories may void your warranty and may cause damage.

Charging case indicators

- Green Battery fully charged or above 60%
- Yellow Battery between 30% and 60%
- Red Charging or battery below 30%
- ⚡ Flashing Red Charging disabled or error due to abnormal temperatures or battery below 10%

Download

Galaxy Wearable app

To connect your earbuds and smart-phone, install the **Galaxy Wearable** app.

Download the app on to a compatible smart-phone from the Galaxy Store, or Playstore. Use the app to view the connection status, and various setting options.

Printed in Korea
GH68-52968A



Connect


Connect to your Samsung device

Open the charging case to enter Bluetooth pairing mode.

Note: Press the left and right touchpads at the same time to manually enter Bluetooth pairing mode.


A pop-up window displays on your mobile device > tap **Connect** and follow the prompts.

You can download the Galaxy Wearable app only on mobile devices running Android operating system 7.0 (API 24), or later, and with 1.5 GB of RAM or more.



Wearing your device

Check the direction of each earbud and point the ear tips in the direction of the lower part of your ear.



Gestures



Single Tap

Music

Play/Pause

Double Tap

Music

Next song

Calls

Answer/End a call

Switch between calls

Triple Tap

Music

Previous song

Touch & Hold

Digital assistant

Launch Bixby or Google

Music

Launch supported music apps

Calls

Reject a call

Noise controls

Launch Active noise canceling or Ambient sound or turn them off

Volume

Adjust volume

Samsung Electronics America, Inc.

85 Challenger Road

Ridgefield Park, New Jersey 07660

Phone: 1-800-SAMSUNG (726-7864)

Internet: www.samsung.com

©2021 Samsung Electronics America, Inc.

Samsung, Samsung Galaxy, Samsung

Health, and Galaxy Wearable are all

trademarks of Samsung Electronics Co., Ltd.

Other marks are the property of their

respective owners.

Screen images are simulated. Appearance

of device may vary.