




Switch



- Switch system needs to be 3.0.0 or above for wired connection. Go to System Setting > Controller and Sensors > turn on Pro Controller Wired Communication
 - NFC scanning, IR camera, HD rumble, motion controls, notification LED are not supported, nor can the system be waken up
 - LED lights indicate the player number, 1 LED indicates player 1, 2 LEDs indicate player 2, 4 is the maximum number of players the controller supports
- 1 – connect the controller to your Switch dock via its USB cable
 - 2 – wait till the controller is successfully recognized by your Switch to play

Windows (X - input)



- required system: Windows 10 (1703) or above
 - LED lights indicate the player number, 1 LED indicates player 1, 2 LEDs indicate player 2, 4 is the maximum number of players the controller supports
- 1 – connect the controller to your Windows device via its USB cable
 - 2 – wait till the controller is successfully recognized by your Windows device to play

Turbo function



- 1 – hold the button you would like to set turbo functionality to and then press the **star** button to activate its turbo functionality
 - 2 – Home LED blinks continuously when the button with turbo functionality is pressed
 - 3 – Hold the button with turbo functionality then press **star** to deactivate its turbo functionality. Home LED stops blinking
- **D-pad joysticks, home, select and start** buttons are not included


Ultimate Software

- 8BitDo Ultimate Software gives you elite control over every piece of your controller: customize button mapping, adjust stick & trigger sensitivity, control vibration power and create macros with any button combination
- e.g. create macros and more with P1, P2
- please visit app.8bitdo.com for the application
- press **profile** switch button to switch between 3 custom profiles. The profile indicator will not light up when using the default setting

support



- please visit support.8bitdo.com for further information & additional support



Switch



- * 要求 Switch 主机系统版本为 3.0.0 或更高版本，在使用前，请确保“设置”-“手柄与感应器”-“Pro 手柄的有线连接”选项为“开启”状态。
- * 不支持 NFC 扫描、六轴体感、红外摄像头、HD 振动、通知灯、唤醒主机等功能。
- * 状态指示灯支持显示玩家数量显示，亮 1 号指示灯为第一个玩家，亮 1、2 号指示灯为第二个玩家，最多支持 4 个玩家显示。
- * 将 Pro 2 有线手柄连接至 Switch 主机的 USB 端口，等待系统识别后即可使用。

Windows (X - input)



- * 要求 Windows 设备系统版本为 Windows 10 (1703) 或更高版本。
- * 状态指示灯支持显示玩家数量显示，亮 1 号指示灯为第一个玩家，亮 1、2 号指示灯为第二个玩家，最多支持 4 个玩家显示。
- * 将 Pro 2 有线手柄连接至 Windows 设备任意 USB 端口，等待系统识别后即可使用。

Turbo 连发功能



1. 按住需要设置连发的功能键，再按下 [星号键] 可开启按键的连发功能。
 2. 按下启用连发功能的按键，[home] 指示灯会持续闪烁，提示此按键已启用连发功能。
 3. 按住需要关闭连发的功能键，再按下 [星号键] 可关闭按键的连发功能，[home] 指示灯停止闪烁。
- * [十字键]、[左 / 右摇杆]、[home]、[select]、[start] 键不支持设置连发。

自定义配置

- * 请访问 app.8bitdo.cn 获取精英软件使用，可对手柄按键映射、摇杆灵敏度、扳机键灵敏度、振动强度以及宏指令等功能进行自定义配置。
- * 如：P1, P2可设置宏指令等功能。
- * 配置后可按 [配置键] 切换自定义配置，若按下配置键时配置指示灯没有亮起，表示正在使用默认配置。

技术支持



- * 若要进一步了解此产品的更多功能，请前往 support.8bitdo.cn 了解详细信息。

