

# Charging Tips



## Step 1:

The fitness tracker requires no charging cable. Just pull out the strap which is below the home key, you will see the built-in USB plug with metal pins.



## Step 2:

Insert the metal pins into any USB socket/Wall charger. (Please ensure that the metal strips align with the USB strips.)



## Step 3:

After a gentle vibration, a battery icon will be shown on the screen when it is being charged successfully.



## Note:

If the watch does not vibrate after plugged in, please turn it over to charge again.