




VX GAMING



Critical Series Charging Stations and Battery Packs

INSTRUCTION MANUAL

Please use the provided diagrams as a reference on how to utilize the Critical Series Charging Stations and Battery Packs.

VX Gaming by:





volcano



HOW TO USE:

- Switch off your Xbox One® console.
- Connect the USB Type-A plug on the included cable into one of the USB ports on the console.
- Connect the Micro USB plug on the included cable into the port on the back of the Charging Station.
- Remove the battery compartment cover from the bottom of the original Xbox One® controller.
- Insert the included battery pack in the battery compartment of the controller.
- Turn your console on.

You can charge the battery pack while attached to the controller or separately. Just make sure to plug the connector coming out from the Charging Station in the port on the battery pack.



WARNING:

- Please read the user manual before use.
- Do not throw or drop the product or subject it to strong physical shock.
- Do not expose the product to liquids.
- Don't use or store the product in humid environment or under high temperature.
- Turn off the power when not in use.