


60cm Ceramic Cooktop




FEATURES

4 Cooking Zones, Side Knob Controls,
9 Power Levels, Residual Heat Indicators,
Durable Ceramic Glass

Congratulations on your new InAlto 60cm Ceramic Cooktop!

YOUR COOKTOP



Legend:

1. Zone A Max. 1200 W zone
2. Zone B Max. 1800 W zone
3. Zone C Max. 1200 W zone
4. Zone D Max. 1800 W zone
5. Glass plate
6. Control Panel

USING YOUR COOKTOP

To start cooking

- Place a suitable pan on the cooking zone that you wish to use. Make sure the bottom of the pan and the surface of the cooking zone are clean and dry.
- Turn the knob control clockwise to set your desired cooking level from 1-9. You can modify the heat setting at any time during cooking.

To finish cooking

- Turn the cooking zone off by turning the knob counter-clockwise to the "OFF" position. After a zone is switched off, the residual heat indicator of the corresponding zone will be lit. The residual heat also can be used as an energy saving function if you want to heat further pans, use the hotplate that is still hot.

Note: For further operation instructions refer to pages 10–11 of your user manual.

DETAILS

Dimensions (W, D, H mm): 590 × 520 × 55
Built-in Dimensions (W, D mm): 560 × 490
Warranty: 3 Years (2 + 1 on registration)

SUPPORT

Telephone: 1300 11 4357
Email: support@residentiagroup.com.au