

Set 2 Light Up Angel Stake Lights

K897 v001: 06/05/22

Please read and retain these instructions for future reference

GAINSBOROUGH
Garden & Wildlife



Dimensions

(H) 72x (W) 18x (D) 4cm
100 cm lead to battery box


- TIMER FUNCTION – 6 HOURS ON 18 HOURS OFF.
- IP44 RATED AND WATERPROOF BATTERY BOX
- WARM WHITE LEDS (not replaceable)
- ANTIQUE FINISH MOON STAKES HAVE A GOLD CENTRE WITH CUT OUT STARS WHICH REFLECTS STAR SHAPES ONTO WALLS ETC OUTDOORS. HEAVENLY ANGELS PERCH ON THE EDGE OF THE MOON CLOSE TO A HANGING FAUX CRYSTAL. CAN BE USED TO LINE PATHS OR PLACE INTO PLANT POTS AND AT NIGHT THEY WILL CREATE A MAGICAL DISPLAY.

Batteries required: 3x AA (not included)

**ALWAYS USE ALKALINE BATTERIES.
DO NOT USE LITHIUM BATTERIES.**

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS FOR USE:

Unpack the components carefully. Please check all parts have been removed from the packaging.



**The Enterprise
Department**

UK Head Office, 11 Bridge Street, Bishop's Stortford, CM23 2JU

Tel: 0844 4824400*, Fax: 01279 756595

www.coopersofstortford.co.uk

EU address: D.S.B. LD, 160 Bd. de Fourmies, 59100 Roubaix, France

Tel: (+44) 1279 701269

*UK Calls cost around 7 pence per minute plus your telephone company's network access.
Please check with your telephone supplier.

Set 2 Light Up Angel Stake Lights k897 Instructions for Use

Please read and retain these instructions for future reference

v001: 06/05/22

WARNING!

- THE LIGHT SOURCES ARE NOT REPLACEABLE.
- DO NOT CONNECT THE CHAIN TO POWER SUPPLY WHILE IT IS STILL IN PACKAGING.
- FOR INDOOR AND OUTDOOR USE
- DO NOT INTERCONNECT WITH ANOTHER LIGHT FITTING.
- DO NOT INTERFERE WITH THE WIRING.

Inserting and replacing the batteries



Set 2 Light Up Angel Stake Lights k897 Instructions for Use

Please read and retain these instructions for future reference

v001: 06/05/22



Battery Box:

Three-stage push button functions:

1 x PUSH = TIMER – the product lights up in repeated cycles daily for 6 hours, then turns off for 18 hours

2 x PUSH = ON – constantly on

3 x PUSH = OFF – constantly off

- **ONLY ADULTS MAY CHANGE THE BATTERIES!**
- **MAKE SURE TO INSERT THE BATTERIES WITH THE CORRECT POLARITY!**
- **REPLACE THE BATTERY COMPARTMENT COVER AFTER CHANGING THE BATTERIES!**

CARE AND CLEANING INSTRUCTIONS:

- Always switch off and remove batteries when not in use.
- Do not shine light directly towards eyes.
- Do NOT immerse in water.
- Do NOT use abrasive cleaners or sharp utensils to clean the lights.
- Store the item in a cool, dry place.
- Wipe with a clean dry cloth.

BATTERIES

- Keep batteries away from children and pets.
- Do not mix used and new batteries.
- Remove the batteries if left for long periods.
- Never dispose of batteries in a fire.
- Battery disposal, spent or expired batteries must be properly disposed of and recycled in compliance with local regulations. For detailed information, contact your local authority.
- Follow the battery manufacturer's safety, usage, and disposal instructions.

DISPOSAL

- Coopers of Stortford use recyclable or recycled packaging where possible.
- Please dispose of all packaging, paper, cartons, packaging in accordance with your local recycling regulations.
- Plastics, polybags – this is made from the following recyclable plastic.



Set 2 Light Up Angel Stake Lights K897 Instructions for Use

Please read and retain these instructions for future reference

v001: 06/05/22

Code & Symbol	 LDPE
Type of Plastic	PE
Commonly used for	Electronic, ceramic, artcrafts, domestic appliances, glass items' protection.

- At the end of the product's lifespan please check with your local council authorised household waste recycling centre for disposal.



*Calls cost 7 pence per minute plus your telephone company's network access charge

The Enterprise Department
Head Office: 11 Bridge Street
Bishop's Stortford, CM23 2JU
Tel: 0844 482 4400*
Fax: 01279 756 595
www.coopersofstortford.co.uk

