


Quick Start Guide

Premium Essential Oil Diffuser



FOR A BETTER LIFE



ASAKUKI
あさのくうき

Accessories

This manual book applies to all same model diffusers with different colors.



Pure White



White Wood



Light Wood



Cherry Wood



Dark Wood



Diffuser * 1



User Guide *1



Remote Control * 1



AC Power Adapter *1



Measuring Cup *1



Notice:

The remote control and AC power cord are included in the water tank.

Using Steps



Connect
the power

Add

water and essential oil in the tank



Press "LIGHT" to adjust LED light

Press "MIST" to turn on/off the diffuser and set timers

Press "HIGH/LOW" to adjust the mist density

Use the remote to control the diffuser

Remote Control Guide

ON/OFF

One press: Turn on the mist and set at continuous misting mode.

Two press: Turn off the mist and light.

Intermittent

When the diffuser is turned on, press to set to intermittent mist mode.

It will mist for 10 seconds and stop 10 seconds and cycle.

(Intermittent mist mode can only be set by remote control)

Continuous

When the diffuser is turned on, press to set to continuous mist mode.

Timing

When the diffuser is turned on:

One press: Set at 60 minutes mist mode.

Second press: Set at 120 minutes mist mode.

Third press: Set at 180 minutes mist mode.

Big/Small

Press to adjust the mist density, one beep sound for strong mist, two beep sound for weak mist.

Light

One press: Turn on the light and 7 color cycles.

Next presses will fix each color at dim or bright mode and turn off the light.



ON/OFF



Inter-
mittent



Timing



Con-
tinuous



Big/small



Light

TECHNOLOGY FOR LIFE
MADE IN CHINA

Button Control Guide



LIGHT Button

After power is connected, press the 'LIGHT' button once to turn on the light. The LED light color will cycle from dim to bright gradually.

Continue pressing will fix the color at a bright or dim status.



MIST Button

Press the 'MIST' button once to turn on the mist and it will be set at continuous misting mode. Continue pressing to set mist time at 60 minutes / 120 minutes / 180 minutes and turn off.

Long press about 3 seconds to turn off both mist and light.



HIGH/LOW button:

Press to adjust the mist output amount.

One beep for strong mist and two beeps for weak mist.

Maintenance & Notice

Clean & Maintenance

Please clean the diffuser per week as follows:

- Unplug the diffuser and pour out the remaining water from 'DRAIN SIDE'.
- Add 2-3 drops of vinegar to 100ML warm water (up to 70 °C).
- Leave diffuser for 5 minutes and gently shake and pour out water.
- Wipe the diffuser with a dry soft cloth.
- If the diffuser will not be used for a long time, please keep it clean and dry.

Notice

- When filling water, do not exceed the max line marked on water tank.
- Please power off diffuser first before adding water.
- Diffuser will beep two times and turn off automatically when water used up.
- Please use pure natural essential oils.
- If the diffuser is leaking for any reason, please unplug the unit and pour out remaining water. Shake diffuser gently to drain water inside, then dry for more than 24 hours.

Troubleshooting

Please refer to the table below in the event of the product operating abnormally

Will not switch on/off	• Is there enough water in the tank? Please add water to the tank. • Is the power cord connected properly? Please disconnect, check cables and reconnect carefully.
No mist or abnormal mist	• Not enough water or too much water? Please add suitable amount of water in the tank, water must never be filled over max line. • Dirt on the ultrasonic plate? Please refer the maintenance instructions remove and re-install correctly. • Dirt or dust in the air intake on the underside of the base? There is a fan on the underside of the base that is required to blow the mist out. If it gets clogged with dust or dirt, it will prevent mist from coming out.
Water leakage from product	• Cover not set on the base properly? Remove the cover and set it back on the base right above the buttons. • Low temperature or high humidity? Under these conditions, the mist may condense quickly into water droplets.



72h Clean the water tank every 3 days

- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Do not permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the oil diffuser down. If the oil diffuser output volume cannot be turned down, use the oil diffuser intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
- Unplug the appliance during filling and cleaning.
- Never leave water in the reservoir when the appliance is not in use.
- Empty and clean the oil diffuser before storage. Clean the oil diffuser before next use.



Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.

4 DIY Essential Oil Blends



Lavender

+



Orange

Good Night Sleep



Clove

+



Grapefruit

Goodbye Mold



Basil

+



Geranium

+



Orange

Brain Booster



Geranium

+



Lavender

+



Oregano

Anti Allergy

Specifications

Dimensions	(W)168 x (H)125MM
Weight(Excluding Adapter)	Approx 634g
Power:Input/Output	AC100-240V 50/60Hz DC24V 500mA
Length Of Cord	Approx 180CM
Electric Consumption	Approx 12W
Time Mode	ON/60min/120min/180min
Tank Capacity	500ml
LED Colors	7 Bright, 7 Dim
Materials	Upper parts PP,lower base ABS
Accessories	AC adapter, measuring cup and remote
Method of Mist Production	Ultrasonic vibration at approx 2.4MHz



ASAKUKI Be With You Any Time!

Dear valuable customer,

Thanks for choosing ASAKUKI.

ASAKUKI originated from Japan, we focus on designed and creative household items for a better life. The word 'ASAKUKI' comes from the Japanese pronunciation (朝の空気 – あさのくうき 'air in the morning') whose products relate to healthy family life.

Utilizing our experience and success in the industry, ASAKUKI has created a customized and unique project management team, designed to fulfill our customers' requirements with the highest quality household items based on innovation, excellence, and comfort, using the latest technology.

Together with a 100% satisfaction guarantee, we want to let you know that if you need any assistance, please feel free to contact our customer support team by simply email us via Amazon message.

We guarantee a positive solution within 24 hours.

Wish a better and happier life!

Best Regards

ASAKUKI



Brand: ASAKUKI

Product Name: Oil Diffuser

Model Number: 100-DF001

Manufacture: Chongqing ChuangHong DianZi ShangWu YouXian Gongsi

Address: CN, 401120, chongqing, chongqing, bei bu xin qu, 1 zhuang 11-3,
jin kai da dao 1228 hao, bei bu xin qu

UK	REP
----	-----

UK Responsible Person: APEX CE SPECIALISTS LIMITED

Address: 89 Princess Street, Manchester, M1 4HT, UK

Contact: Wells

Tel: +441616371080

E-mail: info@apex-ce.com

Made In China







Made in China

