

# Wio Helium Monitor Test Guide

## Installation:

- 1) Update the Wireless Core Firmware on the WioTerminal following the Seeed documentation : <https://wiki.seeedstudio.com/Wio-Terminal-Network-Overview/>
- 2) Drag & Drop the Wio Helium Monitor firmware on the Wio Terminal. The firmware can be downloaded here :  
<https://github.com/disk91/WioHeliumMonitor/blob/master/bin/WioHeliumMonitor.ino.uf2>

## Vérification:

- 1 ) After the firmware download or power it on
- 2 ) The Wio Terminal will boot and display the following screen (the screen is a bit different now : there is a QR code displayed on it).



- 3 ) Check the available WiFi networks and make sure you see WioHeliumMonitor network listed. Do not connect or anything else, this verification is good enough.

