

A detailed line drawing of the Sony WH-1000XM3 headphones. The image shows the over-ear design with a curved headband and two large, padded ear cups. The ear cups are connected to the headband via a hinge mechanism. The drawing is a technical illustration, showing the structure of the headphones without shading or color.

1



This diagram shows the front cover assembly in an exploded view. The components are numbered as follows:

- 1: Front cover (main body)
- 2: Front cover gasket
- 3: Front cover screw
- 4: Front cover screw
- 5: Front cover screw
- 6: Front cover screw
- 7: Front cover screw
- 8: Front cover screw

3

Volume up	Click the "+" to increase volume
Volume down	Click the "-" to decrease volume
Next song	Press and hold the "+" around 2 seconds
Previous song	Press and hold the "-" around 2 seconds

Answer call	Click the call button when call is coming
End call	Click the call button when call is over
Reject call	Press and hold the call button around 2 seconds when call is coming
Redial	Double click the call button to redial last call number

Type	Feature	Description or Details
BT	Version	5 .1
	Paring name	EMBT-01
	Operated distance	10M
	Transmission range	2402 -2480MHz
Speaker	Diameter	Ø40±0. 05mm
	Frequency Response	50HZ-5KHZ At15mW
	Impedance	32Ω±15%
	Sensitivity/S.P.L.	121 ± 3dB(At 1000Hz)
	Rated Power	10mW
Battery	Type	Rechargeable lithium battery
	Capacity	600mAh

CE  

Any Changes or m

6

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.