

# Asus RT-N56U Fibre Setup

Using your own router? No worries, we've got you covered!

## Log into the gateway:

1. Ensure your device is connected to the Router (preferably via cable)
2. Open a web browser
3. Type the following in the address bar at the top: 192.168.1.1
4. Default Username: admin
5. Default Password: admin

This should then give access to the router's user interface

## How to add correct settings for the Mercury network:

From the left menu select: Advanced Settings

Click: WAN

The Internet Connection page displays. Ensure the following settings are changed:

1. WAN Connection Type: PPPoE
2. Enable UPnP: Yes
3. Enable PPPoE Relay: No
4. Get the WAN IP automatically: Yes
5. Connect to DNS Server automatically: Yes
6. PPP Username: (your mercury acct number)@mercurybroadband.co.nz
7. Password: password
8. MTU: 1492
9. MRU: 1492
10. Service Name: Leave blank
11. Access Concentrator Name: Leave blank
12. Additional pppd options: Leave blank
13. Select ISP: Manual
14. Internet: VID - 10, PRIO - 0
15. The rest can remain unchanged
16. Click: Apply.

