

WaterWatcher Leak Detector

HydroCheck

Overview:
The WaterWatcher is designed to detect water leaks. When a leak is detected, the WaterWatcher will sound an alarm and turn off the appliance that is causing the leak by de-energizing its output. The LED indicator on the front of the control module is green when the output is energized and red when it is de-energized. Once the WaterWatcher is triggered, it will stay triggered until it is reset using the Smart Button.

Step-by-Step Installation:

Step 1:	Plug the WaterWatcher control module into a 120 VAC outlet.
Step 2:	Plug the appliance into the WaterWatcher control module.
Step 3:	Place sensor in optimal location to detect potential sources of leaks. Sensor should be placed with probes facing down and label side up.

Product Specifications:

Power:	120 VAC, 60 Hz
Output Rating:	120 VAC, 13.8 Amp, 3/4 HP
Alarm Rating:	80 dB
Cable Length:	12ft
Function:	Output is de-energized in alarm condition



Smart Button Features

Mute Alarm	Press and release the Smart Button while the alarm is active. The alarm will remain muted until the switch has been reset.
Switch Reset	Press and release the Smart Button when the sensor is dry.

Warranty:
STAK Enterprises Inc. warrants the **WaterWatcher** to be free from defects in materials and workmanship under normal use and service for a period of five years from the date of purchase. STAK Enterprises Inc. makes no other express or implied warranty for this device. No agent, representative, dealer, or employee of STAK Enterprises Inc. has the authority to increase or alter the obligations or limitations of the warranty. The company's obligation of this warranty shall be limited to the repair or replacement of any part of the WaterWatcher which is found to be defective in materials or workmanship under normal use and service during the five year period commencing with the date of purchase. During the initial 90-day period commencing with the date of purchase, such repair or replacement shall be made without charge. During the remaining period of the warranty, such repair or replacement shall be made at a charge to the customer not to exceed the manufacturer's cost.

THE DURATION OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSES, SHALL BE LIMITED TO THE PERIOD OF ONE YEAR COMMENCING WITH THE DATE OF PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.