

TA298 indoor and outdoor temperature hygrometer manual

Uses: This product is suitable for, factories, warehouses, building air conditioning management, hospitals, aquaculture species, room, office, hotel, laboratory.... Modern energy saving good helper.

The machine can be hung on the wall or on the table, on the back there is a hook and bracket

Measuring range: outdoor -40C~70(-40~158F)

degree of error: 0.1c(0.1c)

Indoor 0C-50(32F~122°F)

Humidity 10%~99%± 5% Resolution 1%

Function Test: Press MAX/MIN key once to display the previous maximum/minimum indoor and outdoor temperature and humidity values

When the MAX/MIN press the RESET button once to clear a previously memorized maximum or minimum Remeasure

When the MAX/MIN 8 seconds after the display returns to the current temperature and humidity display C/F key

Celsius and Fahrenheit Conversion

Time Debugging:

1 In the initial state, press and hold [MODE] for 2 seconds, the number of minutes the current time starts flashing, press the [ADJ] to adjust the hours, minutes. In normal time display mode, press the [ADJ] can be converted to 12/24 show.

2 In the current clock mode (clock and minutes between two blink once per second), press [MODE] once, switch the display to alarm mode (clock and minutes between two points is not flashing), press live [MODE] for 2 seconds, the alarm time flashes, press the [ADJ] can adjust the alarm time, minute. Alarm mode is displayed, press [ADJ] to set/cancel the alarm alarm function. After setting press the [MODE] returns to normal time display.

This product uses 1.5v AAA batteries External 1.5 m water temperature sensors

*Fonts appear blurred, replace the battery.



中文

TA298 室内外温湿度计手册

用途：本产品适用于工厂、仓库、

楼宇空调管理、医院、水产养殖物种，房间，办公室，酒店，实验室…现代能源拯救好帮手。

机器可以挂在墙上或桌子上，后面是一个钩子和托架

测量范围：室外-40C~70(-40~158F)

错误程度： 0.1c (0.1c)

Indoor0C-50 (32F~122) “F)

湿度 10%~99%± 5%分辨率 1%

功能测试：按 MAX/MIN 键一次显示

室内外先前最高/最小值

温度和湿度值

当 MAX/MIN 按一次 RESET 按钮以清除

预先记忆的最大或最小量测

当显示后的 MAX/MIN 8 秒返回到

当前温湿度显示 C/F 键

摄氏和华氏温度转换

时间调试：

1 在初始状态下，按住[模式]2 秒，

当前时间开始闪烁的分钟数，按

调整小时、分钟的[ADJ]。在正常时间显示

模式下，按 [ADJ] 可以转换成 12/24 显示。

2 在当前时钟模式下（时钟和分钟之间）

每秒闪烁两次)，按[模式]一次，切换

显示到报警模式（时钟和两点之间的分钟数）

未闪烁)，按动[模式]2 秒，告警

时间闪烁，按 [ADJ]可以调整报警时间，分钟。

显示告警模式，按[ADJ]设置/取消警报

设置后按 [模式] 回到正常状态。

时间显示。

本产品使用 1.5v AAA 电池 External 1.5 m 水

温度传感器

字体看起来模糊了，替换电池。

