

Before Starting:



1. **ADD OIL** (included) Oil has been drained for shipping. You **MUST** add oil before starting. Failure to do so will permanently damage your machine.



2. **ADD FRESH GAS** If your machine has sat idle for more than 2 months, you should drain your gasoline tank and fill it only with fresh, new gas.



3. **PLUG IN** the female end (a) of an extension cord into the receptacle outlet* on your machine, and the male end (b) into a wall socket.

* Plug receptacle is next to red start button
Remove the cover to see the prongs -->



- 1 **Fuel On**
Open the Fuel Valve
(Turn dial to ON)




- 2 **Close Choke**
Move Choke dial
to CLOSED position



- 3 **Throttle Up**
Move the throttle to fast
(Turn dial to FAST)



- 4 **Prime It**
If engine is COLD, press &
release Primer Bulb 2-3 times



- 5 **Key In**
Insert Ignition Key



- 7 **Open Choke**
Return Choke dial to OPEN
after engine is warm (~15-20s)



- 6 **Press Start**
Press the Start Button and hold
in until engine starts, then release



26" Two-Stage Snow Blower: YB6770
28" Two-Stage Snow Blower: YB7285

QUICK-START INSTRUCTIONS

Follow these instructions to get your snow blower running quickly and correctly!

YARDMAX

Tame the Great Outdoors®