

Wearing



KÜLKUF

1

SLIDE ON KÜLKUF AND ALIGN THE COOLING PLATE WITH THE INTERIOR SIDE OF YOUR WRIST



2

TIGHTEN STRAP UNTIL COMFORTABLY SNUG AROUND THE WRIST



3

TURN ON



Operating



KÜLKUF

1

ACTIVATE KÜLKUF BY DEPRESSING SWITCH FOR 2 SECONDS.

2

KÜLKUF HAS THREE ADJUSTABLE TEMPERATURE LEVELS.

3

TO CHANGE THE LEVEL, PRESS AND RELEASE THE SWITCH ONCE.

ONCE ACTIVATED, KÜLKUF WILL AUTOMATICALLY TURN OFF IN 5 MINUTES UNLESS MANUALLY TURNED OFF BY THE USER.

BLUE LIGHT/HIGH ~ 8 °C/47 °F

The initial activation will result in a "blue light," the coldest temperature.

MAGENTA LIGHT/MEDIUM ~ 16 °C/60 °F

A second depression of the switch will result in a "magenta light," the medium temperature.

RED LIGHT/LOW ~ 25 °C/77 °F

A third depression of the switch will result in a "red light," the warmest temperature.

NO LIGHT - OFF

A 2-second depression of the switch at any time will turn off the light, indicating "power off."

Note: Once KÜLKUF is turned off, it may temporarily feel slightly warm, which is normal and is the result of the discharge of stored heat from the heat sink.

Technical Specifications



KÜLKUF

BATTERY ~	Rechargeable lithium polymer 3.7V 1500mAh
CHARGER ~	US pin type, Input: 100-240V~,0.5A 50/60HZ Output : 4.2V DC 1A
PRODUCT WEIGHT ~	94 gm / 3.31 oz
TEMPERATURE RANGE ~	8°C to 25°C / 47°F to 77°F
SYSTEM RUN TIME ~	1 hour 45 minutes Lowest Temperature Level 1 hour 20 minutes Medium Temperature Level 1 hour Highest Temperature Level
BATTERY CHARGING TIME ~	2 hours

Battery & Charging



RED LIGHT

Battery is charging



GREEN LIGHT

Battery is charged

USER MANUAL



KÜLKUF

Hot Flash Cooling Cuff



Safety Precautions



IMPORTANT SAFETY INSTRUCTIONS

- Do not use KÜLKUF on the skin where topical ointments or sprays have been applied.
- Do not use over an open wound.
- Operate with care.
- KÜLKUF was not intended for or tested on individuals below the age of 18.
- Never operate KÜLKUF with damaged cables or connectors, following mechanical damage, or if the unit is not fully operational.
- Do not disassemble, make alterations, crush, strike, or puncture. Failure to comply with this requirement may adversely affect the product performance, thereby voiding the warranty and any product liability.
- Do not use KÜLKUF while smoking or near flames.
- Do not incinerate.
- Use KÜLKUF only as directed.

ONLY USE THE CHARGER PROVIDED WITH KÜLKUF. FAILURE TO DO SO MAY RESULT IN FIRE CAUSING BOTH PROPERTY DAMAGE AND PERSONAL INJURY. UNAUTHORIZED PART SUBSTITUTION IS STRICTLY PROHIBITED.

NOTE: KÜLKUF is not intended to be used as a replacement for therapy or treatment of medical diseases or medical conditions. We recommend anyone with concerns to consult their doctor prior to use.

- The battery cannot be removed.
- If at any time you notice a foul odor or swelling of KÜLKUF, discontinue charging and do not use. Contact customer service.
- Do not overcharge the KÜLKUF. Once fully charged, always remove the battery charger from the electrical power socket and disconnect the charging pin from the KÜLKUF.
- Except for cleaning with a damp cloth, keep KÜLKUF clean and dry. Do not immerse KÜLKUF in water as this will void the warranty.
- Do not short circuit the external contacts on KÜLKUF or the battery charger.
- Do not disassemble KÜLKUF for any reason, as such action will void the warranty.
- DO NOT cover or otherwise obstruct the flow of air from the exhaust fan (mesh area) with clothing, bed covers or any other material that could reduce air flow as this will result in overheating and possible damage to KÜLKUF.
- While using the KÜLKUF if the exhaust fan stops functioning or if you feel overheating, immediately remove the KÜLKUF from the wrist and turn it off. Contact customer service.



KÜLKUF MAY NOT BE DISPOSED OF WITH YOUR HOUSEHOLD WASTE. TO LEARN WHERE TO DROP OFF YOUR ELECTRONIC WASTE, PLEASE CONTACT YOUR LOCAL CITY/MUNICIPAL WASTE DISPOSAL SERVICE OFFICE.

Cleaning



CLEANING INSTRUCTIONS

- To clean your KÜLKUF, use a soft cloth or brush to remove any lint from the surface. If wet cleaning is needed, wipe the main body of KÜLKUF with a damp cloth.
- When sanitizing, you can use disinfectant wipes or sprays. You can also place a small amount of sanitizer onto a clean cloth to wipe the main body of KÜLKUF.
- For more Information visit www.kulkuf.com
- Do not put KÜLKUF or any of its parts or accessories into a washing machine or dryer.
- Do not use abrasive materials to clean KÜLKUF; doing so will void your warranty and any product liability.

Box Contents



KÜLKUF HOT FLASH COOLING CUFF



USER MANUAL



WALL CHARGER

Maintenance & Storage



MAINTENANCE

Apart from cleaning instructions, the user should not perform product maintenance. Tampering with this device will void the product warranty, and any product liability. If your KÜLKUF requires maintenance, please contact customer service.

STORAGE

- Unplug the charger from KÜLKUF prior to storage.
- Store KÜLKUF in a cool, dry location.
- Remember that your KÜLKUF is a valuable piece of equipment and should be treated with great care.

Warranty Information

- One year warranty against factory defects.
- 60-day battery warranty.
- Contact customer service for further details at: 833 585 5837.