




Fold 'n Go™
Baby Travel Pod



15 lbs MAX.
6.8 kg MÁX.

KEEP FOR FUTURE REFERENCE

Adult assembly required.



 IMPORTANT SAFEGUARDS	
Important Safeguards.....	3
 INCLUDED PARTS	
Included Parts.....	4
 HOW TO USE	
Directions to Open.....	5
Directions to Close.....	6
How to Clean.....	7
Important Note.....	7
 CUSTOMER SERVICE	
Contact Us	7



IMPORTANT SAFEGUARDS

WARNING: FALL HAZARD


To help prevent falls, do not use this product when the infant begins to push up on hands and knees or has reached 15 lbs. (6.8 kg.), whichever comes first.

WARNING: **SUFFOCATION HAZARD** **INFANTS HAVE SUFFOCATED:**


- In gaps between extra padding and side of the cradle, and on soft bedding.
- Use only the pad provided by manufacturer.
- If a sheet is used with pad, use only the one provided by the manufacturer or one specially designed to fit the dimension of the pad.
- Prevent possible strangulation or entanglement, never use sheet unless it fits securely on pad.
- Strings can cause strangulation! Do not place items with string around a child's neck, such as hood strings or pacifier cords. Do not suspend strings over the pad or attach strings to toys.



INCLUDED PARTS




- A** End Support / hinge
- B** Side Button / hinge
- C** Lock Indicator Arrows
- D** Metal Support Tubes




DIRECTIONS TO OPEN

1. Unfasten closure strap. **(fig. 1)**




2. Open Travel Pod until lock indicator arrows are aligned on both side hinges and an audible click is heard from each side hinge. **(fig. 2)**




3. Straighten end supports until lock indicator arrows are aligned on both end support hinges and an audible click is heard from each end support hinge. **(fig. 3)**

The Travel Pod is now fully open and locked. Attach pad to Travel Pod with hook and loop fasteners facing down. Make sure pad is centered.




DIRECTIONS TO CLOSE

1. **NOTE:** There is no need to remove the pad prior to folding. Simultaneously press buttons on both side hinges (**fig. 1**)




2. Fold Travel Pod until metal support tubes touch. (**fig. 2**)



3. Press button on each end support hinge and continue to fold Travel Pod until flat. (**fig. 3**)

Fasten closure strap.



HOW TO CLEAN

NOTE: The pad is removable and includes a machine washable fitted sheet. When replacing pad, be sure that hook and loop fasteners are facing down and pad is horizontally and vertically centered.

Fitted Sheet: Machine washable. Remove pad first, then remove fitted sheet. Machine wash warm, no bleach. Tumble dry on low heat.

Pad: Surface washable only. Clean with warm water and a mild soap solution. Air dry mattress pad.

IMPORTANT NOTE

Caregivers should discontinue using all Travel Pods when a baby begins to push up on their hands and knees. This developmental characteristic varies from child to child but typically occurs at approximately 3 to 4 months of age or when the child is approximately 15-20 lbs. MUNCHKIN, Inc. recommends that you discontinue use of the Fold 'n' Go™ Travel Pod at 3 months, 15 lbs or when your baby begins to push up on their hands and knees – whichever comes first.

CONTACT US

If you have any questions or wish to provide comments about this product, feel free to contact our Customer Satisfaction team at **1-800-344-2229** (M-TH 8:00am-5:00pm PST, F 8:00am-1:00pm PST) or visit our website at **www.munchkin.com**.





munchkin.com 
800.344.2229 

© 2022 MUNCHKIN, INC. 7835 GLORIA AVE., VAN NUYS, CA 91406. MUNCHKIN BABY CANADA LTD., 3-8460 MOUNT PLEASANT WAY, MILTON, ON L9T 8W7. MADE IN CHINA . WWW.MUNCHKIN.COM/PATENTS.

