



CARE AND USE GUIDE

VACUUM INSULATED STAINLESS STEEL COFFEE CUP INSULATOR

GENERAL CARE


- Before first use, and as soon as possible after each use, wash all parts with warm, soapy water. Rinse all parts thoroughly and allow time to dry.
- Contents should not be left in the container for longer than 24 hours. As soon as possible after each and every use, wash all parts with warm, soapy water. Rinse all parts thoroughly with clean water. Allow all parts to dry completely prior to next use or storage
- DO NOT use abrasive cleaners or scrubbers since they may dull the finish.
- DO NOT use bleach or cleaners containing chlorine on any parts of the product.
- This product is top-rack dishwasher safe; however, hand washing is recommended as the dishwasher uses harsher detergents and hot water that may affect the appearance of your product.
- Residual liquids, foods, or other contents may become trapped between product components, such as lid parts, container parts, gaskets (flexible band around lid and/or stopper), or straws (if present in the product). Although this product is top-rack dishwasher safe, hand washing is recommended to ensure that all parts of the product are thoroughly cleaned.

ASSEMBLY & USE

Cup Insulator:

1. Remove any and all objects placed inside the insulator (B).
2. Remove silicone sleeve (A) by gripping the upper lip of the silicone sleeve (A) and pulling upward until removed from insulator (B).
3. Wash all parts separately, then re-assemble.
 - a. Ensure silicone sleeve (A) is properly seated to avoid cup slippage.
4. Insert your 16 or 20 ounce beverage cup into the insulator (B). Ensure the beverage cup is securely inserted to maximize the cup's insulation.
 - a. If present, ensure your beverage cup's lid is fastened securely to your beverage cup before drinking.
5. To drink, grab the insulator (B) firmly.
 - a. Do not hold the product by the gourmet beverage cup or the silicone sleeve (A) as the cup could slip out of the insulator (B) and burn or scald user.





WARNINGS

- DO NOT use product in microwave, on stove top, or in any type of oven.
- NOT RECOMMENDED FOR USE BY CHILDREN: Keep out of the reach of children, especially when product contains hot contents, which may burn or scald user.
- Always test temperature of contents before consuming.
- DO NOT overfill the container: Leave space at top of container to avoid overflow. Hot contents may burn or scald user if overflow occurs.
- In general, contents should not be left in the container for longer than 24 hours. However, the rate at which contents spoil depends on several factors. Certain contents that include, for example, dairy and/or tomato may start to spoil sooner. Proceed with caution when using the product with quick spoiling contents.

LIMITED WARRANTY

Thermos L.L.C. warrants this Genuine Thermos Brand product to be free from defects in material or workmanship for five years from date of purchase. This warranty does not cover ordinary wear and tear or color fading, or any condition affected by abuse, neglect, alteration, accident or improper use or maintenance.

We will, at our option, repair or replace any product component part that fails to conform to this warranty within 30 days after its receipt by our factory service department.

IN NO EVENT WILL THERMOS BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES.

Some jurisdictions do not allow the exclusion of incidental, consequential or special damages, so the preceding exclusion may not apply to you.

This is a factory guarantee.

Please do not return this product to the retailer.

Send defective unit or component along with written explanation of defect directly to:



Thermos L.L.C. - Warranty Service
355 Thermos Road
Batesville, MS 38606, USA
1-800-831-9242
www.thermos.com

In Canada:
1-800-669-7065
www.thermosbrand.ca

This warranty gives you specific legal rights and you may also have other rights, which vary from state to state or province to province.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REPRESENTATIONS OR CONDITIONS OF QUALITY AND PERFORMANCE, WHETHER WRITTEN, ORAL OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SUCH IMPLIED WARRANTIES, REPRESENTATIONS AND CONDITIONS ARE HEREBY DISCLAIMED. THE REMEDIES STATED HEREIN CONSTITUTE PURCHASER'S EXCLUSIVE REMEDIES AND THERMOS'S ENTIRE LIABILITY FOR ANY BREACH OF WARRANTY.

© 2016 Thermos L.L.C. All rights reserved.
THERMOS is a registered trademark in over 115 countries.

