

AS OF
MAY
2022

This quick reference guide to cooking accessories will help to make sure you have what you need for a successful installation in just 3 easy steps.

Step 1 Find your model number in this guide. Model numbers that contain an underscore (_) are available in multiple colors. For example, LTG4715_ comes in both Stainless Steel (LTG4715ST) and Black Steel (LTG4715BD). LSGS6338F does not have the underscore as it only comes in Stainless Steel. Be sure to confirm availability and ordering of your color choice.

Step 2 Read the information on required and optional accessories to determine your needs and prepare yourself by knowing the answers to the following questions.

- ☐ Gas or electric appliance?
- ☐ If purchasing a gas range or cooktop, is your home natural gas (NG) or liquid propane (LP)?
- ☐ Do you have the required electrical supply and an adequately sized circuit breaker?
- ☐ If installing an over-the-range microwave or hood, have you planned for venting?

Step 3 Identify the items you need to purchase for your cooking appliance. Items with a check box need to be purchased separately.

Where to Buy?

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button.*

Optional Accessories

Purchase by clicking the LG parts & accessories button* or call 1-800-243-0000.

LG Parts & Accessories

Contents

Slide-In Ranges 2-3

Freestanding Ranges 4-5

Over-the Range Microwaves 6

Hoods 7

Wall Ovens 8

Cooktops 9-10





ACCESSORY GUIDE: GAS SLIDE-IN RANGES

What Accessories Do I Need to Purchase for My LG Gas or Dual Fuel Slide-In Range?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Electrical Requirements LG Gas Slide-in Ranges have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.	
	Installation Parts Required for Gas Hookup	
	Anti-Tip Bracket An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	Additional parts needed when installing on concrete floor.	
	LP Conversion Kit If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.	
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Rear Filler If the counter does not bridge the opening at the rear wall, the rear filler kit that is provided with the slide-in range, will be needed.	
	Side Filler Kit (2 pieces) Prevents spills or food residue from sliding in-between the range and countertop. The kit is installed with adhesive, no mounting brackets or screws needed.	
	Broiler Pan and Grid	
	Air Fry Rack	

STEP 1: FIND YOUR MODEL NUMBER

LSDS6338F, LSGS6338F, LTG4715_(ST, BD), LSDL6336_(F, D), LSG6337_(F, D), LSGL6335_(F, D), LSGL5833_(F, D), LSGL5831F



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit
☐ Gas Line Shut-Off Valve ☐ Joint Sealant ☐ Flexible Metal Appliance Connector (3/4" or 1/2" NPT x 1/2" I.D.) ☐ Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 1/2" I.D.) ☐ Flare Union Adapter for Connection to Pressure Regulator on Range (1/2" NPT x 1/2" I.D.)
Anti-Tip Bracket Included and Must be Installed
☐ Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
LP Conversion Kit Included
Rear Filler Included
☐ LSFL301S Side Filler Kit
☐ Broiler Pan – Part Number Coming Soon ☐ Grid Pan – Part Number Coming Soon
☐ Air Fry Rack - LRAL302S (For use with models with Air Fry feature: LSGL6337_, LSGL6335_; these models include an Air Fry Tray / Basket that sits on an existing oven rack, the Air Fry Rack is a standalone rack accessory)

SS / F – PrintProof™ Stainless Steel ST / S – Stainless Steel D – PrintProof™ Black Stainless Steel BD – Black Stainless Steel



What Accessories Do I Need to Purchase for My LG Electric Slide-In Range?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION			STEP 1: FIND YOUR MODEL NUMBER
Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000.			LSI3018SS, LSES6338F, LSE4617ST, LSE4616_(ST, BD), LTE4815ST, LSEL6337_(F, D), LSEL6335_(F, D), LSEL6333_(F, D), LSEL6331F
Electrical Requirements LG Electric Slide-in Ranges require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a 40 or 50 Amp circuit breaker. A 4-wire range power cord or a 4-wire conduit connection may be used. Refer to * below if you have a 3-Prong outlet.			
Anti-Tip Bracket An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.			☐ 4-Prong Range Power Cord or a 4-Wire Conduit Connection (Refer to * below if you have a 3-Prong outlet)
Additional parts needed when installing on concrete floor.			☐ Strain Relief (for Conduit Installations Only)
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000.			Anti-Tip Bracket Included and Must be Installed
Side Filler Kit (2 pieces) Prevents spills or food residue from sliding in-between the range and countertop. The kit is installed with adhesive, no mounting brackets or screws needed.			☐ Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
Broiler Pan and Grid			Rear Filler Included
Air Fry Rack			☐ LSFL301S Side Filler Kit
			☐ Broiler Pan – Part Number Coming Soon
			☐ Grid Pan – Part Number Coming Soon
			☐ Air Fry Rack - LRAL302S (For use with models with Air Fry feature: LSEL6337_, LSEL6335_, LSEL6333_; these models include an Air Fry Tray / Basket that sits on an existing oven rack, the Air Fry Rack is a standalone rack accessory)

*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong range power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong range power cord. LG recommends a 4-wire connection or a 4-prong range power cord.

☒ SS / F – PrintProof™ Stainless Steel
 ☐ ST / S – Stainless Steel
 ☒ D – PrintProof™ Black Stainless Steel
 ☐ BD – Black Stainless Steel

What Accessories Do I Need to Purchase for My LG Gas Freestanding Range?

- ☐ Items in RED with a check box require you to make a purchase
- ☐ Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button [†] or call 1-800-243-0000. LG Parts & Accessories	Electrical Requirements LG Gas Freestanding Ranges have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.	
	Installation Parts Required for Gas Hookup	
	Anti-Tip Bracket An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	Additional parts needed when installing on concrete floor.	
	LP Conversion Kit If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.	
Optional Accessories Purchase by clicking the LG parts & accessories button [†] or call 1-800-243-0000. LG Parts & Accessories	Broiler Pan and Grid	
	Air Fry Rack	

STEP 1: FIND YOUR MODEL NUMBER

LDG4313ST, LRGL5825_(F, D), LRGL5823_(S, D), LRGL5821_(S, D)



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit
☐ Gas Line Shut-Off Valve ☐ Joint Sealant ☐ Flexible Metal Appliance Connector (3/4" or 1/2" NPT x 1/2" I.D.) ☐ Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 1/2" I.D.) ☐ Flare Union Adapter for Connection to Pressure Regulator on Range (1/2" NPT x 1/2" I.D.)
Anti-Tip Bracket Included and Must be Installed
☐ Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)
LP Conversion Kit Included
☐ Broiler Pan – Part Number Coming Soon
☐ Grid Pan – Part Number Coming Soon
☐ Air Fry Rack - LRAL302S (For use with models with Air Fry feature: LRGL5825_, LRGL5823_)

SS / F – PrintProof™ Stainless Steel
 ST / S – Stainless Steel
 D – PrintProof™ Black Stainless Steel
 BD – Black Stainless Steel

What Accessories Do I Need to Purchase for My LG Electric Freestanding Range?

- ☐ Items in RED with a check box require you to make a purchase
- ☐ Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Electrical Requirements LG Electric Freestanding Ranges require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a 40 or 50 Amp circuit breaker. A 4-wire range power cord or a 4-wire conduit connection may be used. Refer to * below if you have a 3-Prong outlet.	
	Anti-Tip Bracket An anti-tip bracket is included and must be installed. Do not operate the range without the anti-tip bracket in place.	
	Additional parts needed when installing on concrete floor.	
Optional Accessories Purchase by clicking the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Broiler Pan and Grid	
	Air Fry Rack	

STEP 1: FIND YOUR MODEL NUMBER

LDE4413ST, LREL6325_(F, D), LREL6323_(S, D), LREL6321_(S, D)



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

☐ 4-Prong Range Power Cord or a 4-Wire Conduit Connection (Refer to * below if you have a 3-Prong outlet)

☐ Strain Relief (for Conduit Installations Only)

Anti-Tip Bracket Included and Must be Installed

☐ Lag Bolt or 1/2" O.D. Sleeve Anchor (Concrete Floors Only)

☐ Broiler Pan – Part Number Coming Soon

☐ Grid Pan – Part Number Coming Soon

☐ Air Fry Rack - LRAL302S
(For use with models with Air Fry feature: LREL6325_, LREL6323_)

*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. For these installations, purchase a 4-prong range power cord. If your home was built before 1996 and has only a 3-wire connection, purchase a 3-prong range power cord. LG recommends a 4-wire connection or a 4-prong range power cord.

☐ SS / F – PrintProof™ Stainless Steel
 ☐ ST / S – Stainless Steel
 ☐ D – PrintProof™ Black Stainless Steel
 ☐ BD – Black Stainless Steel



ACCESSORY GUIDE: OVER-THE-RANGE MICROWAVES

What Accessories Do I Need to Purchase for My LG Over-the-Range Microwave?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button[†] or call 1-800-243-0000.

LG Parts & Accessories

Electrical Requirements

LG OTRs have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker is required.



Venting Requirements

LG OTRs must be properly vented in one of three ways. Do not vent into a wall cavity, attic or unused area. Venting ductwork is not provided and should be purchased separately.

1. Roof venting with 3" 1/4 x 10" duct or 6" round duct
2. Wall venting with 3" 1/4 x 10" duct or 6" round duct
3. Room venting (recirculating)

Installation Parts You May Need for Outside Venting

Roof Venting



Wall Venting




Optional Accessories

Purchase by clicking the LG parts & accessories button[†] or call 1-800-243-0000.

LG Parts & Accessories

Replacement Charcoal Filter

LG OTRs include 1 charcoal filter for room venting installations (recirculating). It is recommended to change the filter every 6-12 months. Order an extra filter now to keep on-hand.




STEP 1: FIND YOUR MODEL NUMBER

LSMC3086SS, LMVH1711ST, LMHM2237_(ST, BD), LMH2235ST, LMVM2033ST, LMV2031_(SS, ST, BD, SB, SW), LMV1831_(SS, ST, BD), LMV1764ST



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit



☐ Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 140 feet.)

☐ Roof Cap

☐ Duct Tape to seal all joints

☐ Caulking to seal the exterior roof opening around the cap

☐ Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 140 feet.)

☐ Wall Cap

☐ Duct Tape to seal all joints

☐ Caulking to seal the exterior wall opening around the cap

☐ Replacement Charcoal Filter – Part Number Coming Soon

■ SS – PrintProof™ Stainless Steel ■ ST – Stainless Steel ■ BD – PrintProof™ Black Stainless Steel ■ SB – Smooth Black ■ SW – Smooth White

What Accessories Do I Need to Purchase for My LG Hood?

- ☐ Items in RED with a check box require you to make a purchase
- ☐ Items in BLACK with a check box are optional
- Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION		STEP 1: FIND YOUR MODEL NUMBER	
		LSHD3680ST, HCED3615_(S, D), LSHD3080ST, HCED3015_(S, D)	
STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER			
Required Accessories Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button† or call 1-800-243-0000. LG Parts & Accessories	Electrical Requirements LG Hoods require a 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker. These Hoods must be hard wired (direct wired) into an approved junction box. A plug and receptacle is not permitted on these products.	☐ 3-Wire Circuit Connection (2-Wire with Ground)	
	A cable locking connector (not supplied) might also be required by local codes. Check with local requirements and codes, and purchase and install appropriate connector if necessary.	☐ Cable Locking Connector	
	Venting Requirements LG hoods must be properly vented in one of three ways. Do not vent into a wall cavity, attic or unused area. Venting ductwork is not provided and should be purchased separately. Use metal ductwork only. For best performance, use round ducts (6" min.) instead of rectangular, especially when elbows are required. 1. Roof Venting 2. Wall Venting 3. Room Venting (recirculating)	☐ Duct Work (The total length of the duct system, including straight duct, elbows, transitions, and wall or roof caps must not exceed 100 equivalent feet.) ☐ Roof or Wall Cap ☐ Duct Tape to seal all joints ☐ Caulking to seal the exterior roof opening around the cap	
Optional Accessories Purchase by clicking the Zephyr button. Zephyr Store	Telescopic Duct Covers	1 Upper and 1 Lower Duct Cover Included LG hoods are designed for a max. ceiling height of 9 ft. 10 in. A duct cover extension is required for taller ceilings.	
	Recirculation Kit & Replacement Charcoal Filter A recirculation kit is required when venting into a room instead of outside. It is recommended to change the charcoal filter every 6-12 months. Order an extra filter now to keep on-hand.	☐ Recirculation Kit – ZRC-01AN ☐ Replacement Charcoal Filter – Z0F-C091	
	Duct Cover Extension Can be used for ceiling heights that are between 9 ft. 10 in. and 12 ft.	☐ 12 ft. Duct Cover Extension for ceiling heights up to 12 ft. – Z1C-00AN	

☒ SS / F – PrintProof™ Stainless Steel
 ☐ ST / S – Stainless Steel
 ☒ D – PrintProof™ Black Stainless Steel
 ☐ BD – Black Stainless Steel

What Accessories Do I Need to Purchase for My LG Wall Oven or Speed Oven?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 1: FIND YOUR MODEL NUMBER			
Single	Double	Combination	Speed Oven
WSES4728F, LWS3063_(ST, BD)	WDES9428F, LWD3063_(ST, BD)	WCES6428F, LWC3063_(ST, BD)	MZBZ1715_(S,D)
 	 	 	
STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER			
☐ 30 Amp Circuit Breaker with Min. #10 AWG	☐ 40 Amp Circuit Breaker with Min. #8 AWG	☐ 50 Amp Circuit Breaker with Min. #8 AWG	3-Prong Power Cord Attached to Unit
☐ 4-Wire Circuit Connection (Refer to * below for 3-wire connection)	☐ 4-Wire Circuit Connection (Refer to * below for 3-wire connection)	☐ 4-Wire Circuit Connection (Refer to * below for 3-wire connection)	☐ 20 Amp Circuit Breaker
☐ Junction Box			Not Applicable
☐ Conduit Connector			Not Applicable
☐ Wire Nuts for 10 Gauge Wiring	☐ Wire Nuts for 8 Gauge Wiring		Not Applicable
☐ 36" of String			Not Applicable
☐ Wood Shims			Not Applicable
Trim Kit Included on LG STUDIO models only (WSES4728F, WDES9428F, WCES6428F)			Not Applicable

*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. A 3-wire connection is possible where local code permits.

☒ SS / F – PrintProof™ Stainless Steel
 ☐ ST / S – Stainless Steel
 ☒ D – PrintProof™ Black Stainless Steel
 ☐ BD – Black Stainless Steel

What Accessories Do I Need to Purchase for My LG Gas Cooktop?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION

Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button[†] or call 1-800-243-0000.


[LG Parts & Accessories](#)

Electrical Requirements

LG Gas Cooktops have a 3-prong power cord attached to the unit. A 120 V, 60 Hz, properly grounded dedicated circuit protected by a 15 or 20 Amp circuit breaker, or slow blow fuse is required.



Installation Parts Required for Gas Hookup



LP Conversion Kit

If your home uses Liquid Propane (LP) instead of Natural Gas (NG), utilize the LP Conversion Kit.



STEP 1: FIND YOUR MODEL NUMBER

LSCG367ST, LCG3611_(ST, BD), LSCG307ST, LCG3011_(ST, BD)



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

3-Prong Power Cord Attached to Unit

- ☐ Gas Line Shut-Off Valve
- ☐ Teflon Tape or a Thread Compound
- ☐ Pipe Fittings
- ☐ Joint Sealant
- ☐ Flexible Metal Appliance Connector (5/8" I.D.)
- ☐ Flare Union Adapter for Connection to Gas Supply Line (3/4" or 1/2" NPT x 5/8" I.D.)
- ☐ Flare Union Adapter for Connection to Pressure Regulator on Cooktop (1/4" NPT x 1/2" I.D.)

LP Conversion Kit Included

☐ ST – Stainless Steel ☒ BD – PrintProof™ Black Stainless Steel



ACCESSORY GUIDE: 36-INCH AND 30-INCH ELECTRIC COOKTOPS

What Accessories Do I Need to Purchase for My LG Electric Cooktop?

☐ Items in RED with a check box require you to make a purchase

☐ Items in BLACK with a check box are optional

Items in BLACK without a box are included with purchase.

STEP 2: READ THIS INFORMATION



Required Accessories

Purchase from dealer links, in-store with unit purchase, or if part is available, click the LG parts & accessories button[†] or call 1-800-243-0000.

[LG Parts & Accessories](#)

Electrical Requirements

LG Electric Cooktops require a 240/208 V, 60 Hz, properly grounded dedicated circuit protected by a properly sized Amp circuit breaker as noted. A 4-wire conduit connection or power cord should be used.*



STEP 1: FIND YOUR MODEL NUMBER

36-INCH

CBIS3618B, LSCE365ST, LCE3610SB



30-INCH

LSCE305ST, LCE3010SB



STEP 3: IDENTIFY THE ITEMS YOU NEED TO PURCHASE FOR YOUR MODEL NUMBER

☐ 50 Amp Circuit Breaker with Min. #8 AWG

☐ 4-Wire Circuit Connection
(Refer to * below for 3-wire connection)

☐ 40 Amp Circuit Breaker with Min. #8 AWG

☐ 4-Wire Circuit Connection
(Refer to * below for 3-wire connection)

☐ Strain Relief

☐ Junction Box

☐ Wire Nuts for 8 Gauge Wiring

*A 4-wire connection is required for all mobile and manufactured home installations, as well as all new construction after January 1, 1996. A 3-wire connection is possible where local code permits.

ST – Smooth Black Glass w/Stainless Trim B / SB – Smooth Black Glass