



LED FLOOR LAMP

user manual



FCCERoHS

English




UNITS: cm

1

English

Step 1




Part A 1 pcs

Part B 1 pcs

2

English

Step 2




Part A 1 pcs

3

English

Step 3




Part A 1 pcs

Part B 1 pcs

4

English


Step 4



5

English

Step 5



6

English

LED floor lamp user manual

Thank you for your choice. Please read the user manual carefully and keep it for future reference.

Correct installation is required, please follow the instructions step by step. After installation, this LED floor lamp can be controlled by remote control or touch-sensitive button on the lamp.

Specification

Model	FLD-024-F2-C58-K1-ee-fff
Wattage	24W
Dimension	ø25×175cm
Input Voltage	100-240V AC, 50/60Hz
Color Temperature	2700K-6500K
Max Luminous Flus	2000 lm
Beam Angle	120 deg
Protection Rating	Remote control
Controlled By	remote control/Touch
Color	2700K-6500K White
Material	Plastic; Cast iron hardware

7

English

Before Assembly

1. Inspect lamp before beginning assembly. Wire connections have been made at the factory and the lamp is ready for assembly.

2. Remove all packing materials from the lamp.

3. To prevent bad connections, avoid pulling wiring connections when removing contents from package or during installation.

4. Lay out all the parts on a flat surface.

5. The floor lamp consists of seven parts: 1×Lamp Head, 4×Pole, 1×Lamp Base, 1×Remote control, 1×Electric Wire with Adapter (Refer to illustration).

Assembly Instruction

1. Place the lamp base on flat surface, then screw each two parts dock-wise in order.

- Please take care not to pinch or damage the wires.
- For better installation, please tighten the bottom pole and lamp base firstly.
- Make sure each section of tubes are tightened.


2. Plug adapter into outlet and now the lamp is ready for use.

Adjustment

For best performance, please adjust the lamp position to directly above your area of reading/working.

8


English



units: cm

9

English



180° up/ down adjustable

350° rotate adjustable

JP US EU UK


10

English

Remote control code matching

Long press ON/OFF on the remote control and turn on the light, the light flashes, indicating Code the remote control and light

Remote controller instruction



ON/OFF

Color Mode

Brightness adjustment

Night light

Color Mode

Brightness adjustment

11

English

Order Button Number	Function
ON/OFF	Press to ON/OFF
NightLight	NightLight Mode
Color Mode	Brightness invariant, Short press to display 4 colors. From Warm color to Cool color in turn. Long press color from Warm to Cool in 0%-100%.
Color Mode	Brightness invariant, Short press to display 4 colors. From Cool color to Warm color in turn. Long press color from Cool to Warm in 0%-100%.
Brightness adjustment	Color invariant, Short press to display 10 Brightness. From 10% to 100%. Long press Brightness from 10% to 100% brightness in 0%-100%.
Brightness adjustment	Color invariant, Short press to display 10 Brightness. From 100% to 10%. Long press Brightness from 10% to 100% brightness in 0%-100%.

12

English

Key Function

Power button

Short touch: Power ON OFF

Color button

	Function
Short press	Brightness invariant, Short press to display 4 colors. From Warm color to Cool color in turn loop.
long press	Brightness invariant, Long press color from Warm to Cool in 0%-100%, call off and Long press again color from Cool to Warm in 0%-100%.

Brightness button


	Function
Short press	Color invariant, Short press to display 4 Brightness in turn loop.
long press	Color invariant, Long press Brightness from 10% to 100% brightness in 0%-100%, call off and Long press again from 100% to 10% brightness in 0%-100%.

13

English

Tips

1. If you want to cancel the pairing with the lamp, the Tun off-on-off-on-off-on lamp flashes when the lamp is working, and the pairing is cleared successfully



off-on-off-on-off-on

2. There is a magnet on the back of the remote control, which can be adsorbed on any iron metal surface such as floor lamp pole

14

English

WARNING:

- Cut off the power before installation.
- Keep it away from flammables and fire source.
- Replacing and clean to avoid electricity touched.
- Lamp is operated in dimming circuit
- Keep it away from water.
- Assemble the lamp according to the instructions and do not rebuild.
- Do not stare at the lamp for a long time.
- Assemble, take apart or move the lamp gently.
- Please do not cover anything on the lamp head and avoid bending and bumping the lamp pole.
- Keep it away from children.

15

