


# XTRARM

## XTRARM tripod Ayta wood / black with felt tray






XTR-FS2110

**VESA**  
200×200/300×200  
300×300/400×200  
400×300/400×400  
600×400


**32" —65"**  
TV Size

**Load**  
≤40KG


Read the entire instruction manual before you start installation and assembly.  
If you have any questions regarding any of the instructions or warnings,  
Please contact your local distributor for assistance.




### Step 1




### Step 2







### Step 3




### Step 4a




Step 4b




5mm




10mm




15mm




20mm




25mm



30mm




35mm





40mm

Step 5




Step 6


Note: Do not knock the screen against the tripod.





Step 7






Notice:  
Avoid knock the screen against  
the tripod





Step 8a



Attach the TV to the fixing device (11) with cable (9) for avoiding topple over.



Step 8b



Step 9

