

INALSA

**MIXER
GRINDER**

Philia
Inara

✿

**Instruction Manual
Cum
Warranty Card**

✿

Dear Customer,

Congratulations! On the purchase of your **INALSA Mixer Grinder**, this is designed to include many superior features that permit you the fullest expression of your juicing skill and enthusiasm. You are now on the threshold of a whole new world of juicing pleasure.

At INALSA, we have a reputation of manufacturing innovative, high quality appliances such as Food Processors, Mixer Grinders, Mixer Grinders, Cooking Ranges, Juice Extractors, Cooktops, Microwave Ovens, Oven Toaster Grillers, Hand Blenders, Electric Kettles, Rice Cookers, and Electric Chimneys. Your newly acquired **INALSA Mixer Grinder** bears the same distinctive hallmark of excellence.

It is all the result of vigorous quality consciousness in INALSA's design and development where uncompromising standards are maintained and rigid quality control measures are exercised on raw materials, components and finally, the finished product.


Your **INALSA Mixer Grinder** has a lot of thoughtful features built in to make your **juicing** convenient. Please read these instructions carefully, so that you may get the best out of the power packed features in your

INALSA Mixer Grinder.

Welcome to the INALSA world of Mixing & Grinding pleasure!!



Parts Identification



1. Liquidizer jar dome

2. S S Liquidizer jar

3. Top body

4. Main body

5. Rotary switch knob

6. Body base
7. Bottom pads

8. Jar Handle

9. SS Chutney jar

10. SS Dry grinder jar

11. D G Jar lid

12. Chutney jar lid
13. Blender jar lid

14. Blender jar

15. Fruit Filter

16. Spatula
- Not Available in Inara 3 Jars Model

Technical Specification*

Model	Philia	Inara (4 Jars)	Inara (3 Jars)
Voltage	240V, 50Hz, AC		
Wattage	780W		
Motor/Insulation	Universal / Class "B" insulation		
Rating	30 Minutes continues at full load		
Cord plug	3-pin, 6A, 250V with PVC cord		
Speed control	3 Speeds with pulse		
Motor RPM	18,000 at full speed (At no load)		
Material Housing	ABS		
Material of Jars	PC & SS		SS
Overload Protector	Re-setting type		
Blender Jar	PC / 1.5 L		No
Liquidizer Jar	SS / 1.2 L	SS / 1.5 L	
DG Jar	SS / 0.8 L		
Chutney Jar	SS / 0.4 L		

*Due to continuous improvements in product, specifications are subject to change without prior notice.



Important Instructions

1. Please note that initial empty running of jars will throw out some oil impregnated in bushes. Therefore, it is advisable to thoroughly clean it before actual use.
2. Blending / liquidizing operation should be done at first speed only. In case a higher speed is used then chances are that the lid may fly off.
3. Turmeric grinding should be done in dry grinding jar (SS). For this break the turmeric into small pieces before grinding.

Do's

- Thoroughly familiarize yourself with the functions of the mixer grinder before operation.
- Before connecting the appliance check the mains voltage comply with the voltage specified.
- Place your mixer grinder at a convenient height so that you can operate it easily. You should be able to look down into the attachments to check the circulation of the ingredients.
- Clear out some space around the machine and keep mixer grinder away from direct heat and sun.
- In dry grinding, friction may heat up the jar. It has nothing to do with the motor, so don't worry.
- Remember Mixer grinder operates at optimum efficiency at the specified voltage only. Wide voltage fluctuations during operation might affect quality of grinding even though motor will still be safe.
- Hold down the lids lightly with hand while mixer is in operation.
- Operate in short cycles depending on the recipes.
- Always clean the jars so that sticky substances or particles do not restrict the blade movement.

Don'ts

- The mixer grinder should not be run for more than 3 minutes at a stretch normally. Turn off the switch and let it rest for at least two minutes to cool down the motor.
- Do not run the motor without any load.
- Your Mixer grinder cannot substitute for a storage shelf. So avoid storing food in the jar.
- Do not operate grinder without the lid properly clamped over the jar.
- Do not touch the moving parts and blades in operation. These revolve at extremely high speeds and may cause injury.
- Do not grind sugar in your mixer grinder it may cause damage to the mixer grinder motor. Do not overload the motor.
- Never lay a thin plastic sheet or cloth under the basic unit. It may get sucked up and block the ventilation holes in the base.
- Do not allow the cord to hang over the edges of the table, or touch hot surface.
- Do not immerse the appliance in water.
- Keep the appliance away from the children.
- Do not attempt to repair the Mixer grinder at home or allow any unauthorized person to do it either. In the event of your Mixer grinder needing attention, take it to your dealer or call him for help.



Before First Use

- After unpacking the unit and before any use, make sure the mechanical parts of the unit and all its attachments are not damaged.
- **Some parts of the jars are lubricated with oil, so it is advised to wash the jars of the appliance thoroughly with soapy water before first use.**
- Carefully go through the instruction manual before starting the grinding operation.

How to fit jars

Hold the jar and check if the blade moves freely and rotates. Place the ingredients in the jar. Cover the jar with lid. Place the jar on the basic unit and then turn it clockwise to lock it in the top socket. Plug in. support lid gently by hand and switch on using the slowest speed and then move on to higher speeds as per requirements. Switch off after operation. For unlocking the jar, turn it anticlockwise.

How to Use Blender Jar (Not Available in Inara 3 Jars Model)

- This jar can be used to extract juice from soft fruits and vegetables.
- Put soft fruits / vegetables inside the fruits filter. (Fruits filter mesh should be properly fitted inside the blender jar).
- Fit the lid on the top of the jar and fit the jar onto the main unit.
- Turn ON the unit.
- Soft pulpy juice shall flow out the mesh into the blender jar.
- Pour out the juice without opening the lid and fruit filter mesh to avoid the skin / seeds / pulp from mixing with the juice.

NOTE :

- Recommended fruits for juicing in fruit filter are watermelon, grapes, sweet lime, oranges and tomato etc.
- Always ensure proper locking of the lid.
- Initially use pulse function for better result.
- **Do not use this jar for wet grinding.**

How to Use Liquidizer Jar

- This jar can be used for grinding items like soaked rice and dal batter grinding, liquidizing for fruit juices, soups, cocktails, milk shakes, purees etc. the minimum capacity is 1/3 of the jar and maximum capacity is 1/2 of the jar.
- Fill the jar with the solids to be liquidized such as tomatoes. Fit the jar on to the main unit.
- Place the lid on the jar.
- If needed more water can be added. Now switch on the mixer for one minute and you will get finally blended juices and purees.
- If ingredients need to be stirred during wet grinding of rice and dal batter, stop mixer, insert spatula and stir.



How to Use Dry Grinder Jar

- This jar can be used for grinding black pepper, roasted coffee seeds, turmeric, coriander, red chillies etc. The jar should not be filled more than $\frac{1}{2}$ of the total capacity.
- Ensure that the jar is absolutely clean and dry.
- Fill the jar with the ingredients. Place the lid on the top of the jar and fit the jar on the main unit.
- Grind at low speeds for about 15 seconds and then move to higher speeds.
- During turmeric grinding first break it into smaller pieces before starting grinding.

How to Use Chutney Jar

- This jar can be used to grind small quantities of Dhania, coconut, green chillies, etc. and chutney grinding. The jar must be filled up to the blade level. The jar should not be filled more than $\frac{1}{2}$ of the jar capacity.
- Put the ingredients into the chutney jar.
- Add a small quantity of water during chutney grinding.
- Put the lid on the top of the jar and fit the jar into the main unit.
- Stir the ingredients if necessary during grinding.
- The ingredients to be ground should not be too large. Cut/ break ingredients into small pieces.

Overload Protector

- The Mixer Grinder is protected against the sudden overloads. In case such a situation occurs, then your mixer grinder will automatically turn off.
- To restart the unit, please wait for 2-3 minutes to allow the motor to cool down and also remove the cause of overload. Press the button located at the bottom of the mixer grinder to restart the unit.

Practical Advice

- **Hold down the lids lightly with hand while mixer is in operation to eliminate chances of lid flying.**
- Long runs heat up the contents and take away the flavour.

Cleaning and Maintenance

How to Clean the Jar

- Pour a little soap and water into the jar, close the lid and run it on the main unit at 1st position. This dislodges the food particles lodged inside the jar.
- Remove the jar and pour out the soap solution and rinse with tap water.
- Wipe the area along the blades with a wet cloth and then dry.
- Wipe the body with a wet cloth & then dry.



WARRANTY

The **"INALSA" Mixer Grinder** is fully warranted against any manufacturing defect for a period of **2 years** from the date of purchase. Should any defect develop in the **Mixer Grinder** during the warranty period, TUAREG MARKETING PVT. LTD. undertakes to get the **Mixer Grinder** or any part thereof, repaired at any of its Authorised Service Center.

The above warranty shall be subject to the following terms and conditions:-

1. Any defective product or part thereof will be repaired within the above stated warranty period on receipt of the same with this card duly filled in and stamped by dealer from whom the product was purchased along with the purchase bill/ invoice, provided the product is brought to our nearest service center freight paid and packed securely.
2. In the event of repairs/ replacement of any part of product, this warranty will thereafter continue and remain in force only for the unexpired period of warranty.
3. This warranty is valid only when:-
 - The product is purchased from the company's authorized dealer and accompanied by this warranty card/ cash memo.
 - The product has been serviced by the INALSA'S authorized service personnel.
 - The product has been used and maintained in accordance with the instruction manual.
4. The warranty does not apply to :-
 - Normal wear and tear of the product
 - Damage due to chipping, peeling, plating and denting.
 - Damages arising due to running of the appliances on the alternate sources of power such as Inverter, generator or any such auxiliary power supply aid resulting in variation/ fluctuating voltage
 - Breakage or damage to components made of ABS, SAN, Bakelite, Glass and such plastic/rubber parts, cord, bulbs and surface coating.
 - Damages resulting from accidents, mishandling or negligence on the part of the customer
 - Product if used for the commercial purposes.
 - Product, the serial number of which has been removed obliterated or altered on the specification plate.
5. The warranty is in lieu of all other warranty, expressed or implied and does not cover indirect or consequential damages/ loss.



WARRANTY CARD

Product : **MIXER GRINDER**

Model : **PHILIA / INARA**

Serial No

Date of purchase.....

Bill/ Cash Memo no.....

Purchaser' name.....

Address.....

.....

.....

Dealer's stamp and Signature



Customer Care Number (Timing: 9:30 to 5:30) (Mon - Sat)

9773982065

INALSA

TUAREG MARKETING PVT. LTD.

154, Bhalswa, Delhi- 110033

