

Warranty Information

Warranty Against Defects: Laser Corporation Pty Ltd ("Laser") warrants your new product to be free from defects in materials and workmanship for 24 months, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. The benefit of this warranty is in addition to your rights under the Australian Consumer Law and to other rights and remedies of the consumer under a law in relation to the goods or services to which the warranty relates. Through a network of retailers and resellers, Laser will provide you with your choice of a repair, exchange (where possible) or refund (within Dead on Arrival period) for this product if it becomes defective within the warranty period.

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CAUTION: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE. DO NOT PLACE ANY OBJECTS FILLED WITH LIQUIDS, SUCH AS DRINKS, ON THIS APPARATUS.

Exposure to Radio Frequency Energy

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

For body worn operation, this product has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of (specified distance) from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This product has been tested and complies with this exposure limit. Please refer to the physical device for applicable FCC ID. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

COPYRIGHT INFORMATION

©2019. All rights reserved. This document may not in whole or in part be reproduced, stored in a retrieval system, transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, or reduced to any electronic medium or machine-readable form without prior consent, in writing, from snakebyte uk Ltd.

Pebble Gear™ is a registered trademark of snakebyte uk Ltd. All trademarks are the properties of their respective owners.



WEEE (Waste Electrical and Electronic Equipment Directive)
If you eventually want to dispose of this product at a later time, please observe the following instructions: Electronic equipment should not be disposed of together with household waste. Please recycle the device if the appropriate recycling ways are available to you. Please contact your local authority or retailer and ask them for advice on recycling.

The crossed-out trash can symbol on your product means that this product is an electrical and electronic device for which special disposal regulations apply.

To enforce recycling, to dispose of WEEE in accordance with the Waste Electrical and Electronic Equipment (WEEE) Regulation and to protect the environment and health, European regulations require the selective collection of WEEE in one of two ways:

- Your retailer will gladly take your device back if you buy a new one from him.
- Old devices can also be disposed of in designated collection points.

RoHS
This product has been certified as RoHS compliant in accordance with Directive 2011/65/EG.

Restricted Use of Electronic Devices

The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with your airline company before travelling. The tablet has an Airplane Mode. Please go into the Settings of the Android Interface to switch the tablet into Airplane Mode. All wireless connections will be turned off.



Guideline for Headphone and Earphone

To prevent possible hearing damage, do not listen at high volume levels, permanent hearing loss may occur if earphones or headphones are used, it is best to avoid high volume levels when using earphones or headphones for extended periods of time. Ensure that the volume level on the tablet is set to its minimum level before connecting a headset.



EU Declaration of Conformity

Hereby we guarantee that snakebyte uk Ltd., 59 High Street, Newport, Shropshire, TF10 7AU, UK, is marketing this device under the name Pebble Gear™ Tablet and complies with the legal requirements and the requirements for Directive 2014/53/EU. This notification is listed under:

www.pebblegear.com/support



WARNING!
CHOKING & STRANGULATION
HAZARD: Not suitable for children under 3 years of age. Small parts choking risk, long cord strangulation hazard.



For further information and additional tablet accessories please visit:
www.pebblegear.com



7" KIDS TABLET
Quick start guide






Included in delivery

Im Lieferumfang enthalten • Inclus dans la livraison
Incluido en la entrega • Incluso nella consegna

TABLET



BUMPERCASE

Stoßfester Bumper • Coque de protection
Estuche de protección • Custodia di protezione



USB CABLE

USB Kabel • Câble USB
Cable USB • Cavo USB



1 Switch tablet on

Schalten Sie das Tablet ein
Allumez la tablette
Encienda la tablet
Accendere il tablet



2 Unlock the screen with your finger

Entsperren Sie den Bildschirm mit Ihrem Finger
Déverrouillez l'écran avec votre doigt
Desbloquee la pantalla con el dedo
Sbloccare lo schermo con il dito



3 Follow the on-screen instructions

Folgen Sie den Bildschirmanweisungen • Suivez les instructions à l'écran
Siga las instrucciones en pantalla • Seguire le istruzioni sullo schermo



Charging the tablet

Tablet aufladen
Chargement de la tablette
Carga de la tablet
Caricare il tablet



Please visit the following link to view full operating instructions:
Bitte besuchen Sie den folgenden Link für die vollständige Bedienungsanleitung:
Veuillez visiter le lien suivant pour voir le mode d'emploi complet :
Por favor, visite el siguiente enlace para ver el manual de instrucciones completo:
Si prega di visitare il seguente link per visualizzare le istruzioni d'uso complete:
www.pebblegear.com/manuals



User interface


Benutzeroberfläche • Interface utilisateur
Interfaz de usuario • Interfaccia utente

Battery indicator

Akku-Anzeige • Affichage de la pile
Indicador de batería • Indicatore della batteria

Time and Wi-Fi signal

Uhrzeit und W-LAN Signal
Heure et signal Wi-Fi
Hora y señal Wi-Fi
Ora e segnale Wi-Fi



Content

Inhalte • Contenu
Contenido • Contenuto

Current user profile

Aktuelles Benutzerprofil
Profil actuel de l'utilisateur
Perfil de usuario actual
Profilo utente attuale

App categories

App-Kategorien • Catégories d'applications
Categorías de aplicaciones • Categorie di applicazioni



Games
Spiele
Jeux
Partidos
Giochi



Books
Bücher
Livres
Libros
Libri



Media
Media
Médias
Medios
Media



Learning
Lernen
Éducation
Educação
Apprendimento



More apps
Mehr Apps
Plus d'applications
Más aplicaciones
Altre applicazioni



Useful accessories for more fun


Nützliches Zubehör für mehr Spaß • Des accessoires utiles pour plus de plaisir
Accesorios útiles para más diversión • Accessori utili per un maggiore divertimento



SCREEN BUDDY

Optimum tablet screen protection

Optimaler Tablet-Bildschirmschutz
Protection optimale de l'écran de la tablette
Protección óptima de la pantalla de la tablet
Protezione ottimale dello schermo del tablet



CARRY BAG

Safe transport of the tablet

Sicherer Transport des Tablets
Transport de la tablette en toute sécurité
Transporte seguro de la tablet
Trasporto sicuro del tablet

Thank you for purchasing this tablet!
Vielen Dank für den Kauf dieses Tablets!
Merci d'avoir acheté cette tablette!
Gracias por comprar esta tablet!
Grazie per aver acquistato questo tablet!

