

COSMO

COSMO Pro Air Purifier Instruction Manual




Directory

Product Overview	1
Safety precautions	3
Important Items	4
Operational Principles	4
Before Use	5
Instructions	6
Product Configuration and Parameters	7
Maintenance	7
Storage	8
Possible Malfunctions & Solutions	8




Product Overview



Product description

- A Display panel B Control panel C Front body D Air intake E Base
- F Air outlet network G Sensor H Rear shell I Power line



Control button

- 1 Digital display 2 Air quality light indicator 3 WiFi, Filter replacement indicator
- 4 UVC, Anion, Timing, Wind speed gear, Auto, Sleep indicator 5 UVC button
- 6 Anion button 7 Timing button/Child lock 8 Power button 9 Wind speed button
- 10 Filter reset button 11 WiFi button

Note: Illustrations of the product, accessories, and user interface in this user manual are for reference purposes only. The actual product and functions may vary due to product enhancements.

Safety Precautions

Read the instructions for use and safety carefully before use and keep them for future reference. It is essential that you read these instructions carefully and observe the following recommendations:

- For your safety, this product conforms to the standards and regulations (Low Voltage, Electromagnetic Compatibility, Environmental Protection).
- This product is not suitable for people with physical, sensory or mental disorders (Including children), or those who lack experience or knowledge in using it, unless supervised by those responsible for their safety, or given prior instructions on machine use.
- Children should be taken care of to ensure they do not play with this product.
- This product is forbidden for children under the age of eight, people with little experience and knowledge, or physically, sensory or mentally handicapped, but they must be trained or instructed to know how to use this product safely and to know the risks involved in this product.
- Do not use this product if the power cord is damaged. If the power cord is damaged, in order to avoid danger, it must be replaced by the manufacturer, its maintenance department or a specialist in a similar department.
- Children must not clean and maintain the product without supervision.
- When servicing this product, refer to the "Maintenance" section of the manual.
- Keep the power cord out of reach of children under the age of eight.
- This product is designed for indoor use and should not be used in industrial applications.
- If the product is damaged due to improper operation, the warranty card is invalid.
- Do not operate the product in dusty, humid, or hazardous locations.
- Always ensure that the electrical plug and power cord are good before use.
- Do not insert foreign objects into the device (such as a needle).
- Always unplug the unit when not in use or moving location. To disconnect from the power supply, grip the plug to pull from the power socket. Never pull by the cord.
- Expand the length of the power cord to the appropriate length before use.

Important matters


- Do not cover the air inlet or outlet.
- Do not touch the appliance with wet hands.
- Do not allow any liquid to enter the appliance.
- Do not use this appliance in a damp place.
- Do not use this appliance close to a heat source.
- Do not place anything on the appliance or insert any foreign objects.
- Please do not place this appliance close to flammable articles or products (curtains, aerosols, organic solvents, etc.)
- Never use the appliance in an inclined or horizontal position. Place the appliance on a flat, stable surface.
- In the case of prolonged absence: switch the appliance off and unplug it.
- Turn off the appliance and unplug before moving.
- Unplug the device when assembling or cleaning the device.

Working Principle

This machine filter system filters large particles of dust, hair, PM2.5, formaldehyde, allergens, etc., to remove odors, purify airborne pollutants, and fresh air to protect your health and family.

Composite filter.

- Volatile organic gases (VOCs)
- Odor
- Secondhand smoke
- Tiny Particles(PM2.5)
- Pollen
- Mites
- Allergen
- Bacteria/Virus



UVC Disinfection Module

- Bacteria
- Virus


Before Use

Place the purifier on a flat, stable surface in the room requiring treatment. To allow the air to circulate freely, avoid placing the appliance behind curtains, below a window, item of furniture or shelf unit, or close to any other obstacle, and leave at least 50cm of free space on each side of the appliance.

Please confirm that the filter bag inside the machine has been removed before initial use.

Please confirm:

- The voltage of your home matches the voltage of the device identification.
- Your device can be connected to a grounded power plug. This device is a Class II appliance (double insulated).
- The air inlet and outlet are completely unobstructed.
- The filter and the rear casing are properly installed (see below).
- If the rear case is not properly installed, the unit will not work properly.



Instructions for use



Power

Turn the purifier on or off.

Open the purifier air quality detection sensor system to open, the operation panel digital tube frame flashes about 30S, the air quality detection sensor system completes the test. The indoor air quality condition is informed by the digital display of the operation panel and the air quality indicator "blue, green and red";

Digital Display	Color	Air Quality
0-75	Blue	Good air quality
76-150	Green	Excellent air quality
151 above	Red	Poor air quality



UVC Function

Press the UVC button to turn on the UVC function. The built-in ultraviolet lamp starts to work, killing bacteria and viruses in the filter and the airflow, and press the UVC button again to turn off.



Anion Function

The anion function is switched on by default. To activate it press button, the anion function will turn on as indicated on the panel and the appliance will start to release the anion. Press the button again to turn it off.



Timer Function/Child Lock

Timer Function: When the purifier is working, press the button to select the required working time (1~12h). After the set time, the purifier will automatically stop working.

Child lock: Press and hold the timer button for 3 seconds to turn on the child lock function; In this mode, other buttons on the control panel will not be available; Press and hold the timer button for 3 seconds to turn off the child lock.



Wind Speed Adjustment

Press the wind speed button repeatedly to select the wind speed you need. The mode changes in the following order: Low -> Medium -> Strong -> Auto -> Sleep.

Auto mode: In this operating mode, the wind speed automatically adjusts according to



Filter Reset

If the filter reset indicator starts blinking red while using the air purifier, replace the filter and hold the button for 5 seconds or longer to reset the filter life.



WiFi Function

Press and hold the button for 3 seconds to connect to wifi.

Product configuration and parameters

Rated voltage:	230V	CADR(Particulates):	600m3/h
Rated power:	60W	Noise:	20-50dB
Material quality:	ABS	Application area:	100m ²
Overall size:	290*290*577mm	Product Weight:	6.9KG

Maintenance

Be sure to stop the appliance operation and remove the power plug from the outlet before cleaning and placing the filter. Do not spray water directly on the appliance.

Never use sulphuric acid, hydrochloric acid or organic solvent (e.g., thinner, kerosene and acetone) to wipe the appliance exterior, or affix labels on the exterior. Doing so may damage the product surface. Care should be exercised to prevent flowing of water into the product.

Filter replacement

Filter	Operating	Frequency
Photocatalysis filter, Anti-bacteria cloth, Activated carbon and Hepa 13 composite filter.	Replace	Every 12 months

This data is based on an average use of 8 hours per day at low speed.

The recommended filter change frequency will vary depending on the duration of use and the operating environment. The corresponding indicator will illuminate when the filter needs to be replaced.

This air purifier is equipped with a filter replacement indicator to make sure that the air purification filter is in optimal condition when the air purifier is operating. When the filters need to be replaced, the filter reset indicator will start blinking.

Note:

*The air filters are not washable or reusable. Do not clean the filter with a vacuum.

*Do not touch the pleated filter surface, or smell the filter as it has collected pollutants from the air.

Storage

If the appliance is not used for a long period of time, store it at a shaded and dry place.

Possible Malfunctions & Solutions

Please check the following before you contact the service center. If the problem persists, contact your after-sales service center.

Symptoms	Possible Causes & Solution
The appliance does not operate.	The power plug is unplugged from the outlet. • Plug it into the outlet properly.
Symptoms	Possible Causes & Solution
A strange odor comes out from the air outlet as well as the filter.	The appliance is located in an area with a lot of smoke or odors. • In areas with a lot of smoke or odors, the lifespan of the filters may be greatly decreased. For best results, ventilate the room first, then use the appliance.
	The odor is coming from the filter. • Replace the filter. The filter replacement frequency may differ depending on the usage environment.
	The appliance is located in an area with a lot of strong odors. • If the appliance is used near where you cook or broil fish or meat, the lifespan of the filters will be greatly decreased. • For best results, ventilate the area first by opening a window or using a vent hood. Use the appliance only to minimize odors left after ventilating the area.