


4K ANDROID TV™ Stick



Quick Reference Guide

Please read the user manual before operating the Stick



Safety instructions




WARNING!

- ❖ Presence of live parts inside the device! Do not open. Risk of electric shock!
- ❖ No parts should be repaired by users.
- ❖ Place the device on a flat, firm and stable surface. Do not put it on a carpet or rug.
- ❖ Place the device in a well-ventilated location to prevent the accumulation of internal heat.
- ❖ Protect the device from high temperatures, humidity, water and dust.
- ❖ Do not place any objects near your device that may damage it (e.g. liquid-filled objects or candles).
- ❖ Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cab, ni-mh, etc.) batteries.

Accessory List


Please open the package and check the following accessories:




TV Stick x1




Remote Control x1



Power Adapter x1



User Manual x1




USB charging


Hardware Structure




- **Front Panel**




- **Bottom Panel**



- **Top Surface Panel**



Remote Control




Note: Press the Google Assistant button to start voice search for what you want.



System Connection

Please refer to below pictures and instructions to connect TV Stick

Note: Please turn off all equipment before connecting.



Step1

Connection with TV

Plug the TV Stick into the TV's HDMI port.

Step2

Connection with Power

Use the power adapter to connect the Stick and TV. Plug the power adapter into A/C outlet. If TV has a powered USB port, it can also plug the micro-USB cable directly into the Stick port.

Note: Some USB ports don't provide enough continuous power. You need to connect with A/C power outlet directly.

Step3

Connection with Network

Enter **Settings**→**Network** to turn on Wi-Fi and connect an available Wi-Fi network with correct password.



Troubleshooting

- **No display after power on?**

Confirm your device connected to the TV well and set the correct HDMI Input from your TV configuration.

- **TV has images but no sound?**

Make sure your TV is not in mute and low volume.

- **Fail to connect to network?**

Make sure your Wi-Fi is functional and your box has a strong enough signal from your router.

- **Remote Control Failure?**

Replace your Remote Control batteries with new ones, then re-paired it by pressing the pinhole on the side of the device for more than 3 seconds.

- **Please use our accessories to avoid any risk.**



Compliance



The terms HDMI, HDMI High-Definition Multimedia interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Google, Android, Google Play, YouTube and other marks are trademarks of Google LLC. Netflix is a trademark of Netflix, Inc. All brands contained herein are trademarks of their respective owners.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

