




Vertical mouse instruction manual

This ergonomic vertical mouse combines the state of the human hand when placed naturally, it can effectively prevent the mouse hand, relieve fatigue, reduce the burden on the arm and shoulder pain, which makes work more relax.





Technical Parameters:

Size:122*62*75mm

weight:140 g

engine:wired, laser

wireless, photoelectric

Number of keys:6

Resolution:wired: 800-1200-2000-3200

Wireless:800-1200-1600

System support:Windows series MAC Linux

Notes: This product has 3 configurations, A .B. Cfor your choice.

Configure A: lithium battery version, this version has a built in_rechargeable lithium battery, with an additional USB charging cable.

Configure B: AAA battery wireless models, loaded with 2 AAA batteries, shipping do not including 2pcs AAA battery

Configuration C: wired models, a USB cable to connect the equipmentpower supplyAppendix



Connected to use

Wired mouse: Insert the USB into the device interface, without any driver, if the cursor is floating, the cause of the cursor floating is the surface of the mouse moving usually, You'd better replace a high quality mouse pad.

Wireless mouse: take out the USB receiver, and correctly insert it into the device which supports the use of USB, open the switch at the bottom of the receiver, the mouse will automatically create a connection with the receiver, then you can use the mouse normally. You can close the switch if you do not use the mouse. This mouse supports secondary sleeping mode, which can save power. If you do not use it for a long time it will automatically sleep, and you can press any mouse button to wake up .

Rechargeable Battery

The power supply of the wireless mouse is the built-in lithium battery, when the mouse can not be used in the machine or when the cursor is not smooth or difficult to move, then need to charge the battery, the charge can use the manufacturer equipped with USB charging line charge, You can use Andrews phone charging line to charge conveniently. The wireless mouse is charging during the charging light is red. when the charging light turns into a green, you can remove the charging device

Warning: This wireless mouse has a battery, do not disassemble, do not put in the fire or high temperature and high heat environment, to prevent the explosion



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

