


1988 Mercedes Benz 560SL (107.048) V8-5.6L (117.967)

Vehicle > Powertrain Management > Fuel Delivery and Air Induction > Fuel Tank > Fuel Gauge Sender > Service and Repair > Procedures

FUEL GAUGE SENDER, REMOVAL AND INSTALLATION

Removing and installing fuel gauge sender

Model 107



Disconnect battery ground cable

Take off hardtop

Open softtop

Unclip cover

Unplug coupling at fuel gauge sender (B4), secure against slipping off.

Remove fuel gauge sender (B4), run empty if necessary.

Replace seal.

Remove securing pin below adhesive strip (of new part).

Tightening torque **40 Nm**.

