














	EN In The Box																						
EN Product Overview	EN Placement * Above functions are available for either earbud in individual or stereo mode.																						
EN Headphones Pairing The Left and Right headphones will automatically pair to each other after the lid is open when they are in the case (with charge). Bluetooth Pairing To The Device To connect to your device for the first time, turn the headphones on to enter the pairing mode, the Right headphone will flash in white alternatively. Headphones will enter a standby mode if not paired to a device within 3 minutes. * After the first successful pairing, headphones will automatically connect to your device. To pair the headphones to a new device, simply place them into the charging case and press the pairing button for 2 seconds. Then click "1MORE ColorBuds 2" in the new device pairing list to connect. * After the first successful pairing, headphones will automatically connect to your device.	EN Charging ① To charge the case with Type-C cable. A full charge will take around 85 minutes. The LED light of the charging case will indicate different battery statuses. * The headphones are certified by Qi wireless charging, please use a Qi certified charging pad to ensure charging safety and efficiency. ② To charge the headphones with the case. Put headphones in correct slot until it locks in via the magnet. The white light of headphones will indicate headphones are charging. A full charge will take around 70 minutes. The red light on the headphones turning off indicates the charging is complete.																						
EN Battery Status Display in 1MORE MUSIC APP Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP. Battery Notification LED indicator for low battery: when there is 25-30 minutes of use left, you will hear the notification sound and the LED indicator will flash white twice. When the charge is too low on the case battery, the LED indicator will flash red.	EN Touch Controls Switch the Listening Modes The default setting of the headphones is "ANC On", touch and hold on the outside of the headphone to switch "ANC On" to "Pass-through". Phonecalls and music can be controlled by tapping the outside of the earbuds. * Above functions are available for either earbud in individual or Stereo mode. * To decline a call, change a song or control volume, please operate on 1MORE MUSIC APP, paired mobile phone or device. * Above functions may vary with different devices.																						
EN Smart Playback An IR Sensor automatically detects when you take out your headphones to stop playback intuitively and resumes playback when you put them back in. To turn off Auto-Play, connect the headphones to the 1MORE MUSIC App and change in the settings. Personalized Sound Enabled by SoundID 1MORE MUSIC APP applies with the personalized sound technology – SoundID. Based on professional music-processing reference standard, SoundID can calculate out the best EQ for ears and solidify it to the headphones for any time use. To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 2 seconds. Then click the new device name and pair with the new cellphone. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: - This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. - This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. - This limited warranty is null and void for products not used in accordance with 1MORE's instructions. - This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. - This limited warranty terminates if you sell or otherwise transfer this product to another party.	EN Extra Functions 1. If only 1 headphone can be paired to the device, Open the case, click the pairing button in the case 3 times quickly to initiate a Left & Right pairing, and then click "1MORE ColorBuds 2" in the device pairing list to connect to your device. 2. Resetting the headphones: Put both Left and Right headphones into the case, then press and hold the pairing button in the case for 8 seconds. The headphones will initiate pairing to each other again and the pairing records on the mobile phone/device will be cleared. 3. OTA Firmware Update: can be done synchronously via the 1MORE MUSIC APP while the Left and Right earbuds are paired to each other. * Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.																						
EN 1MORE (1) Year Limited Warranty 1MORE warrants to the original retail purchaser that this product is to be free from defective materials and workmanship for a period of one year from the date of purchase if it is properly used and maintained. If this product proves defective in either material or workmanship, 1MORE, at its option, will (a) repair the product with new or refurbished parts, or (b) replace the product with an equivalent new or refurbished product, at no charge for parts or labor. If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, 1MORE at its sole option may replace the unit with a current model of equal or greater value. In some cases, modification to the mounting surface may be required where a new model is substituted. 1MORE assumes no responsibility or liability for such modification. TO OBTAIN A REPAIR OR REPLACEMENT UNDER THE TERMS OF THIS WARRANTY, PLEASE RETURN TO THE ORIGINAL DEALER FIRST AND THE ORIGINAL DEALER SHALL REPAIR THE PRODUCT WITH NEW OR REFURBISHED PARTS OR REPLACE THE PRODUCT WITH AN EQUIVALENT NEW OR REFURBISHED PRODUCT. You will be required to submit a proof of purchasing details, including but not limited to a receipt or sales invoice. Return shipping for exchanges/repairs is the sole responsibility of the original retail purchaser. Limitations: - This limited warranty does not cover the failure of the product resulting from improper installation, misuse, abuse, accident, neglect, mishandling, or wear from ordinary use or environmental deterioration. - This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product. - This limited warranty is null and void for products not used in accordance with 1MORE's instructions. - This limited warranty is null and void for products with altered or missing serial numbers and for products not purchased from an AUTHORIZED dealer. - This limited warranty terminates if you sell or otherwise transfer this product to another party.	EN We Appreciate Your Business We know you will enjoy new 1MORE headphones as much as we do. At 1MORE, we value your satisfaction, if you would like more details on this product or any of our other products, please visit us online by scanning the QR code. Go to www.1more.com and sign up for VIP, and 1MORE will treat you like one. Tips - Please read this instruction manual carefully and retain for future reference. - Please fully charge the battery before first use. - If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity. - Only use charging cables and adapters that are FCC (Federal Communications Commission) approved. - In dry environments, static electricity may numb your ear. This is not related to the quality of the product. Safety Information - Never disassemble the headphones. There are no user-serviceable parts inside. - Do not expose the headphones to temperatures below 32 °F (0 °C) or to temperatures above 113 °F (45 °C). - Do not use the headphones in a thunderstorm storm. This could prevent the headphones from working properly, and also increase your chance of being electrically shocked. - Do not use oil or any volatile liquid to clean this product. - Do not listen at high volumes for extended periods of time. - Do not use the headphones in traffic. Do not use the headphones any time it would be dangerous to be unaware of noises around you. - Adult supervision is required for children of age 6 and under. - If you don't feel comfortable after wearing the headphones, please refer to an aurist for advice on whether in-ear headphones are suitable for you.																						
EN FAQ - Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes. - Why the headphones cannot connect to my cellphone, or take a long time to connect? 1) If the earbuds cannot pair to one another, and only one earbud will pair with your cellphone, then put both buds back into the charging case and quickly press the pairing button 3 times, click the device name, they should now pair correctly to the phone. 2) To pair the earbuds to a new cellphone, simply place them into the charging case and depress the pairing button for 2 seconds. Then click the new device name and pair with the new cellphone. - Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on. - Why there is no sound from the headphones while making phone calls after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on. - Why the Bluetooth connection is not stable and causes some interruptions? 1) Try shortening the distance between your headphones and device. Avoid solid barriers in between. 2) Please keep away from strong interference sources, such as Wi-Fi and GPRS. 3) Please make sure the Bluetooth antenna of your device is not blocked. - Why some control functions do not match those in the manual while using third party music/video player Apps? Your operating system and the third party music/video player apps may have different settings for the in-line remote control functions. We recommend that you use the music/video player apps that your device has originally provided. * For more detailed product FAQs, please visit the product support section under www.1more.com	EN WEEE Electrical and electronic equipment, parts and batteries marked with this symbol must not be disposed of with normal household waste; it must be collected and disposed of separately to protect the environment. Your 1MORE retailer will advise you of the correct way of disposal in your country. Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like. CE Declaration of Conformity Hereby, TiniLab Corporation declares that the radio equipment type "1MORE ColorBuds 2" is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.1more.com RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation Exposure Statement Power is so low that no RF exposure calculation is needed. Declaration for EU Compliance Operation Frequency/Max. EIRP: 2400-2483.5MHz, Left ear Max. EIRP is 12dBm, Right ear Max. EIRP is 12dBm.																						
EN Warning Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. ⚡ The symbol indicates DC voltage. ♻️ RECYCLING This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2014/53/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment. ⚠️ To prevent possible hearing damage, do not listen at high volume levels for long periods.	EN FCC The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (FCC ID: 2ASDIES602L (Left ear) , 2ASDIES602R (Right ear)) has also been tested with 0mm against this SAR limit. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changesto this equipment. Such modifications or changes could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.																						
EN Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information Unique Identifier: Trade Name: 1MORE Model No.: ES602 Responsible Party – U.S. Contact Information 1MORE USA, Inc. Address: 10225 Barnes Canyon Road, Suite A202, San Diego, California, 92121 Tel: 1-855-551-6673 E-Mail: support@1moreusa.com IC regulatory conformance This device complies with CAN ICES-003 (B)/NMB-003(B) and CAN RSS-216 / CNR-216 . This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device must not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil est conforme à la norme CAN ICES-003 (B)/NMB-003 (B) et au RSS-216 / CNR-216 . Cet appareil contient des émetteurs / récepteurs exempt (s) de licence qui sont conformes aux RSS exemptes de licence d'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) Cet appareil ne doit pas provoquer d'interférences. (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil. The SAR limit of Canada (ICES) is 1.6 W/kg for head averaged over one gram of tissue. Device types ES602 (IC: 24662-ES602L (Left ear) , 24662-ES602R (Right ear)) has also been tested with 0mm against this SAR limit. * Do not put the battery in trash that is disposed of in landfills. When disposing of the battery, comply with local laws or regulations.	EN Model: ES602 <table> <tr> <td>Headphone Weight (Single): 4.9 g</td> <td>Headphones + Case: 18 hours</td> </tr> <tr> <td>Case Weight: 34.5 g</td> <td>Fully Charged Playtime (ANC Off)</td> </tr> <tr> <td>Product Weight: 44.3 g</td> <td>Headphone: 8 hours</td> </tr> <tr> <td>Headphone Size: 27 × 21 × 20 mm</td> <td>Headphones + Case: 24 hours</td> </tr> <tr> <td>Case Size: 60 × 30 × 38 mm</td> <td>Impedance: 32 Ω</td> </tr> <tr> <td>Headphone Battery Capacity (Single): 55 mAh</td> <td>Wireless Range: 10 m</td> </tr> <tr> <td>Case Battery Capacity: 410 mAh</td> <td>Bluetooth: Bluetooth® 5.2</td> </tr> <tr> <td>Headphone Charging Time: 70 mins</td> <td>Bluetooth Protocol: HFP / A2DP / AVRCP</td> </tr> <tr> <td>Case Charging Time (with cable): 85 mins</td> <td>Input: 5V = 1A</td> </tr> <tr> <td>Fully Charged Playtime (ANC On)</td> <td>Working Temperature: 0 °C ~ 45 °C</td> </tr> <tr> <td>Headphone: 6 hours</td> <td>Frequency Band: 2.400 GHz ~ 2.4835 GHz</td> </tr> </table> The specifications are acquired from laboratory tested data. * The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors. Manufacturer: TiniLab Corporation Add: No. 3333, Liuxian Avenue, Tower A, 35th Floor, Tanglang City, Nanshan District, Shenzhen, China Product information can be found at www.1more.com	Headphone Weight (Single): 4.9 g	Headphones + Case: 18 hours	Case Weight: 34.5 g	Fully Charged Playtime (ANC Off)	Product Weight: 44.3 g	Headphone: 8 hours	Headphone Size: 27 × 21 × 20 mm	Headphones + Case: 24 hours	Case Size: 60 × 30 × 38 mm	Impedance: 32 Ω	Headphone Battery Capacity (Single): 55 mAh	Wireless Range: 10 m	Case Battery Capacity: 410 mAh	Bluetooth: Bluetooth® 5.2	Headphone Charging Time: 70 mins	Bluetooth Protocol: HFP / A2DP / AVRCP	Case Charging Time (with cable): 85 mins	Input: 5V = 1A	Fully Charged Playtime (ANC On)	Working Temperature: 0 °C ~ 45 °C	Headphone: 6 hours	Frequency Band: 2.400 GHz ~ 2.4835 GHz
Headphone Weight (Single): 4.9 g	Headphones + Case: 18 hours																						
Case Weight: 34.5 g	Fully Charged Playtime (ANC Off)																						
Product Weight: 44.3 g	Headphone: 8 hours																						
Headphone Size: 27 × 21 × 20 mm	Headphones + Case: 24 hours																						
Case Size: 60 × 30 × 38 mm	Impedance: 32 Ω																						
Headphone Battery Capacity (Single): 55 mAh	Wireless Range: 10 m																						
Case Battery Capacity: 410 mAh	Bluetooth: Bluetooth® 5.2																						
Headphone Charging Time: 70 mins	Bluetooth Protocol: HFP / A2DP / AVRCP																						
Case Charging Time (with cable): 85 mins	Input: 5V = 1A																						
Fully Charged Playtime (ANC On)	Working Temperature: 0 °C ~ 45 °C																						
Headphone: 6 hours	Frequency Band: 2.400 GHz ~ 2.4835 GHz																						




產品概覽




1MORE MUSIC APP 電量顯示

耳機與充電盒的電量狀態將在 1MORE MUSIC APP 中顯示。



電量提示



保固範圍

1MORE 保證消費者自初次購買之日起一年內，對 1MORE 產品在正常使用途中材料和工藝上的缺陷進行保修。在保固範圍內，1MORE 會直接受理您的申訴（包括從 1MORE 授權的經銷商處購買的 1MORE 產品）。在保固期內，1MORE 將自行決定修理或更換有缺陷產品或按照購買價格進行退款。本保固不適用於天災意外或使用，保養，維修不當，或是其他不是由材料，工藝上的缺陷引起的情况。完整的保固細節請登錄 www.1more.com 查看。


感謝您的購買

我們知道您會享受並喜愛 1MORE 耳機。在 1 MORE 我們格外重視您的滿意度，如果您想要了解更多產品的訊息請掃描背面的二維碼，進入 www.1more.com 登錄成為 VIP，1MORE 將提供您專榮的服務。


NCC

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。


包裝內容




耳機佩戴




開 / 關機



充電 ① 使用 Type-C 充電線給充電盒充電




② 使用充電盒為耳機充電



觸控功能

聆聽模式切換
耳機出廠設置為“主動降噪”，長觸耳機表面（約 1.5 秒）可在“主動降噪”與“通透模式”模式間切換。
通話和播放功能可通過觸擊耳機表面來實現。



* 上述功能適用於單、雙模式使用時的任一耳機。
* 拒接電話、選曲及音量調節，請在 1MORE MUSIC APP 及手機等設備端進行操作。
* 以上功能定義因設備不同可能略有差異。



其它功能

- 如左、右耳機無法配對，僅有單個耳機可與藍牙設備連接，可將左、右耳機放入盒中，三連擊配對按鈕，再點擊藍牙設備配對列表中的“1MORE ColorBuds 2”進行連接。
 - 耳機恢復出廠設置：
將左、右耳機放入充電盒中，長按充電盒配對按鈕 8 秒，左、右耳機重新自動配對，且藍牙設備的連接記錄被強制清除。
 - OTA 軟體升級：左、右耳機藍牙連接時，可直接在 1MORE MUSIC APP 上同步升級。
- * 1MORE MUSIC APP 的所有功能，在不同手機及操作系統上或有不同，請聯繫客服了解更多詳情。

名稱：1MORE ColorBuds 2 時尚豆	
型號：ES602	滿電播放時長（降噪開）* 單耳滿電：6 小時
耳機重量（單個）：4.9 克	搭配充電盒滿電：18 小時
充電盒重量：34.5 克	滿電播放時長（降噪開）* 單耳滿電：8 小時
整機重量：44.3 克	搭配充電盒滿電：24 小時
耳機尺寸：27 × 21 × 20 mm	藍牙規範：Bluetooth® 5.2
充電盒尺寸：60 × 30 × 38 mm	藍牙協議：HFP / A2DP / AVRCP
喇叭阻抗：32 Ω	輸入：5V=1A
通訊距離：10 米（在空曠環境下）	工作溫度：0℃～45℃
耳機電池容量（單個）：55 mAh	頻率波段：2.400 GHz～2.4835 GHz
充電盒電池容量：410 mAh	
耳機充電時間：70 分鐘	
充電盒充電時間（有線）：85 分鐘	
規格參數為實驗室測試數據。 * 播放時長為 AAC 格式、50% 音量條件下的實驗室測算數據，依設備設置、環境、用情況及諸多其他因素可能有所差異。	
製造商：萬魔聲學股份有限公司	
地址：深圳市南山區留仙大道 3333 號塘朗城 A 座 35 樓	

