








BIKE BELL USER MANUAL

 BIKE BELL	PARTS  COPPER BELL BLACK BELL COVER EVA PAD EVA PAD WATERPROOF RING CLAMP SCREW	AIRTAG INSTALLATION  Turn the black bell cover clockwise. AirTag Placement After inserting your Airtag, lock the black bell cover clockwise.	HANDLEBAR INSTALLATION  Diagram showing the bell being attached to a handlebar using the clamp and screw.	Bike Bell Material: Copper Waterproof grade: IPX5 Size: 38x49x56mm Weight: 40.9g Product does not contain AirTag Certified 
 CAMPANA DE BICICLETA	PIEZAS  CAMPANA DE COBRE CUBIERTA DE CAMPANA EVA PAD EVA PAD ANILLO IMPERMEABLE ABRAZADERA TORNILLO	INSTALACIÓN DE AIRTAG  Gire la cubierta negra de la campana en el sentido de las agujas del reloj. Colocación de AirTag (Localizador) Después de insertar su AirTag (Localizador), bloquee la tapa de la campana en el sentido de las agujas del reloj.	INSTALACIÓN DEL MANILLAR  Diagram showing the bell being attached to a handlebar using the clamp and screw.	Campana de Bicicleta Material: Cobre Grado Impermeable: IPX5 Tamaño: 38x49x56mm Peso: 40.9 g El producto no contiene AirTag (Localizador) Certificado 

