


Hob instructions:

Control Panel



1. ON/OFF control
2. Power / Timer regulating controls
3. Heating zone selection controls
4. Timer control
5. Keylock control
6. Double zone control

Switching on the cooking hob:

1. Press on button (1) down After power on, the buzzer will beep once, all the indicators will light up
2. Touch the heating zone you require button (3)
- 3.
4. Select a heat setting by touching the “-” or “+” control button (2). If you do not choose a heat setting within 1 minute, the ceramic hob will automatically switch off. You will need to start again at step 1.

Turning off the hob:

5. Once you are ready to turn off the hob select the heating zone you require to turn off
6. Turn the cooking zone off by scrolling down to “0” or touching “-” and “+” control button (2) together
7. Turn the whole cooktop off by touching the ON/OFF control button (1).

