




ASSEMBLY & SAFETY INSTRUCTION

etherCON® Magnetics | A & B-Series



NOTE:

- Attention: this Product is strictly not intended for use in PoE systems.
- This product is designed to be installed built-in electronic devices.
- This product is strictly not intended to be used within explosive environments.



Assembly

- Install the receptacle in the panel cutout.
- Finish the installation and fasten the screws.
 - ▶ Use the special Neutrik A-screw to fixing.
 - ▶ **max. Torque 40 Ncm.**

Find more details of
connectors on
www.neutrik.com.



Neutrik AG
Neutrik Americas Inc.
Neutrik (UK) Ltd.
Neutrik Vertriebs GmbH

LI
USA
UK
DE/NL/AT/DK

T: +423 / 237 24 24
T: +1 704 / 972 3050
T: +44 1983 / 811 441
T: +49 8131 / 280 890

F: +423 / 232 53 93
F: +1 704 / 438 9202
F: +44 1983 / 811 439
F: +49 8131 / 280 830

Neutrik France
Neutrik Tokyo Ltd.
Neutrik Hong Kong Ltd.

FR
JP
HK

T: +33 1 / 4131 6750
T: +81 3 / 3663 4733
T: +852 / 2687 6055

F: +33 1 / 4131 0511
F: +81 3 / 3663 4796
F: +852 / 2687 6052

Draft. Nr.: BDA 633 | Update: 2021-09-07 | Data subject to change without prior notice. © 2021 NEUTRIK®, NEUTRIK® are registered trademark of Neutrik AG. ALL RIGHTS RESERVED.

www.neutrik.com

NEUTRIK®

