

## Anderic RR1001 User Manual

**Note:** The RR1001 is preprogrammed to control LG TV.

**Recommendation:** Please visit our website for mobile & desktop versions of this manual. We recommend downloading it to your mobile device or bookmarking our URL so you can access the manual whenever you need help with your RR1001 remote. You can go to the URL below or scan the QR code directly.

<http://www.anderic.com/rr1001>



### Program - Code Input Method

1. Turn on the TV manually.
2. Press and hold the **[SET]** and **[POWER]** keys simultaneously for 3 seconds; the indicator light shall remain on, then release the keys.
3. Enter the 4-digit code of your brand TV from the code list at the end of this manual. After a valid code entry, the indicator turns off. The indicator flashes four times quickly for an invalid code and exits setup mode.

**NOTE:** After entering code setup mode, if without pressing any button for 10 seconds, the remote shall quit the setup mode.

### Program - Shortcut Key Method

1. Turn on the TV manually.
2. Press and hold **[SET]** and the respective TV brand key from the chart below. (**0-9, +100, MUTE**) simultaneously and continue to hold keys until the TV is powered off; the indicator light shall remain on for the duration;

Now the remote is automatically searching the code of that TV brand. If the TV is controlled (by powering on or turning it off), release the buttons to save the code and quit programming.

### **Shortcut Key - Brand Chart**

| BRAND                             | Press Key  | BRAND                                           | Press Key  | BRAND                                    | Press Key  |
|-----------------------------------|------------|-------------------------------------------------|------------|------------------------------------------|------------|
| SONY<br>VIEWSONIC<br>WESTINGHOUSE | <b>[1]</b> | SAMSUNG<br>INSIGNIA<br>AOC<br>ENVISION<br>DYNEX | <b>[2]</b> | PHILIPS<br>Magnavox<br>FUNAI<br>AUDIOVOX | <b>[3]</b> |



|                           |            |                                     |                      |                    |            |
|---------------------------|------------|-------------------------------------|----------------------|--------------------|------------|
| TOSHIBA<br>SANSUI<br>COBY | <b>[4]</b> | JVC<br>SANYO<br>Sylvania<br>Emerson | <b>[5]</b>           | LG<br>ZENITH       | <b>[6]</b> |
| MITSUBISHI<br>POLAROID    | <b>[7]</b> | SHARP<br>YAMAHA<br>ORION<br>EMERSON | <b>[8]</b>           | PANASONIC<br>HAIER | <b>[9]</b> |
| VIZIO<br>NEC<br>OLIVIA    | <b>[0]</b> | HITACHI<br>MITSUI                   | <b>[+10<br/>0/-]</b> |                    |            |

### **Program – Manual Code Search**

1. Turn on the TV.
2. Press and hold the **[SET]** key, then long press the **[CH+]** key for about 5 seconds until the indicator light remains on. Release the keys.
3. Press and release the key **[CH+]** or **[CH-]**, with each press code, will change. Long-pressing the **[CH+]** or **[CH-]** key code will change faster. When the channel changes, please press the **[SET]** key quickly to save the code.

**NOTE:** Pressing **[CH+]** scrolls forward, while **[CH-]** scrolls backward through the code database. If no key is pressed in 10 seconds, the setting will be exited automatically during the setting process.

### **Learning function**

1. Press and hold the **[SET]** key, then simultaneously long-press the **[VOL+]** key for about 5 seconds; the indicator light will light and remain on. Release the two keys. The remote is now in learning mode.
2. Point the original remote toward the RR1001. The distance should be within 1-3 cm, and the eyes of the remotes must directly align.
3. Press the key you want to learn from the original remote control (the LED of RR1001 will keep flashing), then press any key of RR1001 to which you wish to assign the code. The indicator light will remain on.
4. Repeat **Step 2** to continue learning the other keys.
5. When you have finished learning all the desired keys, press and hold the **[SET]** key, then simultaneously press the **[VOL-]** key, and the indicator light will go out. The learning will be saved and exited.

**NOTE:** During the learning process, if no keys are pressed in 25 seconds, the learning state will be exited without saving.

### **Code Identification**

1. Press and hold the **[SET]** and **[POWER]** keys simultaneously for 3 seconds; the indicator light shall remain on, then release the keys.



2. Input **[9] [9] [0]** with number keys. The indicator light will flash twice and turn off.
3. Press the key **[1]**, count the number of indicator light flashes, and write it down.
4. Press the key **[2]**, count the number of indicator light flashes, and write it down.
5. Press the key **[3]**, count the number of indicator light flashes, and write it down.
6. Press the key **[4]**, count the number of indicator light flashes, and write it down.

NOTE: If the code number is 0. The indicator light will not flash.

### **Factory Reset**

Press and hold the **[SET]** and **[POWER]** keys simultaneously for 3 seconds; the indicator light shall remain on, then release the keys.

Press the **[CC]** key and the light shall flash three times. The remote has now been reset to factory settings.

NOTE: The factory code can control 95% of the most popular TVs if the remote is reset to factory settings.

### **Setting the Sleep Timer**

NOTE: The SLEEP button operates the Sleep function of your TV, providing it supports the Sleep function. Alternatively, with the instructions in this section, you can enable the remote to turn off your TV after 1 to 99 minutes. This feature works even if your TV does not have its Sleep function.

- First, make sure you have your remote programmed to your TV using one of the above programming methods.
  - After successfully programming your remote, try pressing the **SLEEP** button first and make sure the on-screen sleep option **DOES NOT** appear before continuing. If it does occur, you do not have to continue with the following steps.
1. Press and hold the **[SLEEP]** key until the indicator light blinks and remains on. Then release the key.
  2. Using the numerical pad, press numbers 01 - 99 depending on the minutes you would like before the TV turns off (Example: If you press 01, the TV will turn off in 1 minute). The indicator light will turn off. TV Sleep Timer is now set.
  3. Leave the remote pointing towards the TV with an unobstructed path.

NOTE: To cancel the sleep function, press and hold the **[SLEEP]** or **[POWER]** key for 3 seconds. Pressing any other additional buttons on the remote will not cancel the sleep timer.

### **Setup Lock**

1. Press and hold the **[SET]** and **[POWER]** keys simultaneously for 3 seconds; the indicator light will remain on, then release the keys.
2. Input code using keys **[9] [9] [6] [6]**; the indicator light shall flash five times. The remote is locked and cannot be programmed in any way unless these steps are repeated.

NOTE: to unlock the remote, repeat the above steps.

Additional Notes: This unit will retain the programmed codes when changing the batteries.

**Copyright Dan's Electronics Etc., Inc. All rights reserved. 2023.**

**TV CODE LIST**



|                  |                                                   |
|------------------|---------------------------------------------------|
| ACTION           | 1019                                              |
| ADMIRAL          | 1048 1298 1299 1008 1015 1027 1072 1259 1346      |
| ADVENT           | 1257 1278 1002 1034                               |
| ADVENTURA        | 1300                                              |
| AIKO             | 1165 1032 1399                                    |
| AIM              | 1143                                              |
| AIWA             | 1019 1024                                         |
| AKAI             | 1204 1216 1217 1255 1301 1010                     |
| AKAWA            | 1019 1298 1302 1303                               |
| AKIO             | 1076 1082 1012 1032 1033 1304                     |
| AKISHI           | 1010                                              |
| ALARON           | 1298                                              |
| ALFIE            | 1085                                              |
| ALLEGRO          | 1072                                              |
| AMARK            | 1304 1028 1043 1002                               |
| AMBASSADOR       | 1027                                              |
| AMERICAN ACTION  | 1019                                              |
| AMPRO            | 1015                                              |
| AMTRON           | 1019                                              |
| ANAM             | 1031 1014 1019 1028 1043 1305                     |
| ANAM NATIONAL    | 1305                                              |
| AOC              | 1250 1251 1252 1253 1254 1301 1306 1400 1401 1402 |
| AOMI             | 1365                                              |
| APEX DIGITAL     | 1120 1269                                         |
| ASAHI            | 1113                                              |
| ASCENT (LCD)     | 1022                                              |
| AUDIOLOGIC       | 1092                                              |
| AUDINAC          | 1048 1076 1019                                    |
| AUDIOVOX         | 1019 1020 1032 1033 1120                          |
| AUDITRON         | 1307                                              |
| AURORA           | 1164                                              |
| BAYSONIC         | 1019 1062                                         |
| BELCOR           | 1301                                              |
| BELL & HOWELL    | 1021 1299                                         |
| BENQ (LCD)       | 1331                                              |
| BGH              | 1048 1090 1104 1105 1337                          |
| BLUESKY          | 1166 1169 1019                                    |
| BLUE LIGHT (LCD) | 1007 1334                                         |
| BLUE POINT       | 1019 1303 1304                                    |



|                  |                                                                                 |
|------------------|---------------------------------------------------------------------------------|
| BRADFORD         | 1019                                                                            |
| BROCKWOOD        | 1301                                                                            |
| BROKSONIC        | 1019 1026 1027 1028 1029 1031 1033 1043 1067 1071 1074 1259 1299 1302 1308 1164 |
| BROKSONIC 1-14   | 1308                                                                            |
| BROKSONIC 1-16   | 1031                                                                            |
| BROKSONIC LETRAS | 1027                                                                            |
| CALCULADORA      | 1078                                                                            |
| CANDLE           | 1301 1076                                                                       |
| CAMIVALE         | 1301                                                                            |
| CARVER           | 1034                                                                            |
| CARREFOUR        | 1168                                                                            |
| CCE              | 1022 1024 1033 1047 1057 1064 1067 1068 1073 1076                               |
| CEGESA           | 1162                                                                            |
| CELEBRITY        | 1002                                                                            |
| CELERA           | 1267 1269 1003                                                                  |
| CENTURION        | 1301                                                                            |
| CENTURY          | 1019 1032 1114                                                                  |
| CETRONIC         | 1019                                                                            |
| CHANGHONG        | 1003                                                                            |
| CHASSIS          | 1039 1113                                                                       |
| CHONGUI          | 1177                                                                            |
| CINERAL          | 1032 1033 1048 1050 1081 1092                                                   |
| CITIZEN          | 1304 1032 1114 1259 1299 1301 1303                                              |
| CLAIRTONE        | 1306                                                                            |
| CLARION          | 1019                                                                            |
| CLASSIC          | 1019                                                                            |
| COBY             | 1465                                                                            |
| COLOMBIA         | 1034                                                                            |
| CONCERTO         | 1301                                                                            |
| CONVERSOR        | 1116 1159                                                                       |
| CONTEC           | 1019 1306 1403                                                                  |
| CORONADO         | 1002 1114                                                                       |
| CRAIG            | 1019                                                                            |
| CROSLEY          | 1034                                                                            |
| CROWN            | 1085 1107 1167 1002 1019 1114 1302                                              |
| CURTIS MATHES    | 1220 1008 1009 1010 1021 1033 1034 1072 1114 1299 1301 1304 1344 1355 1404      |
| CXC              | 1019                                                                            |
| CYBER HOME       | 1338 1002                                                                       |



|                  |                                                                                                                                                             |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DAEWOO           | 1033 1032 1114 1120 1218 1301 1019 1002 1458 1<br>405 1406 1407                                                                                             |
| DAYTEK           | 1120 1292                                                                                                                                                   |
| DAYTRON          | 1114 1301                                                                                                                                                   |
| DELUX            | 1020                                                                                                                                                        |
| DENON            | 1009                                                                                                                                                        |
| DIAMOUD          | 1139                                                                                                                                                        |
| DISH             | 1041 (MODEL: 100840)                                                                                                                                        |
| DISNEY           | 1258                                                                                                                                                        |
| DUMONT           | 1087 1098 1015 1301                                                                                                                                         |
| DURABRAND        | 1020 1081 1113 1141 1348                                                                                                                                    |
| DWIN             | 1008 1072                                                                                                                                                   |
| DYNASTY          | 1019 1028 1032                                                                                                                                              |
| DYNEX            | 1260 1261 1279 1278                                                                                                                                         |
| ELECTROBAND      | 1002 1306                                                                                                                                                   |
| ELECTROHOME      | 1114 1408                                                                                                                                                   |
| ELECTROLIGHT     | 1322                                                                                                                                                        |
| ELECTROTUNE      | 1305                                                                                                                                                        |
| ELEKTRA          | 1011 1074 1019 1023 1032 1044 1033 111<br>4 1218 1299 1301 1303 1304 1326                                                                                   |
| ELEMENT          | 1281 1282 1283 1284                                                                                                                                         |
| ELTEC            | 1342                                                                                                                                                        |
| EMERSON          | 1013 1026 1062 1087 1199 1014 1019 1020 1021 1<br>023 1027 1033 1038 1114 1198 1259 1298 130<br>1 1303 1306 1341 1343 1409 1410 1411 1412 1413<br>1414 1415 |
| ENVISION         | 1250 1251 1252 1253 1254                                                                                                                                    |
| ER-21613 (XZ415) | 1293                                                                                                                                                        |
| FECCO            | 1090                                                                                                                                                        |
| FEEL-NOLOGY      | 1104 1105                                                                                                                                                   |
| FISHER           | 1021 1317 1060 1075 1077 1106 1112 1113 1180                                                                                                                |
| FLO              | 1231                                                                                                                                                        |
| FUJITSU          | 1314 1320 1317                                                                                                                                              |
| FUNAI            | 1012 1013 1019 1067 1198 1199 1298 1416                                                                                                                     |
| FUTRONIC         | 1113 1125 1132 1141                                                                                                                                         |
| FUTURETECH       | 1019                                                                                                                                                        |
| GE               | 1007 1008 1010 1088 1120 1015 1017 1018 1031 1<br>033 1043 1072 1081 1301 1305 1317 1347 1355                                                               |
| GFM              | 1013 1198 1199                                                                                                                                              |
| GIANT            | 1082 1064                                                                                                                                                   |
| GIBRALTER        | 1015 1301                                                                                                                                                   |
| GOLDMUND         | 1118                                                                                                                                                        |



|                |                                                                                                                     |
|----------------|---------------------------------------------------------------------------------------------------------------------|
| GOLDSTAR       | 1044 1097 1183 1114 1301 1028 1417 1418 1419                                                                        |
| GOLDTEXT       | 1051                                                                                                                |
| GOTECH         | 1051                                                                                                                |
| GO VIDEO       | 1010 1304                                                                                                           |
| GRADIENTE      | 1005 1033 1058 1061 1063 1070 1080 1301                                                                             |
| GRUNDIG        | 1054 1055 (SAT) 1056 (VIDEO) 1096                                                                                   |
| GRUNPY         | 1019 1298                                                                                                           |
| HAIER          | 1348 1219 1221 1267 1268 1269 1270 1271 1272 1289                                                                   |
| HALLMARK       | 1301                                                                                                                |
| HANSTAI        | 1300                                                                                                                |
| HANTEK         | 1019                                                                                                                |
| HARMAN /KARDON | 1034                                                                                                                |
| HARLY DAVIDSON | 1298                                                                                                                |
| HARVARD        | 1019                                                                                                                |
| HAVERMY        | 1072                                                                                                                |
| HCI            | 1196 1197                                                                                                           |
| HDE            | 1131                                                                                                                |
| HELLO KITTY    | 1033                                                                                                                |
| HITACHI        | 1009 1025 1089 1021 1234 1266 1083 1111 1114 1001<br>1172 1299 1301 1309 1310 1420 1421 1422 1423 1424<br>1425 1390 |
| HIMITSU        | 1019 1038                                                                                                           |
| HISENSE        | 1126 1130 1141 1154 1157 1169 1290                                                                                  |
| HITECH         | 1103                                                                                                                |
| HP             | 1249                                                                                                                |
| HPS            | 1033 1047 1064 1067                                                                                                 |
| HYUNDAI        | 1020 1021 1108 1148 1289                                                                                            |
| ILO            | 1233 1349 1352                                                                                                      |
| INFINITY       | 1034                                                                                                                |
| INSIGNIA       | 1255 1256 1257 1258 1259 1260 1261 1277 1278 1279 1280 1470                                                         |
| INTEQ          | 1015                                                                                                                |
| ITT NOKIA      | 1078                                                                                                                |
| JBL            | 1034                                                                                                                |
| JCB            | 1002                                                                                                                |
| JC PENNEY      | 1003 1008 1114 1301 1304 1316 1317 1347 1355                                                                        |
| JEC            | 1034 1298                                                                                                           |
| JENSEN         | 1002 1034                                                                                                           |
| JERROLD        | 1035 1036                                                                                                           |
| JVC            | 1031 1259 1005 1426                                                                                                 |



|            |                                                                           |
|------------|---------------------------------------------------------------------------|
| JWIN       | 1104                                                                      |
| KAWASHO    | 1313                                                                      |
| KEC        | 1019                                                                      |
| KENBROWN   | 1026                                                                      |
| KENWOOD    | 1002 1301                                                                 |
| KINGSEI    | 1029                                                                      |
| KIREY      | 1019                                                                      |
| KMC        | 1002                                                                      |
| KOWBNOW    | 1081                                                                      |
| KOLIN      | 1200 1201 1202 1203                                                       |
| KONKA      | 1038 1062 1086 1218 1255 1258 1350 1427 1428 1<br>429                     |
| KOTRON     | 1074                                                                      |
| KTV        | 1002 1019 1032 1114 1298 1302 1303 1306                                   |
| KURAZAI    | 1299                                                                      |
| KWORLD     | 1170 1294                                                                 |
| LCD (3517) | 1176                                                                      |
| LEXUS      | 1020                                                                      |
| LG         | 1022 1011 1044 1301 1183 1001 1358 1359 1360 1<br>361 1299 1015 1392 1384 |
| LODGENET   | 1299 1324                                                                 |
| LOEWE      | 1034                                                                      |
| LOGIK      | 1148 1153 1155 1299                                                       |
| LOWE       | 1010                                                                      |
| LUXMAN     | 1301                                                                      |
| LXI        | 1003 1008 1015 1021 1034 1072 1301 1355                                   |
| MAGNAVOX   | 1034 1076 1114 1298 1301 1306 1317 1325 1430 1<br>431 1432 1382           |
| MAJESTIC   | 1034 1301                                                                 |
| MATSUI     | 1034                                                                      |
| MATSUSHITA | 1014                                                                      |
| MAXENT     | 1333                                                                      |
| MEGATRON   | 1009 1028 1043 1301                                                       |
| MEI        | 1306                                                                      |
| MEMOREX    | 1182 1188 1270 1014 1021 1259 1298 1299 1301<br>1304                      |
| MERRITT    | 1032                                                                      |
| MGA        | 1301                                                                      |
| MICROSONIC | 1048                                                                      |
| MIDLAND    | 1008 1015 1114 1317 1355                                                  |
| MIKADO     | 1010 1304                                                                 |
| MILLROCK   | 1194                                                                      |



|                 |                                                                                 |
|-----------------|---------------------------------------------------------------------------------|
| MIRACLE         | 1113                                                                            |
| MITSUBISHI      | 1006 1046 1065 1082 1287 1301 1059 1072                                         |
| mitsui          | 1023 1002 1019 1020 1038 1142 1218 1341 1343                                    |
| MITACHI         | 1019                                                                            |
| MONTGOMERY WARD | 1002 1072 1301                                                                  |
| MOTEVA          | 1012                                                                            |
| MOTOROLA        | 1072 1305 1456                                                                  |
| MTC             | 1019 1114 1300 1301 1304 1306                                                   |
| MULTITECH       | 1019                                                                            |
| MUSTANG         | 1107 1167                                                                       |
| NAD             | 1003 1301 1344                                                                  |
| NAOKI           | 1037 1020                                                                       |
| NEC             | 1321 1095 1301 1305 1259 1340                                                   |
| NEWTECH         | 1021                                                                            |
| NICO            | 1026                                                                            |
| NIKKO           | 1003 1015 1021 1032 1301                                                        |
| NIPPON          | 1301                                                                            |
| NOKIA           | 1078                                                                            |
| NOBLEX          | 1021 1066 1068 1084 1085 1093 1117 1158 1163 1164 1171 1173 1175 1177 1393 1389 |
| NORCENT         | 1252 1269 1332                                                                  |
| NOSHI           | 1316                                                                            |
| NUEVO           | 1048                                                                            |
| NTC             | 1032                                                                            |
| NU-TEC          | 1289                                                                            |
| OLEVIA (LCD)    | 1327 1202 1455                                                                  |
| OLIVIA          | 1200 1201 1202 1203 1327                                                        |
| OLYMPIC         | 1048                                                                            |
| ONCOMMAND       | 1323                                                                            |
| ONKING          | 1019                                                                            |
| ONWA            | 1019                                                                            |
| OPTIMUS         | 1014 1021 1344                                                                  |
| ONIDA           | 1005                                                                            |
| OPTONICA        | 1072 1340 1346                                                                  |
| ORION           | 1278 1026 1259 1298                                                             |
| PACK            | 1032                                                                            |
| PACIFIC         | 1019                                                                            |
| PACKARD BELL    | 1019 1032 1114 1299 1304                                                        |
| PANASONIC       | 1014 1069 1021 1023 1030 1031 1072 1229 1230 (ID) 1301 1304 1305 1340 1346 1454 |
| PANATRONIC      | 1259 1302                                                                       |
| PANABlack       | 1014                                                                            |



|                  |                                                                                                                                                                                 |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PAXAN            | 1033                                                                                                                                                                            |
| PDI              | 1183 1184 1185 1186                                                                                                                                                             |
| PHILCO           | 1019 1020 1025 1032 1033 1002 1009 1034 1038<br>1045 1052 1072 1076 1114 1259 1301 1305 1306<br>1317 1074 1086 1341 1343                                                        |
| PHILCO-VCR       | 1052                                                                                                                                                                            |
| PHILIPS          | 1001 1005 1016 1339 1034 1012 1047 1050 1051<br>1345 1053 1057 1066 1067 1184 1187 1213 121<br>4 1215 1222 1252 1325 1433 1382                                                  |
| PHILIPS RC2144   | 1051                                                                                                                                                                            |
| PHILIPS-MAGNAVOX | 1001 1005 1016 1034 1012 1339 1047 1050 1051 1053<br>1057 1066 1067 1184 1187 1213 1214 1215 1222 1252                                                                          |
| PILOT            | 1114 1301                                                                                                                                                                       |
| PIONEER          | 1010 1301 1309 1344 1434                                                                                                                                                        |
| POLAROID         | 1188 1189 1205 1206 1207 1208 1209 1210 1211 1<br>330                                                                                                                           |
| POLOROID         | 1255 1258 1259 1278 1353                                                                                                                                                        |
| PORTLAND         | 1002 1032 1033 1114 1301                                                                                                                                                        |
| PRIMA            | 1002 1048 1260                                                                                                                                                                  |
| PRISM            | 1034                                                                                                                                                                            |
| PROSCAN          | 1008 1031 1248 1301 1355                                                                                                                                                        |
| PROTON           | 1301 1457 1435                                                                                                                                                                  |
| PROVIEW          | 1281 1282 1283 1284                                                                                                                                                             |
| PULSAR           | 1015 1301                                                                                                                                                                       |
| PXCATV           | 1100 1102                                                                                                                                                                       |
| QUASAR           | 1014 1031 1305 1340 1346                                                                                                                                                        |
| RADIO SHACK      | 1002 1008 1019 1021 1114 1301 1340 1346 1355                                                                                                                                    |
| RANSER           | 1119                                                                                                                                                                            |
| RC123 (AGT)      | 1109                                                                                                                                                                            |
| RCA              | 1007 1008 1017 1018 1115 1120 1297 1301 1<br>305 1309 1316 1317 1010 1033 1072 1090 134<br>4 1355 1356 1357 1362 1363 1364 1436 1437<br>1438 1439 1440 1441 1442 1443 1444 1386 |
| RCA HOTELERO     | 1017                                                                                                                                                                            |
| RCONWA           | 1086                                                                                                                                                                            |
| RC27T08          | 1296                                                                                                                                                                            |
| RC-Y35 (NAN 2)   | 1152                                                                                                                                                                            |
| REALISTIC        | 1019 1021 1114 1301 1340 1346                                                                                                                                                   |
| RINEX            | 1107                                                                                                                                                                            |
| RECCOR           | 1144                                                                                                                                                                            |
| RHAPSODY         | 1306                                                                                                                                                                            |
| ROOMCONX         | 1354                                                                                                                                                                            |



|                       |                                                                           |
|-----------------------|---------------------------------------------------------------------------|
| ROYAL                 | 1034 1341                                                                 |
| ROYAL OROWN           | 1302                                                                      |
| ROWA                  | 1124                                                                      |
| RUNCO                 | 1015 1299 1301 1351                                                       |
| SAMPO                 | 1114 1301                                                                 |
| SAMSOUN               | 1073                                                                      |
| SAMSUNG               | 1010 1088 1042 1066 1068 1074 1078 1114 1301 1<br>304 1312 1315 1002      |
| SAMSUX                | 1114                                                                      |
| SANSUI                | 1090 1122 1123 1137 1259 1278 1291                                        |
| SANYO                 | 1021 1060 1075 1077 1106 1112 1113 1180 12<br>85 1286 1319<br>1019 1317   |
| SCEPTRE               | 1385                                                                      |
| SCIMITSU              | 1301                                                                      |
| SCOTT                 | 1019 1026 1114 1298 1301                                                  |
| SEARS                 | 1003 1008 1012 1021 1032 1034 1114 1298 1301 1<br>304 1317                |
| SEMIVOX               | 1019                                                                      |
| SEMP                  | 1049 1121 1003                                                            |
| SENR                  | 1373                                                                      |
| SENSEI                | 1033                                                                      |
| SHARP                 | 1004 1040 1072 1095 1114 1160 1161 1287 1298 1<br>301 1340 1346 1445 1446 |
| SHENG CHIA            | 1072                                                                      |
| SHOGUN                | 1019 1298 1301 1304                                                       |
| SHIMASU               | 1298                                                                      |
| SIGNATURE (2000)      | 1027 1072 1299 1301                                                       |
| SIMILAR               | 1048                                                                      |
| SIMPSON               | 1317                                                                      |
| SINGER                | 1012 1032 1033 1034 1304                                                  |
| SOLE                  | 1471                                                                      |
| SONIC                 | 1144                                                                      |
| SONY                  | 1002 1311 1212 1395 1383 1381                                             |
| SONY 2-13 CHAN        | 1002 1311                                                                 |
| SONY PANTALLA         | 1002                                                                      |
| SONY RM-720           | 1002                                                                      |
| SONY TRINITRON MENU   | 1002                                                                      |
| SONY TRINITRON SELECT | 1002                                                                      |
| SONY WEGA MENU        | 1002                                                                      |
| SOYO                  | 1235 1236 1237 1238 1239 1240 1241 1242 12<br>43 1244 12451246 1247       |



|              |                                                                                                        |
|--------------|--------------------------------------------------------------------------------------------------------|
| SOUNDESING   | 1019 1298 1301                                                                                         |
| SPECTRICON   | 1028                                                                                                   |
| SQUAREVIEW   | 1012 1447                                                                                              |
| SSS          | 1019 1301                                                                                              |
| STARLITE     | 1019                                                                                                   |
| SUPERSONIC   | 1019 1285                                                                                              |
| SUPREME      | 1002                                                                                                   |
| SVA          | 1091 1269                                                                                              |
| SYLVANIA     | 1198 1199 1012 1013 1034 1114 1301 1306 1317 1<br>448                                                  |
| SYMPHONIC    | 1198 1199 1012 1013 1019                                                                               |
| SYNTAX       | 1200 1201 1202 1203                                                                                    |
| S/M (LCD)    | 1265 1335 1336 1453                                                                                    |
| T-07 (NAN 2) | 1142                                                                                                   |
| TAHOCI       | 1094                                                                                                   |
| TANDY        | 1072                                                                                                   |
| TAKATA       | 1181                                                                                                   |
| TAKUMN       | 1261                                                                                                   |
| TATUNG       | 1305                                                                                                   |
| TCL          | 1090 1128 1386                                                                                         |
| TECHNOL ACE  | 1298                                                                                                   |
| TECHNOVALLEY | 1019 1032 1259 1301 1304 1303                                                                          |
| TECHNICS     | 1014 1015 1031                                                                                         |
| TECHWOOD     | 1032 1298 1301                                                                                         |
| TEDELEX      | 1145 1146 1147 1149 1150                                                                               |
| TEKNIKA      | 1019 1032 1034 1114 1298 1299 1301 1304                                                                |
| TELEFUNKEN   | 1063 1079 1088 1099 1101 1127 1129 1133 1134 1<br>135 1136 1138 1140 1150 1156 1289 1291 1301 10<br>10 |
| TELERENT     | 1299                                                                                                   |
| TERA         | 1378                                                                                                   |
| THOMSON      | 1110                                                                                                   |
| THORENS      | 1019 1028 1309                                                                                         |
| TLC          | 1002 1090                                                                                              |
| TMK          | 1027 1301                                                                                              |
| TNCI         | 1015                                                                                                   |
| TOSAKI       | 1039                                                                                                   |
| TOPHOUSE     | 1057 1092 1113                                                                                         |
| TOSHIBA      | 1003 1380 1039 1049 1072 1174 1232 1288 1304 1<br>321 1021                                             |
| TOSONIC      | 1306                                                                                                   |
| TOTEVISION   | 1114                                                                                                   |



|                    |                                                                      |
|--------------------|----------------------------------------------------------------------|
| TVS                | 1259                                                                 |
| TRUTECH            | 1191 1192 1193                                                       |
| ULTRA              | 1076                                                                 |
| UNIREX             | 1019 1298 1341                                                       |
| VEA (LCD)          | 1335                                                                 |
| VECTOR RESEARCH    | 1301                                                                 |
| VERTEX             | 1248 1292                                                            |
| VICTOR             | 1005                                                                 |
| VIDTECH            | 1301                                                                 |
| VIDEOLOGIC         | 1032                                                                 |
| VIDIKRON           | 1034                                                                 |
| VIEWSONIC          | 1195 1262 1263 1264 1265 1266 1251 1273 1274 1<br>275 1276           |
| VIORE (LCD)        | 1145 1464                                                            |
| VIZIO              | 1187 1189 1190 1466 1467 1468 1469                                   |
| VTECH              | 1159                                                                 |
| WARDS              | 1003 1034 1298 1299 1301 1317 1340 1344 1346 1<br>347 1449           |
| WAYCON             | 1003                                                                 |
| WHARFADA           | 1151                                                                 |
| WESTINGHOUSE       | 1002 1223 1224 1225 1226 1227 1228 1398 1396 1<br>464                |
| WHITE WESTINGHOUSE | 1033 1259 1298                                                       |
| XR 1000            | 1299                                                                 |
| YAMAHA             | 1301 1318                                                            |
| YORK               | 1301                                                                 |
| YUPITERU           | 1019                                                                 |
| ZENITH             | 1015 1252 1032 1076 1259 1299 1301 1450 1451 1<br>452 1384           |
| ZENITH CONCIERGE   | 1015                                                                 |
| ZONDA              | 1028 1033 1057 1072 1081 1114 1289 1301 1303 1<br>304 1340 1342      |
| OTHERS             | 1010 1011 1017 1020 1022 1031 1040 1164 12<br>59 1327 1328 1329 1330 |

