

YARD SIGN SET


Assembly Instructions

Includes 10 Yard Decorations and 20 Stakes

ASSEMBLY TIP: Choose the placement in your outdoor space before staking into the ground.



- 1 Two **Stakes** are included for each **Sign**. Use both **Stakes** to prevent spinning.



- 2 To insert the **Stake**, slide it into a **Flute** at the bottom of the **Sign** several inches or until you reach the edge of the shape.



- 3 Repeat with a second **Stake** for the **Sign**. Continue inserting two **Stakes** into each **Sign** until they are all assembled.



- 4 Push staked **Sign** into the ground. It will have more stability the further it is pushed in.

