





PCC-180

PC COMPUTER CASE

USER MANUAL

1 M/B installation


Put M/B on the M/B bracket, align the screw holes then fix the M/B by screws



different M/B has different installation characteristics, please refer to the user manual of your M/B before installation please refer to the user manual of your M/B before installation


2 Power Supply installation

Put PSU to the position as shown in the illustration, fasten the 4pcs screws of "a" positions



3 ODD installation


Take off the plastic front panel, then put ODD in the ODD bay according to the arrow direction shows in the following illustration, align the screws holes of both sides, then fix ODD by screws



Please note:
ODD installation depends upon if the front panel is with or without ODD position.
If the front panel is without ODD position, then ignore it

4 HDD installation

Put 3.5"HDD in HDD bay as shown in the following illustration, align the screw holes, then fix HDD by screws




1×3.5"HDD or 1×2.5"SSD can be mounted on the bottom cover

5 SSD installation


Put 2.5" SSD on the SSD mounting positions as shown in the following illustration, then fix it by screws

■ SSD installation (1)




3×SSD can be installed on the M/B bracket as shown in the above illustration

■ SSD installation(2)




1×3.5"HDD or 1×2.5"SSD can be mounted on the bottom cover

6 FAN positions available



1



2