

BLINDER

QUICK START GUIDE

1300



WHAT'S IN THE PACK



OPERATION



*NOTE THE BLINDER 1300 IS PACKAGED IN DEMO-MODE. TO ENABLE FULL FUNCTION OF THE LIGHT, CONNECT IT TO A USB-C CHARGER.




LONG PRESS (2 SECS) - ON/OFF
QUICK PRESS - CHANGE MODE
DOUBLE PRESS - TOGGLE BETWEEN STEADY & FLASH MODES
QUICK PRESS WHEN OFF TO CHECK BATTERY STATUS


CHARGING



LIFT THE CHARGING-PORT HATCH.



INSERT USB TYPE-C CHARGING CABLE.





ONCE THE CHARGE CABLE IS INSERTED, THE POWER BUTTON WILL GLOW AMBER INDICATING THE BLINDER IS NOW IN CHARGING MODE.



ONCE FULLY CHARGED, THE POWER BUTTON WILL GLOW GREEN. AFTER 1 MINUTE THE GREEN LIGHT WILL TURN OFF.

BATTERY STATUS



A QUICK PRESS OF THE POWER BUTTON WHEN THE LIGHT IS SWITCHED OFF WILL INDICATE THE BATTERY STATUS.



WHEN THE POWER BUTTON LIGHT IS FLASHING RED, THE LIGHT'S OUTPUT WILL BE REDUCED TO 30% TO PRESERVE RUNTIME.

MOUNTING

BAR MOUNT




22.2 mm Ø BAR
26 mm Ø BAR
31.8 mm Ø BAR
35 mm Ø BAR

SELECT THE CORRESPONDING HOLE TO SUIT YOUR BAR DIAMETER.



FIRMLY HOLD THE MOUNT IN PLACE & STRETCH THE STRAP DOWNWARDS.



THEN PULL THE STRAP AROUND THE BAR & SECURE ON THE HOOK.




PLACE THE LIGHT IN THE CRADLE.



COMPLETE MOUNTING BY PULLING UP ON THE TAB WHILE APPLYING DOWNWARD PRESSURE TO CLICK THE LIGHT INTO POSITION. MAKE SURE THE LIGHT IS SECURE BEFORE RIDING!

TO REMOVE, PRESS DOWN ON TAB & GENTLY PULL LIGHT AWAY FROM CRADLE.

UNDER MOUNT



LOCKED UN-LOCKED

UN-LOCKED.

PLACE THE LIGHT INSIDE THE MOUNT IN THE UN-LOCKED POSITION.

LOCK THE UNDER-MOUNT.

MAKE SURE THE UNDER-MOUNT IS LOCKED BEFORE RIDING. DO NOT RIDE WITH THE UNDER-MOUNT UNLOCKED!

REFER TO YOUR GO-PRO OR COMPUTER MOUNT INSTRUCTIONS TO COMPLETE BLINDER UNDER-MOUNT INSTALLATION.

MODES & RUNTIMES

MODE	LUMENS	RUNTIME
High	1300	1.5hr
Medium	650	3hr
Low	230	8hr
Pulse	420	8hr
Strobe	230	16hr
Eco	150	120hr

DESIGNED BY KNOG MELBOURNE, AUSTRALIA

2 YEAR WARRANTY

KNOG.COM