

Surround
first



Quick Start Guide

Octane-40
Sound Bar



I. Important - Warnings and Safety

1. Do not place the speaker near heat sources such as fire, radiators, stoves and other apparatus that produce heat.
2. Use only accessories supplied by FINGERS.
3. It is recommended to refer all servicing to qualified personnel. Servicing is required when the speaker has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

II. Care and Maintenance


1. Switch off the speaker before cleaning it.
2. Use soft, damp cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.

III. In the box

- 1 x FINGERS Octane-40 Sound Bar
- 1 x Remote Control
- 1 x AUX Cable
- 1 x Power Cord
- 2 x Wall-mounting Brackets
- 1 x Screw Set
- 1 x Quick Start Guide
- 1 x Brand Note



IV. On-board Controls



#	Function	Operations
1	Power On/ Stand-by	Short press - To switch between stand-by & operational mode
2	Mode	Short press - To switch between BT USB HDMI(ARC) Optical AUX Mode
3 +	Next Track/ Increase Volume	Short Press - To navigate to Next track (in BT/USB/HDMI ARC modes) Long Press - To increase the volume level (in all modes)
3 -	Previous Track/ Decrease Volume	Short Press - To navigate to previous track (in BT/USB/HDMI ARC modes) Long Press - To decrease the volume level (in all modes)

LED display



Displays details of Mode input, Equalizer, Volume levels, Tracks, etc.

Details:

1. Red LED: Standby mode

2. BT: In BT mode


3. USB: In USB mode

4. AUX: Auxiliary input mode

5. OPT: Optical mode

6. ARC: HDMI (ARC) mode

V. Connections




#	Connection	Description
1	HDMI(ARC)	Enable to connect compatible devices using HDMI ARC cable
2	OPTICAL IN	Enable to connect compatible devices using an Optical cable
3	USB Port	Enable to connect a Pen drive for direct MP3/WAV playback
4	AUX IN	Enable to connect compatible devices using 3.5 mm AUX cable
5	Power Switch	Power On-Off switch
6	AC IN	Use to connect the AC power cord

Note: To prevent malfunction and/or damage to speakers or other devices, we recommend to always turn the volume down and switch OFF all the power devices before making any connections.



VI. Connect the Sound Bar

A. Power your system




i. Plug the power cord of Sound Bar into the Socket




ii. Insert AAA batteries in the remote

B. Connect to TV



C. Connect to other devices



D. Placement of Sound Bar & Wireless Sub-Woofer



a) On Table/ Flat Surface

- Place the Sound Bar on the table/flat space.




b) Wall Mounting

Fix the screw on the wall with Wall-mounting brackets and screw set provided. Hook the Sound Bar on the wall.



VII. Remote Control



1. Power/Stand-by: To switch between stand-by and operational mode
2. Mute: To enable or disable volume mute of the system
3. VOL +/-: To adjust volume level of the speaker system
4. Play/Pause: In BT/USB/ HDMI(ARC) - To Play/Pause current track
In AUX and Optical mode - As Volume Mute function
5. Next Track/Previous Track: To select Previous/Next Track in BT/USB/HDMI ARC mode
6. Mode: To navigate among various playback modes of Bluetooth, USB, AUX, Optical and HDMI(ARC)
7. Repeat: To repeat One/All track in USB Mode
8. BT: To directly go to Bluetooth Mode
9. USB: To directly go to USB Mode
10. AUX: To directly go to AUX Mode
11. OPT: To directly go to Optical Mode
12. HDMI ARC: To directly go to HDMI ARC Mode
13. EQ: To select different equalizers - Music (EQ1), Movie (EQ2) and News (EQ3)
14. BASS +/- : To adjust bass levels of the speaker system
15. TREBLE +/-: To adjust treble levels of the speaker system
16. 3D: To select 3D effect ON/OFF




VIII. Modes

You can enjoy your music in the following ways

i. BT ii. USB iii. Optical iv. HDMI(ARC) v. AUX

i. BT

- Press on the mode button till the voice prompt of the word “BT mode” is heard.
 - The LED screen highlights “BT” signifying that it is ready to pair a device.
 - Make sure that Bluetooth is enabled on your device.
 - Find the device list and select FINGERS Octane-40.
- A sound prompt of “Connected” is heard and it is ready to play.



ii. USB

- Insert the USB device (Pen Drive) in the provided port.
- Press the mode button till the voice prompt of the word “USB mode” is heard.
- You can then play your favourite tracks directly from the USB Disk.

iii. AUX

- If you wish to listen to music from mobile devices, plug in the AUX cable in the AUX port.
- Press the mode button till the voice prompt of the word “AUX mode” is heard.
- You can then stream music directly from your mobile devices.

iv. Optical

- If you wish to listen to music from TV or other devices with Optical out, plug in the Optical cable in the Optical port.
- Press the mode button till the voice prompt of the word “Optical mode” is heard.
- You can then stream music directly from your devices.



v. HDMI (ARC)

- If you wish to listen to music from TV or other devices with HDMI ARC out, plug in the HDMI ARC compatible cable in the HDMI(ARC) port.
- Press the “Mode symbol” button till the voice prompt of the word “HDMI mode” is heard.
- You can then stream music directly from your TV.

X. Product Specifications

Parameters	Octane-80
Wireless Protocol	Bluetooth v5.0
Total Output Power	40 W Sound Bar: 10W x 4 = 40W
Input Power	AC 110 ~ 240 V
BT Supported profiles	A2DP, AVRCP, AVDTP, AVCTP, GAVDP
Driver unit	Sound Bar: 4 x 2.25" (4 Ω)
Playback Options	BT* USB AUX Optical HDMI ARC
BT Frequency Range	2.402 GHz ~ 2.480 GHz
Effective Range	Up to 10 m
Dimensions	Sound Bar: 935 x 65 x 92 mm
Weight	2.0 kg
Colors	Rich Dark Silver

*When connected via BT Mode - you can move around and play music within a wireless range of up to 10 m, with audio fidelity keeping stable and intact throughout.





Ver.: 1.0.0

Stay connected with us

f @fingers.co.in  @FingersIndia  @FingersIndia

Customer Service

- Support email: customer.care@fingers.co.in
 - 022-4938 7600: Mon - Fri (9.30 am to 6.30 pm)
- For further information, please visit www.fingers.co.in

• Images shown may vary from actual product.
• Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website www.fingers.co.in

