

# Analog DECT Phone



AMT-9210-SM / AMT-9110-SM

AMT-9210-SM-7979 / AMT-9110-SM-7979

ASP-9210-SM / ASP-9110-SM

ASP-9210-SM-7979 / ASP-9110-SM-7979

## QIG

## V 1.00



# 1 Overview

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

## Package Contents

When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. Base Unit
2. Handset
3. Stand
4. AC Adaptor
5. RJ-45 Cable
6. Quick Installation Guide (This document)

## 2 Product Description

The following contains important information to help you familiarize with the functions of the VoIP phone.

### Front View




#### 1. Base unit keys

|   | Name                      | Description                                        |
|---|---------------------------|----------------------------------------------------|
| 1 | Message waiting indicator | To indicate an incoming call or unread messages.   |
| 2 | Speed dial keys           | Press to dial the preset number.                   |
| 3 | Alphanumeric keys         | Press these keys to enter phone numbers and texts. |
| 4 | Function keys             |                                                    |
|   | HOLD                      | Press to put an active call on hold.               |
|   | REDIAL                    | Press to call the last number dialed.              |



| Name            | Description                                                                                                                                                                            |
|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CONF            | Press to activate the three-way conference call.                                                                                                                                       |
| MUTE            | Press to mute a call.                                                                                                                                                                  |
| SPEAKER         | Press to activate the speakerphone for hands free conversations.                                                                                                                       |
| MESSAGE         | Press to retrieve voice messages.                                                                                                                                                      |
| VOLUME          | Press to increase or decrease the volume of the ringer tone or speakerphone.                                                                                                           |
| LINE 1 / LINE 2 | To indicate a line been used as the following status:<br>- Idle: No LED indication.<br>- Pre-dialing a call: Green LED.<br>- In call: Red LED.<br>- In on-hold call: Blinking red LED. |

## Back View




| NO. | Name             | Description                   |
|-----|------------------|-------------------------------|
| 1   | DC 6V Power jack | Connects to AC power adapter. |
| 2   | PSTN line port   | Connects to PSTN line.        |




# Connecting the Phone

The following illustration shows how to connect the power



The following illustration shows how to install the phone and stand.



## 3 Operation

### Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator. You can answer the call by doing one of the followings:

- Pick up the **handset** to answer the call.
- Press the **Line (Line1/Line2)/Speaker** key to answer the call.

### Making a Call

#### Dialing with the Keypad

- Enter the telephone number with the alphanumerical keypad.
- After entering the number you want to call, press the # key to force dialing or wait for 4 seconds before the number is dialed automatically.

### Using the Speed dial keys

You can use the 10 pre-assigned speed dial hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using speed dialing, follow the steps below:

- Press the speed dial hotkey that has been pre-assigned to the phone number and the call will start automatically.

## Call Options

While a call is in progress, a number of additional options are available.

## Using the Speaker Phone

For hands free operation, you can use the built-in speaker to talk on the phone. To use the speakerphone, follow the steps below:

- While talking on the phone, press the **SPEAKER** key on the phone to enable the Speakerphone function.
- Press **SPEAKER** key again to terminate the call.

## Putting a Call on Hold

You may want to put a call on hold temporarily while doing some work or attending to a second incoming or outgoing call. To put a call on hold, do one of the following:

- Press the **HOLD** key on the phone to put the call on hold.
- When you receive a second call, press the next available **LINE** key to attend to the new call, and the first call will be put on hold automatically.

## Checking Voice Messages

If the **message waiting indicator** at top of handset or base unit lights up in red, it indicates that there are one or more new messages in voicemail box.

- Press the **MESSAGE** key on the phone to retrieve voice messages.

# 4 Support

For technological support, please email to [support@aeicommunication.com](mailto:support@aeicommunication.com).

