



Online Manual

To launch the online manual, press the HOME button, select Apps from the Home menu, and select "E-Instruction Manual" from the apps list.

What is included in the box

- Accessories
- Included with this TV are the following accessories
- 1 x Quick Start Guide
 - 1 x Remote Control and 2 x AAA Batteries
 - 1 x Safety Leaflet
 - 1 x Stand installation pack

Additional Accessories

If you don't have the RF cable shown below, then you can purchase one from www.umc-uk.co.uk/cables. If you are intending to connect your TV to an RF socket in order to receive Freeview you will need this cable.



RF Cable

This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.

Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.



Freeview Play brings together live TV viewing with "catch up" TV services such as BBC iPlayer, ITV player, More4 programmes, such as sport, comedy, dramas and soaps, etc. Content is made up from recommendations of the major broadcasters and offers an alternative means of searching.

Note that to use the full functionality of Freeview Play your set must be connected to the internet.

Sky Remote Code



If you wish to use your Sky remote to operate the TV's basic functions, you will need a Sky remote control (Revision 9 or later) and you will need to program it with the code 2134. If you wish to use your Sky Q remote to operate the TV's basic functions, you will need to program it with the code 4170.

Please save your box/packaging as you will need this in the event of warranty/service repair or support. We are unable to carry out warranty/service if you are unable to package it correctly. The safest way to package your item in the event of warranty/service repair is in it's original box/packaging.

Using the remote control



- Key**
- 1** **STANDBY** - Switch on the TV when in standby or vice versa. By long pressing of this button, the set will display a menu offering power down option to energy saving standby mode.
 - 2** **SOURCE** - To display the input/source menu.
 - 3** **NUMBER BUTTONS** - 0-9 to select a TV channel directly.
 - 4** **GUIDE** - Opens the 7 day TV guide (digital TV mode).
 - 5** **VOL (+/-)** - To increase/decrease the sound level.
 - 6** **The Google Assistant** - Use your voice to access entertainment, control smart devices, obtain answers on screen, and more.
 - 7** **HOME** - Display the TV Home Menu.
 - 8** **CH (+/-)** - To increase or decrease the channel being watched.
 - 9** **MENU** - Display LIVE TV menu. This button works only in sources (TV, HDMI, component, etc.). It will not work in the Home Menu.
 - 10** **INFO** - Press once for now/next channel information.
 - 11** **SUB** - Allows you to navigate the on-screen menus and adjust the system settings to your preference.
 - 12** **BACK** - To go back a previous step.
 - 13** **EXIT** - To exit all menus.
 - 14** **NETFLIX** - Access the Netflix App.
 - 15** **Prime video** - Access the Prime video App.
 - 16** **YouTube** - Access the YouTube App.
 - 17** **Freeview Play** - Access the Freeview Play app; service.
 - 18** **MTS** - Opens audio track menu.
 - 19** **TEXT** - To enter/exit teletext.
 - 20** **SUB** - To switch the dialogue at the bottom of the screen (on/off).
 - 21** **TV** - To switch to Live TV.
 - 22** **MI** - To play/pause media
 - 23** **MI** - To play in fast forward mode
 - 24** **MI** - To stop the playback
 - 25** **COLOUR BUTTONS** - Execute corresponding function at that time

SHARP

androidtv

Quick Start Set Up Guide

For information on using the TV's features, please refer to the Operating Instructions. (Available online to download.)

Model Numbers

40BN2KA **43BN2KA**
40BN3KA **43BN3KA**
40BN4KA **43BN4KA**
40BN5KA **43BN5KA**
40BN6KA **43BN6KA**

Register your manufacturers guarantee online within 14 days of purchase at www.registertoday.co.uk/sharp and enter into a prize draw to...



Quick & easy guide for setting up your TV

What is included in the box

Using the remote control

Setting up the TV for the first time - including attaching the stand

Connecting other devices to the Television

Need help setting up or using your TV?

Please contact the UK & ROI Helpline*

Telephone UK 0330 024 0803 or ROI 01443 3323

Online support at: www.umc-uk.co.uk

Email support at: service@umc-uk.co.uk

*Calls to 0330 numbers are charged at standard call rates and are included as part of any bundled minutes with your phone provider. Hours are correct at time of this document being published.
Please note these hours are subject to change periodically.
Calls to the ROI number are charged at the local call rate.

The telephone opening hours are:

Monday to Friday: 8.30am – 6pm

Saturday: 9am – 5pm

Bank Holidays: 10am – 4pm

Closed Christmas and New Years day.



Technical Specification

	40BN2KA 40BN3KA 40BN4KA 40BN5KA 40BN6KA	43BN2KA 43BN3KA 43BN4KA 43BN5KA 43BN6KA
Energy Efficiency Class (SDR)	G	
Power consumption (SDR)	58 W	65 W
Energy Efficiency Class (HDR)	G	
Power consumption (HDR)	95 W	103 W
Screen resolution (pixels)	3840 x 2160	
Screen Size (diagonal)	101 cm / 40 inches	108 cm / 43 inches
RF	75 ohm Antenna • Analog • DVB • Satellite	
Inputs	3 x HDMI • 3 x USB • 1 x SD card reader • 1 x RJ45 LAN/Ethernet 1 x Composite/CVBS Video & Component/YPbPr input • 1 x L/R Audio input for Composite/CVBS & Component/YPbPr	
Sound Outputs	1 x Digital Optical Audio output • 1 x 3.5mm Headphone	
Speaker*/ Amplifier Watts (RMS)	2 x 10 / 2 x 8	
Voltage and power consumption	AC 220V ~ 240V; 50Hz 58/90/110W (home mode/standard/max) (<0.5W in Standby)	AC 220V ~ 240V; 50Hz 65/95/115W (home mode/standard/max) (<0.5W in Standby)
Dimensions including stand (mm)	914W x 580H x 194D	968W x 610H x 194D
Net weight (Kgs)	6.8	7.4
Wall Mounting	VESA 200 X 200 (mm)	

*Built-in Harman Kardon speaker systems (Full-range speaker and tweeter).

SOUND SYSTEM BY
harman/kardon

Harman Kardon is trademark of
HARMAN International Industries,
Incorporated, registered in the
United States and/or other countries.

HDMI

The terms HDMI, HDMI High-Definition
Multimedia Interface, and the HDMI
Logo are trademarks or registered
trademarks of HDMI Licensing
Administrator, Inc.

androidtv

Google, Google Play,
YouTube, Android TV and
other marks are trademarks
of Google LLC.

Dolby Audio

Manufactured under license
from Dolby Laboratories. Dolby,
Dolby Audio, and the double-D symbol
are trademarks of Dolby Laboratories
Licensing Corporation.

Setting up the TV set for the first time



To obtain a copy of your Operating Instructions, please go to: https://www.umc-uk.co.uk/instruction-manuals/Sharp-TV_information.html

1 Fitting the stand


The TV panel must be facing downwards.

For the stand installation, there is one type of screw provided as shown below.


Note: To complete the stand installation you will require a cross head screw driver.




2 Connecting your set




3 Powering On the TV




4 First time installation



5 Pairing the remote



6 The Google Assistant



Win a


SHARP Soundbar

Register your manufacturers guarantee online within 14 days of purchase at www.registertoday.co.uk/sharp and enter into a prize draw to win a Sharp Soundbar

Terms and conditions apply. Online registration only.



Wall Mounting the TV



Connectivity

