

## Changing the filter

Equipment required:

Filter cartridge CLARIS Pro Smart<sup>+</sup>  
1 item (Art. 25055)







Filter cartridge CLARIS Pro Smart  
maxi 1 item (Art. 24146)



These short instructions do not replace the »X6 Instructions for Use«. Make sure you read and observe the safety information and warnings first in order to avoid hazards.

»Display«

Precondition:



»Saved«  
»Filter is being rinsed«  
»Empty drip tray«

