


GET THE FREE RUKUSfx[®] PRO STUDIO APP NOW



Download the RUKUSfx[®] PRO STUDIO APP now for in-depth tutorials, advanced features, games, and so much more.




Watch all the tutorials in the RUKUSfx[®] PRO STUDIO APP or at www.rukusfx.com/tutorial

A few important things to know before getting started:

1) RUKUSfx[®] PRO is NOT rechargeable. It uses 3 AAA batteries that are either pre-installed in your unit or included in the package. Remember to change the batteries if you ever experience issues with RUKUSfx[®] PRO.
NOTE: The USB port does NOT charge your RUKUSfx[®] PRO.

2) Download the RUKUSfx[®] PRO STUDIO APP from the Apple or Android app stores. With the APP installed, you'll be able to access all the advanced (and fun) features RUKUSfx[®] PRO has to offer, including games, advanced DJ tools and much more!



INSERT BATTERIES

To insert the batteries, unscrew the battery door with a Phillips head screwdriver and insert 3 AAA batteries as shown on the inside of the battery door once removed. Be sure to insert the batteries as shown.

3 POSITION SWITCH: OFF/MUSIC/ SOUND EFFECTS


There is a 3 position switch – OFF/MUSIC/SOUND EFFECTS. Please refer to the image above. In the MUSIC position, you can access the songs and instruments library. In the SOUND EFFECTS position, you can access the sound effects library.

BUTTON FUNCTIONS

There are several buttons on your RUKUSfx[®] PRO. What they do is shown above. To further understand what they can do and how to use them, please watch the video tutorial in the RUKUSfx PRO STUDIO APP or at www.rukusfx.com/tutorial

FOUR SIMPLE MOVES

The magic of RUKUSfx[®] PRO is that movement creates music and sound effects. HOW you move is super important for RUKUSfx[®] PRO to work the way it was designed. The four movements – PUNCH, SWIPE, FLICK, and TWIST-- are shown below. That said, it's really difficult to show precise movements on paper...you know, because paper doesn't move. So please watch the video tutorial for clear guidelines on how to perform each of the four moves. Watch tutorials on your RUKUSfx[®] PRO STUDIO APP or go to www.rukusfx.com/tutorial



Punch

Swipe



Flick

Twist



RUKUSfx[®] PRO

GET THE RUKUSfx[®] PRO STUDIO APP NOW



CREATE A SONG

Now that you've watched the tutorials (wink wink), you're ready to create your first song! Flip the switch on the side of the device to the second position shown (Music Mode). Now, click the "Next Song" button indicated above and scroll through until you find a song that connects with your soul (or just until you find one you like).

Next, try the four movements shown above. It might take a few tries to get them down perfectly, but the most important thing to remember is that your movements need to be clean and deliberate. If your PUNCH is more FLICK-Y than PUNCH-Y, then there's a pretty good chance RUKUSfx[®] PRO will interpret that move as a FLICK.

ADVANCED FEATURES: ALT TRACKS

Now that you've become a master of movement, you can effortlessly create songs with four different tracks. When you're ready to take creating to the next level, just press and hold the ALT Tracks Button (Trigger button), perform one of the four basic moves - PUNCH, SWIPE, FLICK, or TWIST - and you'll instantly have access to four new tracks. When you release the ALT Tracks button, you'll be back to playing the first four tracks. After a few minutes, you'll be mixing all eight tracks and creating songs seamlessly.

ADVANCED FEATURES: FREESTYLE / ALL STOP

Press and hold the Freestyle button to move freely without triggering a new music or sfx track. Now you can dance around to your hearts content without interrupting the current music track that is playing. Let go of the button and get back to creating music/sfx with motion. Double-tap the Freestyle button to immediately stop all music and sfx.

ADVANCED FEATURES: RECORDING

To **RECORD YOUR PERFORMANCES**, select a song you would like to perform. Press the Performance Record button. You will hear three short beeps. As soon as you hear the last beep, start performing your song (using PUNCH, SWIPE, FLICK or TWIST). When you're done, press the Performance Record button again. You will see a RED light followed by a series of colored lights prompting you to save your recording to one of the four basic moves (PUNCH, SWIPE, FLICK, or TWIST). Your recording will be saved into that position and you'll be able to play it back whenever you want. NOTE: you must save your performance to one of the four moves before the lights stop flashing. Otherwise, your recording will not be saved. Repeat the above process to record up to 7 more performances (with and without pressing the ALT Tracks Button). To access your recorded performances at any time, double press the Performance Record Button and you will be instantly brought to your recorded performances. Then PUNCH, SWIPE, FLICK, or TWIST to hear them.

To **RECORD WITH MICROPHONE**, press the Microphone Record button. You will hear three short beeps. As soon as you hear the last beep, start talking into the mic. When you're finished, press the Microphone Record button again. You will see a RED light followed by a series of colored lights prompting you to save your recording using one of the four basic moves (PUNCH, SWIPE, FLICK, or TWIST). Your recording will be saved into that position and you'll be able to play it back whenever you want. NOTE: You must save your recording to one of the four moves before the lights stop flashing. Otherwise, your recording will not be saved. Repeat the above process to record up to 7 more mic recordings (with and without pressing the ALT Tracks Button). To access your mic recordings at any time, double press the Microphone Record button and you will be instantly brought to your mic recordings. Then PUNCH, SWIPE, FLICK, or TWIST to hear them.

ADVANCED FEATURES: RUKUSfx[®] PRO STUDIO APP

With RUKUSfx[®] PRO connected to the STUDIO APP you'll have so many advanced features to explore.

DJ Mixing Tools
Advanced Audio Editing
New Song Creation

Music Layering
Beat Snap
Games and much more



We're here to help!

For customer support or questions
please email: support@rukusfx.com

WWW.RUKUSFX.COM

DOWNLOAD RUKUSfx[®] PRO STUDIO APP NOW!

RUKUSfx[®] PRO is manufactured by Kidfinity Inc,
Distributed by Just Play, LLC

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963. PRINTED IN CHINA Bluetooth[®]

CAUTION : Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



46808 RUKUS Pro- FA23
WB: 9"W x 3"D x 11"H
April 21, 2023

4.21.23
-added FCC ID and other info
-change tm to (R) for all Rukus logos
-updated dieline

MOCK INFO BOX
FOR: xx
WHEN: xx
MATERIALS: Poster and Lam
ZUND: RUKPro_FA23_46808_WB_AC_R21.pdf



MILLIONS OF COMBINATIONS.
Create original DJ style mixes from built-in music tracks and FX.

YOUR MOVES CONTROL THE MIXES.
Loop, mix, and remix with built-in tracks and sound FX or load-up your favorite music to remix.

MOTION CONTROLLED MUSIC MIXER + GAMING

- **120+** MIXABLE MUSIC TRACKS
- **120+** SOUND EFFECTS
- BUILT-IN SPEAKER
- LOAD-UP YOUR FAVORITE MUSIC

CONNECTS TO RUKUSfx PRO STUDIO APP

mixing.

Layer, mashup, and modulate tracks and sound FX to create custom mixes on the fly.

gaming.

Use RUKUSfx PRO as a controller for interactive gaming.

editing.

Cut up your favorite music to remix and play instantly on the device.



GET IT ON
 Google Play

Download on the
 App Store

www.rukusfx.com

@rukusfx @rukusfx @rukusfx

RUKUSfx PRO

Watch and share online
www.rukusfx.com

@rukusfx @rukusfx @rukusfx

GET IT ON
 Google Play

Download on the
 App Store

RUKUSfx PRO

Stickers

CONNECTS TO FREE
RUKUSfx PRO
STUDIO APP!

INCLUDES BONUS
SILICONE SKIN!



MOTION CONTROLLED MUSIC MIXER + GAMING

HAND-HELD MOTION CONTROLLED MUSIC MIXER

Loop, mix, and remix with 4 simple moves.



PUNCH



FLICK



SWIPE



TWIST

move.

Choose your music and move.
Create original DJ style mixes from built-in music tracks and FX.

mix.

Your moves control the mixes.
Loop and mix with the built-in tracks and sound effects or load-up your favorite music to remix.

create.

Millions of combinations.

- **120+** Mixable Music Tracks
- **120+** Sound Effects

Watch and share online
www.rukusfx.com

@rukusfx @rukusfx @rukusfx

GET IT ON
 Google Play

Download on the
 App Store

MOTION CONTROLLED

120+ MIXABLE MUSIC TRACKS

120+ SOUND EFFECTS

DJ STUDIO COMPANION APP

AGES 6+

WARNING: CHOKING HAZARD-
Small parts. Not for children under 3 years.

Includes: 1 RUKUS FX DEVICE, 1 SKIN, 3 AAA (LR03) BATTERIES

RUKUSfx PRO

RUKUSfx is manufactured by Radiality Inc.
Distributed by Just Play, LLC

Just Play

JUST PLAY LLC ©2023 JUST PLAY, LLC
4850 TREX AVE, SUITE 100
BOCA RATON, FL 33433, USA


Requires 3x "AAA" (LR03) type batteries.

- Battery Instructions**
1. Remove batteries when not in use or discharged.
 2. Do not mix old and new batteries.
 3. Do not use rechargeable batteries.
 4. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Replacement of batteries must be done by an adult.

Dispose of batteries safely.
Never dispose of batteries in fire, as they may leak and explode.

Product is shipped in "OFF" mode. Please switch from "OFF" to "Music" or "Sound effect" mode.



CAUTION: Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

1-800-317-3245
or write: customer@justplayproducts.com
Visit us at: www.justplayproducts.com

MADE IN CHINA
CONFORMS TO THE SAFETY REQUIREMENTS
OF ASTM F963.



See RUKUSfx
in action here

Please retain this address for future reference.
CAUTION: How an adult removes and disposes of all packaging, ties and fasteners before use.

In the interest of better quality and value, we are constantly improving and updating our products. Consequently, pictures on this package may sometimes vary from the product itself.

FCC ID: 2AAB4680300

