



INTRODUCTION


Thank you and congratulations on your choice of W-KING T8 Bluetooth Speaker.

Before using this speaker, please take a few minutes to read this manual, which includes detailed messages concerning the proper operation of the unit.

WHAT'S IN THE BOX

1. Main unit ×1
2. User Manual ×1
3. DC charging adapter ×1
4. 3.5mm audio cable ×1

PRODUCT OVERVIEW




- 1. Mode**
Short press: toggle between Bluetooth, USB, and AUX mode.
Press and hold: switch the prompt tone to Chinese or English
- 2. “-”**
Short press: decrease volume
Press and hold: the previous song

3. Play/Pause

Press to control music play or pause

4. “+”

Short press: increase volume
Press and hold: the next song



1. Power

Press and hold to power on/off

2. USB storage device reader

Connect to a USB storage device.

3. AUX IN

Connect to an external audio device through a 3.5mm audio cable.

4. Reset

Insert a pin to reset.

5. DC charging

Connect to the charging adapter.

6. Pairing

Press to disconnect the Bluetooth connection, and the speaker enters pairing mode.

USING YOUR W-KING T8

1. Bluetooth Connection

- Connect your W-KING T8 with Bluetooth-enabled devices.
- (1) Power on T8, it enter Bluetooth pairing mode automatically;
 - (2) Choose “W-KING T8” to connect.
 - (3) Once successfully connected, music will stream to this speaker.
- Disconnect Bluetooth connection
- (1) T8 can remember a maximum of 8 paired devices.
 - (2) In Bluetooth mode, press the pairing button, disconnect the Bluetooth connection.

Remarks:

- (1) Automatically turn off when there is no connection for 10 minutes.
- (2) Bluetooth transmission distance may vary with the environment.
- (3) When turning on this speaker next time, it will reconnect to the last connected device automatically. If not, please try manually.

2. Charging the Speaker

- Please use included adapter to charge the speaker.
- (1) Low battery prompt tone: when battery capacity is less than 10%;
 - (2) Low battery turn off: when battery capacity is less than 3%.

3. USB device reading

Insert a USB device into the USB reader slot.

The speaker will automatically switch to USB mode, and after 2 seconds it will automatically play music stored in the USB device.

** Support format: mp3, WMA, APE, FLAC, WAV*

4. AUX IN

Connect the music source device with T8 via included 3.5mm audio cable.
The speaker will automatically switch to AUX IN mode, then when you play music, it will stream to the T8 speaker.

LED INDICATOR

FUNCTION	INDICATOR
Bluetooth pairing	Blue LED flashes
Bluetooth connected	Blue LED stays on
USB mode	Cyan color; Playing: stays on; pause: flashes
AUX IN	Green color; Playing: stays on; pause: flashes
Low battery/charging	Red LED
Charging finish	Green LED

SPECIFICATIONS

Bluetooth version: 4.2
Product size: 265*100*195mm
Bluetooth transmission distance: 10 meters
Speaker drivers: woofer×2pcs, 80mm, 15W each;
tweeter×2pcs, 31mm, 8W each;
Speaker output: 30W
S/N:≥75dB
Charging: DC 15±0.5V/1.2A
Battery: built-in lithium battery, 3pcs battery cells
Total cells capacity 6000mAh;
Playtime: 5-8 hours

** Transmission distance is tested in open space without interference.
* The above data is based on WEIKING laboratory environment and test results; actual playtime may vary with environment and user habit, for reference only.*

SAFETY NOTICE

1. Please read and keep this manual for reference.
2. Do not open (or modify in any way) the unit or its AC adaptor.
3. Do not attempt to repair the unit, or replace parts within it. Refer all servicing to your retailer or an authorized W-KING distributor.
4. Never use or store the unit in an extreme temperature, humid or dusty environment; please do not expose the unit to rain or chemical materials, and it's dangerous to put it in vibration places, please make sure it's placed stable before using. Please avoid strong impact.
5. When used by children, please make sure an adult provides supervision until they are familiar with operation methods and safe operation notice.