




# User Manual

## Plastic 3-in-1 Spiralizer

Item #407SLCR31

**WARNING:** Blades are extremely sharp.



### Parts

- A) Spiralizing Platform and Crank
- B) Handle
- C) Blade Storage
- D) Slicer Blade

- E) Fine Shredder Blade
- F) Coarse Shredder Blade
- G) Non-Slip, Suction Feet



# User Manual

## Features

Includes 3 blades: slicer, fine shredder, and coarse shredder

Sturdy suction base

Works great with potatoes, zucchini, carrots, radishes, apples, cabbages

## Instructions

1. Screw face of the spiralizer and the crank into opposite sides of the handle so that the face will be towards the blade plate, the crank will be at the end of the spiralizer, and the handle at the base will be facing towards your body.
2. Press suction base to surface for security while using product.
3. Slide blade plate into place on your spiralizer, making sure the blade is locked into place.
4. Stick desired ingredient onto face of spiralizer, securing with the spikes.
5. Press vegetable or other ingredient into blade and apply pressure by twisting crank and holding handle.
6. Your food will be sliced on the other side of the spiralizer. Ensure that you have a bowl or container there for storage.

